

# USER MANUAL

## LC-WELD PRO

MANUFACTURER:

LASERCOMMERCIAL ENTERPRISE

B67583120

C/PERE ANDORRÀ, Nº 5, Nave 6

08650 SALLENT

(BARCELONA) SPAIN





# CONTENTS

CHAPTER 0 - PREFACE.....	7	2.6.1 MAXIMUM PERMISSIBLE EXPOSURE (MPE).....	30
ADDRESSEES.....	7	2.6.2 NOMINAL EYE RISK DISTANCE (DNRO) .....	30
SYMBOLS, WARNINGS AND CATEGORISATIONS USED IN THIS MANUAL.....	8	2.6.3 REFLECTED BEAM HAZARD .....	31
CHAPTER 1 - SUMMARY .....	9	2.6.4 LIGHT RADIATION AND RADIATION PROTECTION.....	33
1.1 INTRODUCTION.....	9	2.6.5 ULTRAVIOLET LIGHT .....	34
1.2 REFERENCES.....	10	2.7 ANALYSIS OF RISKS AND RISK FACTORS.....	35
1.3 TYPES OF USE.....	11	2.7.5 EYE HAZARD .....	35
1.3.1 INTENDED USE.....	11	2.7.6 SKIN HAZARD.....	36
1.3.2 UNINTENDED USE (FORESEEABLE MISUSE).....	12	2.7.8 IN-PROCESS HAZARDS .....	37
1.4 CERTIFICATION.....	13	2.7.9 SAFETY OF GAS CYLINDERS .....	40
1.4.1 CE MARKING .....	14	2.7.10 RISK ANALYSIS OF LC-WELD EQUIPMENT.....	40
1.5 DECLARATION OF CONFORMITY	15	2.8 SAFETY MARKINGS ON LASER EQUIPMENT AND LABELLING.....	44
CHAPTER 2 - SAFETY INFORMATION	16	2.8.1 REGULATORY COMPLIANCE .....	48
2.1 SYMBOLS AND WARNINGS IN THIS MANUAL .....	16	2.9 WORKPLACE.....	49
2.2 CLASSIFICATION OF THE LASER PRODUCT .....	17	2.9.1 SECURITY OF THE ENVIRONMENT.....	49
2.2.1 CLASSIFICATION OF LASER PRODUCTS.....	19	2.9.2 ESTABLISHMENT OF A CONTROLLED LASER AREA.....	50
2.2.1 LASER RADIATION AND SAFETY RISKS .....	20	2.9.3 SAFE WORKING SPACE: CONTROLLED LASER AREA.....	51
2.3 SECURITY INDICATORS.....	21	2.9.3 LASER SAFETY OFFICER (LSO).....	54
2.4 SAFETY GOGGLES AND MASK	22	2.10 ELECTRICAL SAFETY.....	55
2.4.1 SAFETY GLASSES .....	22		
2.4.2 WELDING MASK.....	26		
2.5 PPE CLOTHING .....	26		
2.6 LASER TECHNICAL DATA AND SAFETY RISKS .....	27		



2.11 PREVENTION AND SAFETY SYSTEMS .....	56	4.2.1 DATA LASER WELDING EQUIPMENT .....	69
2.11.1 POWER SUPPLY CIRCUIT .....	56	4.2.2 DATA WIRE FEEDER.....	70
2.11.2 "ground" CLAMP AND CONTROLS.....	56	4.2.3 LASER DATA.....	70
2.11.3 LASER EMISSION WARNINGS.....	57	4.2.4 DATA GUN .....	71
2.11.3 grounding .....	57	CHAPTER 5 - PACKING AND DELIVERY .....	73
2.11.4 ELECTRICAL PROTECTION MAGNETOTHERMICS .....	58	5.1 CONTENTS OF THE SHIPMENT OF THE LC-WELD PRO EQUIPMENT .....	73
2.12 TRAINING.....	58	5.2 DELIVERY .....	78
2.13 GENERAL SAFETY INSTRUCTIONS.....	59	5.3 INSPECTION ON DELIVERY .....	79
2.14 PROHIBITIONS .....	59	5.4 UNPACKING THE PACKAGE .....	79
CHAPTER 3 - LASER WELDING .....	61	CHAPTER 6 - INSTALLATION .....	81
3.1 DESCRIPTION .....	61	6.1 PRECAUTIONS.....	81
3.2 DIFFERENCES, ADVANTAGES AND DISADVANTAGES COMPARED TO OTHER WELDING TYPES .....	61	6.2 PREPARATION OF EQUIPMENT.....	81
3.3 LASER WELDING APPLICATIONS .....	62	6.2.1 ENVIRONMENTAL CONDITIONS.....	82
3.4 INTENDED USE OF THE LASER WELDING MACHINE.....	62	6.2.2 ELECTRICAL CONNECTION .....	82
3.4.1 MATERIALS SUITABLE FOR LASER WELDING .....	63	6.2.3 GAS CONNECTION.....	82
CHAPTER 4 - LASER WELDING EQUIPMENT .....	64	6.2.4 safety, cab and semaphore .....	83
4.1 EQUIPMENT COMPONENTS ....	64	6.2.5 COOLING AND COOLING WATER .....	86
4.1.1 OVERVIEW OF THE REAR OF THE EQUIPMENT .....	65	6.2.6 AIR OUTLET .....	87
4.1.2 LASER RESONATOR.....	66	CHAPTER 7 - USE OF the EQUIPMENT .....	88
4.1.3 CHILLER OR COOLER.....	66	7.1 GUN: PARTS, COMPONENTS AND OPERATION .....	89
4.1.4 FEEDER OR YARN FEEDER .....	66	7.1.1 "GROUND" CLAMP .....	89
4.1.5 DISPLAY.....	67	7.1.2 QBH .....	90
4.1.6 GUN .....	67	7.1.3 STEERING MIRROR SYSTEM .....	90
4.1.7. CONNECTION POINTS.....	69	7.1.4 FOCAL LENS.....	91
4.2 TECHNICAL DATA.....	69	7.1.5 SIRGA .....	92
		7.1.6 LENS PROTECTORS.....	92
		7.1.7 GAS in the gun.....	94

## ORIGINAL USER'S MANUAL



7.1.8 WELDING PIPE .....	94	8.5.1- NEW TASK .....	147
7.1.9 COLLIMATOR LENS .....	94	8.5.2. CURRENT TASKS .....	149
7.1.10 NOZZLES .....	95	8.5.3 TASKS PERFORMED .....	150
7.2 ROLLERS .....	98	8.5.4 GROUPS .....	152
7.3 SWITCHING THE EQUIPMENT ON AND OFF .....	99	8.6 CONFIGURATION .....	154
7.4 SWITCHING THE GUN ON AND OFF 100		8.6.1- LANGUAGE .....	155
7.5 FOCAL LENGTH.....	101	8.6.2 ETHERNET .....	156
7.5.1 CALCULATION OF THE FOCAL LENGTH.....	103	8.6.3 FACTORY RESETS.....	158
7.6 POSITIONING.....	106	8.6.4 ADMIN.....	159
7.7 WELDING .....	107	8.6.5 SYSTEM INFO.....	160
7.7.1 WELDING WITH MATERIAL CONTRIBUTION .....	107	8.6.6 UPDATE .....	160
7.7.1.4 STEP-BY-STEP THREAD ADJUSTMENTS .....	109	8.6.7 DATE & TIME .....	163
7.7.2 WELDING WITHOUT MATERIAL SUPPLY .....	115	8.7 HELP.....	163
CHAPTER 8 - SOFTWARE .....	117	8.7.1- DOCUMENTATION .....	164
8.1 STARTING THE SOFTWARE ...	117	8.7.2- VIDEOS.....	164
8.1.1 GENERAL SOFTWARE BUTTONS .....	118	8.7.3. TECHNICAL SERVICE .....	165
8.1.2 MAIN MENU .....	119	8.8 ALARMS.....	165
<b>8.2 START</b> .....	120	8.8.1 ALARMS HISTORY .....	166
<b>8.3 USERS</b> .....	122	8.8.2 ALARM EXPLANATION.....	167
8.3.1 MANAGEMENT .....	123	8.10 STATISTICS .....	170
8.3.2 SESSIONS .....	123	8.10.1 COSTS.....	170
8.3.3 HISTORY.....	124	8.10.2 STATISTICS.....	172
8.4 WELDING .....	125	<b>8.11 EXPORT STATISTICS</b> ...	176
8.4.1 SYNERGIC.....	126	<b>8.12 BACKUP</b> .....	178
8.4.2 MANUAL MODE.....	132	8.12.1 BACKUP EXPORT .....	179
8.4.3 WELDING SCREEN .....	142	8.12.2 IMPORT BACKUP .....	180
8.4.4 SCREEN FOCAL LENGTH .	144	CHAPTER 9 - WELDING PARAMETERS .....	182
8.4.5 CALIBRATION SCREEN .....	145	9.1 - LC-WELD PRO EQUIPMENT PARAMETERS.....	182
8.5 TASKS .....	146	9.2 CHOICE OF WELDING NOZZLES AND CLEANLINESS.....	185
		CHAPTER 10 - DASHBOARD AND REMOTE CONTROL.....	186
		10.1 <b>ETHERNET</b> .....	187



10.2	ETHERNET: NETWORK CONFIGURATION .....	188	12.1.5	ORDER OF VERIFICATION .....	203
10.3	ETHERNET : PHYSICAL CONNECTION .....	189	12.2	INSPECTIONS OF THE OPTICAL SYSTEM	203
10.4	ETHERNET: CONNECTION VERIFICATION.....	189	12.3	REPLACEMENTS IN THE OPTICAL SYSTEM .....	204
10.5	ETHERNET: TROUBLESHOOTING .....	190	12.3.1	LENS PROTECTOR REPLACEMENT.....	204
10.6	CLOUD DASHBOARD CLIENT	190	12.3.2	LENS REPLACEMENT.....	204
CHAPTER 11	- MAINTENANCE .....	194	12.3.3	NOZZLE REPLACEMENT	205
11.1	TRANSPORT AND STORAGE	194	12.4	ERRORS AND MALFUNCTIONS	205
11.2	CAUTIONS .....	195	12.4.1	EQUIPMENT FAULTS AND MALFUNCTIONS.....	206
11.3	PERIODIC REVIEWS .....	196	12.4.2	WELDING ERRORS AND ANOMALIES.....	209
11.3.1	DAILY REVIEWS.....	196	12.5	SERVICE AND ASSISTANCE.	210
11.3.2	WEEKLY REVIEWS.....	197	12.6	FAILURES.....	210
11.3.3	INSPECTIONS every 10-12 months: REFRIGERATOR WATER AND REFRIGERATOR PUMP FILLING .....	198	12.7	ACCIDENTS .....	211
CHAPTER 12	- DIAGNOSIS AND TROUBLESHOOTING.....	200	CHAPTER 13	- DISMANTLING THE WELDING DEVICE.....	212
12.1	DIAGNOSTIC PREMISES.....	200	13.1	LASER WELDING EQUIPMENT DISMANTLING PROCESS.....	212
12.1.1	RULE FUNDAMENTAL ....	200	CHAPTER 14	- ANNEXES.....	213
12.1.2	SEPARATION BETWEEN EQUIPMENT AND GUN .....	201	ANNEX 1	- LASER SOURCE CHARACTERISTICS.....	213
12.1.3	DO NOT INSIST .....	202	ANNEX 2	- DIRECT, DIFFUSE AND/OR SPECULAR EXPOSURE.....	214
12.1.4	STATE OF THE OPTICS ..	202			



# LEGAL NOTICES

---

## Disclaimer notice

© Lasercomercial Enterprise, SLU, 2023. All rights reserved. No part of this publication may be copied, reproduced, transmitted, stored in a retrieval system, or adapted in any form, in any medium, or by any means, without the prior written permission of LC Lasers, except as permitted by applicable copyright laws. Authorised copies must bear the same copyright and other proprietary notices that appear on the original version.

This manual is subject to change and revision without notice. LC Lasers presents this information as accurate and reliable, however, LC Lasers makes no **warranties or representations, express or implied, in connection with this document, including, without limitation, any implied warranty of merchantability or fitness for a particular use, purpose or application**, either alone or in combination with any other device, equipment, apparatus, material or process.

Users must assume full responsibility for the use of any product. **LC Lasers disclaims any liability for any incidental, consequential, indirect or special damages, including, without limitation, loss of profits, loss of production costs or similar damages, in connection with the furnishing, performance or use of this product.**

Furthermore, LC Lasers assumes no liability for the use of the information contained in this document or for any infringement of patents or other rights of third parties that may result from its use. LC Lasers shall not be liable for errors or omissions in this document or for incidental, consequential, indirect or special damages, including, without limitation, loss of profits, loss of production costs or similar damages, in connection with the furnishing, performance or use of this material.

LC Lasers does not grant any licence, directly or indirectly, under any patents or other intellectual property rights for the use of the information provided in this document.



## CHAPTER 0 - PREFACE

---

This manual must be read and complied with by all persons in the controlled laser area.

All users must review the entire user guide and receive full training by authorized personnel before using the device.

The original language of this manual is Spanish.

### ADDRESSEES

This guide is intended for all owners and operators of the LC-WELD device, as well as all persons working in and around the laser equipment when it is in use. The use of this product should be limited to fully trained industrial, professional, technical or commercial operators who are responsible for welding in industrial and non-industrial installations for commercial purposes.




All users of this product must be trained in laser safety and welding and must follow all instructions and safety warnings in the user guide, the safety labels on the EQUIPMENT and all applicable safety standards, laws and regulations. The following standards and directives have been taken into account in the preparation of this manual and may be consulted for a better understanding of the contents:

- UNE-EN 60825-1:2015 Safety of laser products. Part 1: Equipment classification and requirements.
- UNE-EN 60825-4:2006 Safety of laser products. Part 4: Laser radiation protection systems.
- IEC / TR 60825-14:2004 Safety of Laser products - Part 14: A user's guide
- EN ISO 11553-1:2020 Safety of machinery - Laser processing machines. Laser processing machines. Part 1: General safety requirements.
- UNE-EN 12254:2010 Screens for workstations with lasers. Safety requirements and tests.
- UNE-EN 207:2018 Personal eye protection equipment. Filters and eye protection against laser radiation (laser safety goggles).
- Directive 2006/25/EC of the European Parliament and of the Council of 5 April 2006 on the minimum health and safety requirements regarding the exposure of workers to risks arising from physical agents (artificial optical radiation).
- Royal Decree RD 486/2010, of 23 April, on the protection of the health and safety of workers against risks related to exposure to artificial optical radiation. BOE n° 99 24/04/2010.



- ANSI Z136.9:2013 American National Standard for Safe Use of Lasers in Manufacturing Environments.

### SYMBOLS, WARNINGS AND CATEGORISATIONS USED IN THIS MANUAL

SIGNAGE AND/OR SYMBOL	EXPLANATION
 <b>DANGER</b>	This concept and signage indicates an important hazard to be aware of. Failure to avoid this hazard can result in fatalities, serious injuries.
	This 'WARNING' sign is accompanied by an important explanation for the safety and use of the equipment by the user.
 <b>IMPORTANT</b>	This signage is accompanied by an explanation that should be given special attention as it is highlighted.



# CHAPTER 1 - SUMMARY

---

## 1.1 INTRODUCTION

LC presents the LC-WELD PRO laser welding device, which consists of a fibre laser source and a cooler, a laser gun and a housing with a 10 inch display. This manual contains all necessary information related to the LC-WELD PRO laser welding equipment and has been compiled by LC Lasers. This is a guide compiled with experience and dedication to facilitate the understanding and use of the LC-WELD PRO laser welding equipment by the end user. In order to make continued and lasting use of the equipment, the person(s) who will be operating the LC-WELD PRO laser welding equipment must be familiar with the installation, operation, maintenance and safety systems of the equipment.

The fibre laser source provides up to 1500W maximum output power at an infrared wavelength of 1070 nm.

These operating instructions indicate the safe and proper handling of the machine described in detail in the following chapters. The safety instructions given throughout this manual as well as the general instructions for machine operation must be observed. The accident prevention measures and general safety regulations at the workplace and at the workstations associated with this equipment must also be observed.

The LC-WELD PRO laser device has been tried and tested with special attention to handling and safety. By following the safety regulations, this user guide and applying proper safety practices when operating the laser, LC-WELD PRO is a safe and reliable device.

Before starting any work on the machine, the operator must have read these operating instructions, especially the chapter on basic safety instructions.

Due to its special characteristics, laser light poses different safety risks than light from other sources. Laser radiation can be hazardous to eyes and skin if the irradiance of directly propagated, specularly reflected or even scattered laser radiation is sufficiently high. All laser operators and persons in the vicinity of the laser when in use must be aware of the hazards and wear all recommended personal protective equipment. They should also follow all safety procedures provided and recommended during the use of the equipment.

To ensure safe operation and optimum product performance, follow all instructions in this guide and adhere to all safety and related warnings.



In this manual we will refer to the LC-WELD PRO laser welding machine as "welding machine", "laser machine", "laser welding machine", "LC-WELD PRO", "laser welding equipment" and derivatives of all these options.

### 1.2 REFERENCES

The following standards and directives have been taken into account in the preparation of this manual, which can be consulted for a better understanding of the content:

- UNE-EN 60825-1:2015 Safety of laser products. Part 1: Equipment classification and requirements.
- UNE-EN 60825-4:2006 Safety of laser products. Part 4: Laser radiation protection systems.
- IEC / TR 60825-14:2004 Safety of Laser products - Part 14: A user's guide
- EN ISO 11553-1:2020 Safety of machinery. Laser processing machines. Part 1: General safety requirements.
- UNE-EN 12254:2010 Screens for workstations with lasers. Safety requirements and tests.
- UNE-EN 207:2018 Personal eye protection equipment. Filters and eye protection against laser radiation (laser safety goggles).
- Directive 2006/25/EC of the European Parliament and of the Council of 5 April 2006 on the minimum health and safety requirements regarding the exposure of workers to risks arising from physical agents (artificial optical radiation).
- Royal Decree RD 486/2010, of 23 April, on the protection of the health and safety of workers against risks related to exposure to artificial optical radiation. BOE n° 99 24/04/2010.
- ANSI Z136.9:2013 American National Standard for Safe Use of Lasers in Manufacturing Environments.



## 1.3 TYPES OF USE

### 1.3.1 INTENDED USE

The LC-WELD system has been designed exclusively for use by fully trained industrial, professional, technical or commercial operators who are responsible for welding in industrial and non-industrial installations for commercial purposes. Following the steps and instructions in this manual regarding the use and operation of the laser machine is the only intended use of the laser welding machine. It is only intended for use for its primary function: metal welding work using a laser beam.

No one other than the operator of the laser device should be in the laser controlled area while the equipment is in use. Ideally, the operator should be able to be observed and monitored by personnel outside the controlled laser area by means of cameras. If any person is inside the controlled laser area, he/she must wear appropriate PPE.

The intended use of this product is limited to the processing of metallic materials such as stainless steel, galvanised steel, mild steel, aluminium and copper:

- Metal fabrication and processing.
- Metallurgy applications.
- Bodywork and similar.
- Construction.
- Maintenance and repair of various materials.
- Transport.
- Metal furniture.
- Aerospace.

The following materials are suitable for welding with LC-WELD equipment:

- Stainless steel.
- Aluminium.
- Titanium.
- Galvanised steel.
- Carbon steel.



**To work other materials or special alloys not specified in the above list, please consult LC technical service for your safety.**



### 1.3.2 UNINTENDED USE (FORESEEABLE MISUSE)



**Under no circumstances shall the laser welding machine be used for any purpose other than welding the materials specified and suitable for laser welding.**

As indicated in the previous points, the type of welding to be carried out can be selected and the nozzles of the laser welding gun can be exchanged for this purpose, but not for any other purpose. The user of the laser welding machine is obliged to use the specified PPE for the intended use of the machine.



**Under no circumstances work or be near the laser machine without the appropriate laser safety goggles.**

Under no circumstances may the laser welding machine be used to work on objects that could injure people or animals or damage buildings, valuables or similar objects.

Under no circumstances should the laser gun be pointed at living beings, sensitive materials, structures, constructions, electrical equipment, electrical apparatus, electrical installations, vehicles, automobiles or other objects that are far away from the actual welding work. Such actions may result in serious accidents to persons, animals and valuable installations. LC is exempt from any legal, penal or administrative liability and repercussions resulting from the misuse of the laser welding machine not foreseen in this manual.

Under no circumstances should the filler wire be used for any purpose other than to feed material during welding. It is important not to touch this wire under any circumstances once the machine is running.

Examples of product misuse include the following:

1. Work without following the safety measures specifically explained in this guide.
2. Use of this product by untrained persons in any area.
3. Inadequate protective measures in the workplace. Key protective measures include: (1) Establish a controlled laser zone with restricted entry by interlocking; (2) provide PPE to ALL workers within the controlled laser zone (e.g. laser safety goggles, welding mask and appropriate filters, and clothing and gloves suitable for welding work).
4. Unauthorised modification or conversion of the product by the user or other personnel without the express written authorisation of LC.
5. Intentionally disabling or bypassing product safety systems.



6. Use parts and consumables (other than PPE meeting safety requirements) from other manufacturers (e.g. protective window, nozzle tips, etc.) that do not meet the minimum requirements.
7. Use this product for welding parts containing materials other than those described in section 1.2.1.
8. Remove or render illegible safety labelling and hazard warnings.
9. Holding parts by hand or in any manner in which the welding head points in the direction of parts of a person's body.
10. The use of this product by any person in a residential area.
11. Welding on containers containing flammable, combustible or unknown materials.
12. Use laser equipment for non-welding work.

#### 1.4 CERTIFICATION

LC Lasers certifies that the LC WELD PRO laser welding equipment has been inspected and tested by authorised personnel.


LC WELD PRO has passed the LC quality control prior to shipment of the laser device to the customer. This quality control has been thoroughly checked by:

- Internal components of the equipment.
- Conductivity.
- Testing of equipment and proper functioning.
- External aesthetics of the equipment.
- Spare parts.

Below is the CE marking for this product.



1.4.1 CE MARKING





## 1.5 DECLARATION OF CONFORMITY



## CE Declaration of Conformity

Us **LaserComercial Enterprise**  
C/ Tomas Viladomiu, 61  
08650 - Sallent  
(Barcelona)

CE

We declare, under our sole responsibility, that the installation:

<b>Generic name:</b>	Laser Welding
<b>Brand:</b>	LC LASERS
<b>Model:</b>	LC - WELD PRO
<b>Año de expedición:</b>	2023

classified as a machine, according to directive 2006/42/CE - Machinery Directive, and to which this declaration refers, it adapts to what is reflected in the following standards or regulatory documents, among others:

EN ISO 12100:2012 - Safety of machinery - General principles for design - Risk assessment and risk reduction.  
EN ISO 13853:2020 - Safety of machinery - Laser processing machines - Part 1: Laser safety requirements  
EN ISO 13853:2020 - Safety of machinery - Laser processing machines - Part 2: Laser safety requirements  
EN ISO 12254:2010 - Screens for laser working places - Safety requirements and testing  
EN 60204-1:2007 - Safety of machinery - Electrical equipment of machines - Part 1: General requirements  
EN ISO 14120:2016 - Safety of machinery - Guards - General requirements for the design and construction of fixed and movable guards  
EN ISO 14119:2014 - Safety of machinery - Interlocking devices associated with guards - Principles for design and selection  
EN ISO 13857:2008 - Safety of machinery - Safety distances to prevent hazard zones being reached by upper and lower limbs  
EN ISO 13850:2007 - Safety of machinery - Emergency stop - Principles for design  
EN 60981-2:1993 - ELECTROMAGNETIC COMPATIBILITY. GENERIC EMISSION STANDARDS. PART 2: INDUSTRIAL ENVIRONMENT  
EN ISO 13849-1:2016/AC - Safety of machinery - Safety-related parts of control systems - Part 1: General principles for design  
EN 13849-2:2013 - Safety of machinery - Safety-related parts of control systems - Part 2: Validation  
EN 13792-1:2008 - Ergonomics of the thermal environment - Methods for the assessment of human responses to contact with surfaces - Part 1: Hot surfaces  
EN 1357-1:2004 - Safety of machinery - Integral lighting of machines  
EN 61310-2:1995 - SAFETY OF MACHINERY. INDICATION, MARKING AND ACTUATION. PART 2: REQUIREMENTS FOR MARKING  
EN 61310-3:1995 - Safety of machinery - Indication, marking and actuation -- Part 3: Requirements for the location and operation of actuators.  
EN 60825-1:2015 - Safety of laser products - Part 1: Equipment classification and requirements.  
EN 60825-4:2007 - Safety of laser products -- Part 4: Laser guards (IEC 60825-4:2006).

The described product complies with the following European Directives:

- 2014/35/UE Low Voltage Directive
- 2014/30/UE Electromagnetic Compatibility Directive
- 2006/42/EC Machinery Directive

The company indicated above will be in charge of compiling the Technical Construction File at the motivated request of the competent national authorities, as indicated in Annex II 7.1 section II of the aforementioned Directive 2006/42/CE.

  
 Sallent,  
 March 20, 2023  
(Place and date of expedition)

  
**LaserComercial Enterprise NIF-867588130**  
 C/ Tomas Viladomiu 61, 08650 Sallent (Barcelona)  
 Ferran Sardans  
 Technical director  
(Name and signature)



# CHAPTER 2 - SAFETY INFORMATION

---

To ensure safe operation and optimum performance of the laser welding equipment and associated peripherals, follow all warnings in the product user guide.

Safety precautions must be observed during all phases of operation, maintenance and service.

It is essential to read the entire manual before using the LC-WELD PRO laser welding unit. Keep the manual with the machine; if the equipment is sold or passed on to third parties, provide the user manual.

Before installation and use, read and follow the instructions in these operating instructions. Damage to persons and/or property can result if the following instructions are not followed.

Operation of the system is only permitted with equipment and spare parts supplied or included in the manufacturer's parts, any kind of deliberate modification by the user without consulting the manufacturer may pose a risk to the health of persons using the machine.

The equipment must be handled by personnel trained and authorised by the user company.

Users of this equipment should follow these recommendations and apply proper laser safety practices at all times and in all work involving this equipment.

All set-up and maintenance operations must only be carried out by qualified personnel.

## 2.1 SYMBOLS AND WARNINGS IN THIS MANUAL

In CHAPTER 0, the symbols and words used in this manual to indicate importance of concepts and/or explanations are specified. They are designed to draw your attention to any hazards or important information. These standardised signal words will identify important hazards and warnings.

Safety warning messages shall appear in this user guide whenever hazards or risk situations may occur. They shall alert the user to direct and indirect hazards related to the use of the product and associated peripherals, and shall contain general rules of behaviour.



For your safety, it is important to read and fully understand the meaning of these signal words and symbols. Follow all safety warnings and proceed with caution to avoid accidents, personal injury and property damage.

## 2.2 CLASSIFICATION OF THE LASER PRODUCT

The harmonised standard UNE-EN 60825-1:2015 establishes different classes of laser products according to their ability to cause damage to biological tissues, especially the eye and the skin. These classes are established from Class 1 to Class 4:

- Class 1 is the only class that is safe under all conditions (in use and in case of failure), because access to laser radiation exceeding the radiation exposure limit values is not possible.
- Class 4 is the highest class, and in case of exposure to laser radiation always involves damage to the eye as well as to the skin and both direct and reflected or diffuse exposure. In addition, Class 4 presents a fire hazard due to ignition of flammable materials.

Section 5.2 of UNE-EN 60825-1:2015 states that measurement of laser radiation levels may be necessary to classify a laser product. Measurements are unnecessary when the physical characteristics and limitations of the laser source clearly place the laser product or installation in a particular class.

In this case, the machine integrates a high-power Class 4 laser product. Furthermore, the aim is to use the laser beam of the generator for metal welding. During the intended operation the laser beam must therefore be accessible:

**The LC WELD is a Class 4 laser product.**



### **DANGER**

#### **INVISIBLE CLASS 4 LASER RADIATION**

**Severe and permanent eye damage from reflected or scattered radiation.**

Cautions:

- If the system can be active (key switch on), it is necessary to wear laser goggles inside the laser area.
- After stopping work and before leaving the controlled laser area, the operator of the laser device must: (1) turn the key switch to the OFF position and (2) remove the key and store it in a safe place. This prevents unauthorised and untrained personnel from using the laser device.



The LC WELD PRO has a red pointer on the head to help focus the beam. This red pointer is a class 3R laser.

All lasers should be classified according to their power or output energy and the wavelength of the laser. This device is classified as a high power laser instrument with the laser classification for each laser type specified below.

	Main fibre laser (used for welding)	Laser pointer (aids positioning prior to work)
Laser classification	Class 4	Class 3R
Wavelength	1070 nm	600 to 700nm
Emitted laser radiation	Invisible (Infrared)	Visible (Red)
Average power	1500w	20mW
Peak power	1500W	20mW



**DANGER**

**INVISIBLE CLASS 4 LASER RADIATION - EYE AND SKIN HAZARDS**

**This level of light can cause serious damage to eyes and skin.**

**Precautions:**



- Due to these risks, a qualified laser safety officer must be present to ensure a safe working environment.
- If the system may be switched on, it is necessary to wear laser safety goggles within the controlled laser area.
- While the laser device is in operation, appropriate safeguards, guards and laser safety procedures shall be in place.
- The laser operator should wear all recommended PPE, including: (1) specified laser goggles and (2) welding helmet with appropriate filters.
- Additional PPE intended to protect the skin includes gloves, protective clothing and aprons resistant to fire, heat and electric arc.

**DANGER****CLASS 3R VISIBLE LASER RADIATION.**

- **Avoid exposing the eyes to this laser.**
- **Avoid looking directly into the laser beam or with optical instruments.**

## 2.2.1 CLASSIFICATION OF LASER PRODUCTS

CLASS	DANGER
1	The device is safe to use, including direct viewing over a long period of time, even when using optical observation devices.
1M	Non-laser beam, including direct vision for a long time (naked eye); seeing through an optical instrument can be dangerous (letter "M" stands for "magnifying optical viewing instruments")
1C*	Without ocular risk, the ELV for skin (or other non-ocular tissues) may be exceeded in case of interactional exposure (the letter "C" is derived from the term "contact", deduced from the mode of operation).
2	Secure ** for momentary exposures (0.25 s), valid only for the wavelength range 400-00 nm.
2M	Safe ** for a short period of time; possible injury if viewed with an optical instrument.
3R	Laser exceeding the maximum permissible exposure (MPE) for direct beam viewing (the letter "R" is derived from the term "reduced requirements")
3B	Hazardous if exposed to direct beam, regardless of exposure duration. Diffuse reflections are normally safe, but the EMP may be exceeded when using an optical viewing instrument. In addition, there is a risk of fire from the direct beam (the letter "B" is historical as it comes from the first classification).
4	Dangerous direct vision, dangerous skin exposure, dangerous diffuse reflection and fire hazard, also due to diffuse reflection.

\* This class refers to direct applications with intentional radiation exposure to the skin or internal body tissues in medical, diagnostic, therapeutic or cosmetic procedures. The emitted laser radiation may be Class 3R, 3B or 4, but the technical characteristics of the device prevent ocular exposure (the beam may be Class 3R or 4, but the technical characteristics of the device prevent ocular exposure (the beam may be only if the applicator is in contact with the skin, or in close proximity to the skin or internal body tissues), thus reducing the hazard class to Class 1. By extension, the requirements of this class can be applied to laser equipment developed, for example, in biomedical research at the CNRS.




\*\* The concept of "safe" is linked to the absence of injury. However, these rays can cause intense and painful glare.

### 2.2.1 LASER RADIATION AND SAFETY RISKS

When working with laser welding equipment, both diffuse and specular laser emissions can be produced by diffuse reflection. By testing different materials, it has been determined which types of reflections are produced in each case (see ANNEX 2),


To carry out the measurements of the diffuse laser radiation emissions in the different materials that can be welded with the LC WELD machine, the power meter has been positioned at a distance of ~150 mm from the welding point and the angle has been varied to maximise the laser power detected. Below is a table with the power values obtained for each material. It can be noted, especially in the case of aluminium which was analysed for two incident laser power values, that the diffuse emission is more important for a lower incident power. This is due to the fact that the laser induces a drastic change of the irradiated area which affects its ability to reflect the laser. Diffuse laser emission values as a function of the welded material:

Material	Incident power	Diffuse power
Aluminium	75%=1400W	50mW
Aluminium	35%=700W	200mW
Iron	35%=700W	40mW
Stainless Steel	35%=700W	20-40mW



*Diffuse reflection of a laser beam*

As far as specular reflection is concerned, it depends in particular on the reflectivity of the welded material. When the laser is incident on a material, it generates a beam directed in the opposite direction and at the same angle as the incident beam with respect to the plane of the welded part.



*Specular reflection*

There is a big difference in the behaviour of the materials:

- Aluminium has a higher reflectivity, especially for an incident laser power of 1 kW. Comparing the incident laser power and the reflected part results in a reflectance factor of 5%. The reflected laser power decreases with increasing incident power on the material. As in the case of diffuse reflection, this behaviour is due to the fact that increasing the laser power on the material induces changes in the impacted area which can influence the reflected part of the power.
- The same behaviour is observed with iron, although in this case, the reflectance factor is much lower (~ 2%),
- Finally, stainless steel has a constant reflectance (~ 2%) independent of the incident laser power.

#### 2.2.1.1 SECONDARY RADIATION RISK

Welders who are exposed to invisible UV light without proper protection can suffer permanent eye damage. Even brief exposure to invisible UV light during welding can cause blurred vision, burning, tearing, pain and eye irritation (feeling of sand in the eye).



#### **DANGER**

##### **Visible and invisible light radiation produced during welding**

The interaction between high-power laser beams and the target materials being welded can create plasmas that produce UV and "blue light" emissions that can cause conjunctivitis, photochemical damage to the retina and sunburn-like reactions on the skin.

## 2.3 SECURITY INDICATORS



The laser resonator has an "emission on" status light located on the front panel of the unit. When this status light comes on (during welding or cleaning), it means that the laser emission has been initiated by the operator controls on the manual welding head.

**DANGER****DANGER WHEN THE POWER SUPPLY IS SWITCHED ON!**

The laser device is in a hazardous state and all precautions must be taken as if the laser were ready to emit.

All necessary precautions should be taken.

The laser welding equipment has indicators to announce the laser emission. On the welding screen under the WORK option, a green indicator is visible when the laser is in emission.

Outside the controlled laser area, light signals can be reproduced to indicate when the equipment is switched on for work, when it is switched off and when the laser is in emission, with a traffic-light type light.

## 2.4 SAFETY GOGGLES AND MASK

### 2.4.1 SAFETY GLASSES

**Laser safety goggles**, as PPE, must be CE-certified in accordance with the European standard *EN207: Personal eye protection equipment. Filters and eye protectors against laser radiation* must also meet the following requirements:

- Provide a level of protection appropriate to the characteristics of the laser used (wavelength, power, mode of operation, etc.),

According to the characteristics of the source integrated in the welding equipment and the measurements studied, **the minimum protection level required is DLB6 at the wavelength of 1060-1070 nm.**

The selection of appropriate **laser safety glasses** requires the end user to accurately identify the range of wavelengths emitted by this product and the Predictable Exposure Limits (PEL). All laser safety glasses have energy-absorbing filters. Laser safety glasses are usually thicker.

The protection level of the goggles must ensure that, in the worst case, what the filter can transmit must be less than the EMP value. The goggles must be suitable for the wavelength of the laser we are working with.

Review the product safety labelling and verify that the personal protective equipment (i.e. goggles, enclosures, viewing windows or peepholes, etc.) being used is suitable for the output power and wavelength ranges. Decisions regarding safety glasses should also take into account possible secondary radiation risks due to radiation from the welding process and UV radiation.

## ORIGINAL USER'S MANUAL



Protective eyewear is based on the use of filters that can transmit or attenuate a certain wavelength of light, partially or completely. The optical density (OD) of a filter is a measure of this attenuation of the energy passing through the filter.

The higher the OD value, the higher the attenuation and the higher the protection value (more light of a certain wavelength is filtered out). In addition, the protective goggles must offer sufficient resistance against LEP (i.e. they must withstand a direct laser impact for at least 5 seconds according to EN 207).

Below is an example photo of the glasses delivered with the equipment:



Safety Goggles STARLIGHT X2, Filter: 0206

The CE of the glasses delivered with the LC-WELD PRO equipment:



## EU-Konformitätserklärung



Der Hersteller

PROTECT-Laserschutz GmbH  
Mühlhofer Hauptstraße 7  
90453 Nürnberg

erklärt in seiner alleinigen Verantwortung hiermit, dass die nachstehenden Produkte

Artikel-Nr.	Filter	Gestell	Gestellfarbe
000-K0206-GLAD-20	0206	GLADIATOR	silber
000-K0206-OVSP-02	0206	OVERSPEC II	weiß
000-K0206-OVSP-20	0206	OVERSPEC II	silber
000-K0206-RETR-21	0206	RETRO	titan
000-K0206-SPEC-02	0206	SPECTOR	weiß
000-K0206-SPEC-20	0206	SPECTOR	silber
000-K0206-STAR-X-01	0206	STARLIGHT-EXTRA	schwarz

im Einklang mit der Verordnung (EU) 2016/425 des Europäischen Parlaments über persönliche Schutzausrüstungen und zur Aufhebung der Richtlinie 89/686/EWG und entsprechen der nationalen Norm, mit der die harmonisierte Norm EN 207: 20 09 + AC: 2011 + EN 207:2017 umgesetzt wird, sowie der Richtlinie über die allgemeine Produktsicherheit: 2001/95/EG stehen.

Die notifizierte Stelle DIN CERTCO Gesellschaft für Konformitätsbewertung mbH, Notified Body 0196, hat die EU-Baumusterprüfungen durchgeführt und die EU-Baumusterprüfbescheinigungen C5083PF/R0 (Tragekörper OVERSPEC II); C5822PF/R0 (Tragekörper SPECTOR)) ausgestellt.

Die notifizierte Stelle ECS GmbH – European Certification Service, Notified Body 1883, hat die EU-Baumusterprüfungen durchgeführt und die EU-Baumusterprüfbescheinigungen (C1548.5PF (Filter 0206)); (C863.5PF (Tragekörper GLADIATOR)); (C7002.5PF (Tragekörper RETRO)); (C2334.1PF (Tragekörper STARLIGHT-Extra)); (C1168.4PF (Tragekörper UNIVERSAL unkaschiert)) ausgestellt.

Petra Fröbel  
Geschäftsleitung PROTECT-Laserschutz GmbH  
Nürnberg, 05.12.2019

Rüdiger Fröbel  
Geschäftsleitung PROTECT-Laserschutz GmbH  
Nürnberg, 05.12.2019

**DANGER****EYE HAZARD DURING LASER WELDING WORK**

Risk of permanent eye damage and impairment of vision due to reflected and scattered invisible class 4 laser beam reflections. Risk of eye damage as a result of exposure to UV light, heat and sparks produced during processing of the material.

**Cautions:**

- Operators must wear the specified laser safety goggles in combination with the specified welding mask when the device is in operation.
- Laser goggles alone do not provide sufficient eye protection when using laser welding equipment, it is necessary to use the welding mask to adequately protect from UV rays.

**LC provides a pair of laser safety goggles with the LC WELD equipment.**

- All persons present in the controlled laser area, whether they are working with the machine or are present as observers, must wear appropriate laser safety goggles.
- It is recommended to minimise the number of people present in the controlled laser area.
- Before entering the controlled laser area, all persons must properly don PPE.
- Do not use with laser safety glasses other than those indicated in this guide.

**DANGER****INCORRECT OR DAMAGED LASER SAFETY GOGGLES**

Severe and permanent eye damage and impaired vision may occur.

**Precautions:**

- Before using laser safety goggles, all personnel should check the labelling on the goggles and confirm that they comply with the OD or LB rating (depending on the user's country), identified earlier in this section.
- **The goggles must protect for the wavelength used in the laser equipment.**
- Before use, laser safety goggles should be inspected for cracks, discolouration, damage to the coating, marks or cracks.
- **Under no circumstances should damaged glasses be used.**

**Also check the mechanical integrity of the mount.**



- 
- **If the condition of the laser safety goggles is suspect, that pair should be discarded and replaced.**
- 

#### 2.4.2 WELDING MASK

A suitable welding mask must be worn to provide adequate protection from the UV light produced during the welding process.

**Ultraviolet light protection screen**, with a grade 3 according to regulations:

- *EN 166: Personal eye protection.*
- *EN 169 Personal eye protection - Filters for welding and related techniques - Permeation properties and recommended use.*

It is **MANDATORY to wear** a welding or oxy-fuel welding type protective shield.

### 2.5 PPE CLOTHING

Refer to section 2.7.6 for information related to skin hazards. The skin of unprotected personnel may be exposed to extremely hazardous levels of laser radiation, UV radiation and blue light related to the welding process itself, as well as to burns due to hot parts.

To protect against skin hazards, the operator of the hand-held laser device must wear flame-, heat-, and arc-resistant gloves, clothing, hats, and aprons while the device is in operation.

In addition to eye protection, there is a variety of Personal Protective Equipment (PPE) for the operator of the LC-WELD PRO laser welding equipment:

**Skin protection** (clothing): one upper piece of special welding flame-retardant cotton.

Class 1 protective clothing is for protection against less hazardous welding techniques and situations, which produce lower levels of molten metal splashes and radiant heat.

- *UNE-EN ISO 13668:2013 Protective clothing. General requirements.*
- *UNE-EN ISO 11611:2015: "Protective clothing used during welding and allied processes".*

These garments are designed to protect the wearer's body, including hoods, aprons, sleeves, and gaiters and excluding the hands. This standard does not cover requirements for foot, hand, face and eye protectors. For adequate protection against the risks to



which welders may be exposed, additional PPE covered by other standards should be used to protect the head, face, hands and feet.

If a suit is required, these will consist of:

- A single garment (gown or overalls).
- A two-piece suit, consisting of jacket and trousers. The jacket must be of sufficient length to overlap the top of the trousers.

**Flame retardant gloves:** It is important to use welding gloves when working with the laser welding machine. It should be a type B welding glove, recommended for TIG. Characteristics: Category II PPE, according to Standards:

- o EN 388:2016 (gloves for protection against mechanical hazards)
- o EN 420:2003+A1:2009 (General Requirements for protective gloves)
- o EN 407:2004 (Protective gloves against thermal hazards)
- o EN 12477:2001+A1:2005 (Protective gloves for welders)



IMPORTANT

**The gloves have good resistance to the heat generated by welding activities, with a comfortable inner lining for the wearer. In addition, they should be comfortable and flexible to work with ease.**

## 2.6 LASER TECHNICAL DATA AND SAFETY RISKS

Knowing the details of the laser provides relevant information to make a good choice of PPE and to understand the risk factors related to this equipment. The Laser Safety Officer (LSO) of the workplace has to identify the maximum permissible exposure and hazard distances to determine which PPE and safety procedures are necessary.

Technical data of the laser resonator:

<b>Model</b>	<b>L1500W-V2.06</b>
<b>Product reference</b>	L1500W-V2.06-50µm
<b>Laser Power</b>	1500W
<b>Laser Type</b>	CW HPP
<b>Consumption</b>	<3800W
<b>Voltage</b>	220-240VAC



<b>Wavelength</b>	1070nm ±10
<b>Power range</b>	1-100%
<b>Frequency range</b>	<50 kHz
<b>Laser Efficiency</b>	42%
<b>Start time</b>	10 µs
<b>Type of connection</b>	QBH
<b>Fibre length</b>	10m
<b>Need for refrigeration</b>	2,2kW Q
<b>Weight</b>	20kg
<b>Dimensions</b>	435x339x100mm
<b>Laser Class</b>	4 (IEC 60825-1)
<b>Leading-edge power</b>	1mW

The European Directive 2006/25/EC on the minimum health and safety requirements regarding the exposure of workers to risks arising from physical agents (artificial optical radiation), and its transposition into Spanish law by Royal Decree 486/2010 (article 6), in the assessment of the risks of exposure to laser radiation, the exposure levels of workers must be compared with the exposure limit values. The methodology applied in the assessment, measurement and/or calculations shall be in accordance with the International Electrotechnical Commission (IEC) standards for laser radiation, i.e. the UNE-EN 60825 series of standards.


#### Laser safety terms and definitions

- **Maximum Permissible Exposure:** Maximum Permissible Exposure (MPE) is the level of laser radiation to which people can be exposed under normal circumstances without suffering adverse effects. The MPE is the irradiance or radiant exposure that can be incident on the eye (or skin) without causing injury or adverse biological changes to the eye or skin. The MPE is the highest power (in W/cm<sup>2</sup>) or energy density (in J/cm<sup>2</sup>) of a light source that is considered safe. The MPE varies depending on the wavelength of the laser, the energy involved and the duration of exposure. The MPE is a necessary parameter for determining the appropriate optical density (OD) and nominal danger zone (NDZ). Note that there is a different MPE value for eyes and skin. In the EU: See Directive 2006/25/EC and TROS Laser radiation.
- **Nominal eye risk distance (DNRO):** The DNRO is the distance from the laser aperture (or equipment reference point) to the position at which the irradiance (E) is equal to the EMP. DNRO is the distance along the axis of the unobstructed



beam of a laser to the human eye beyond which the irradiance or radiant exposure during normal operation is not expected to exceed the MPE. At distances greater than the DNRO, the laser beam intensity is not hazardous in the case of unshielded vision or exposure. The calculation of the DNRO depends on the characteristics of the laser beam, such as output power, beam diameter and beam divergence. The DNRO is usually much larger than the largest dimension of its working area.

- **Nominal Hazard Distance (NHA):** The NHA describes the space within which the level of direct, reflected or scattered radiation during operation exceeds the applicable MPE. Exposure levels beyond the NPZ boundary are below the applicable MPE. If you are within the NPZ, you are at risk of exposure above the MPE and should therefore wear PPE.
- **Optical density:** OD is a measure of the attenuation of laser radiation through a material. This value is mainly used in the specifications of laser safety glasses and viewing windows. The higher the OD, the greater the attenuation of laser radiation. The OD is used in the determination of the appropriate laser eye protection.





### 2.6.1 MAXIMUM PERMISSIBLE EXPOSURE (MPE)

The value of the EMP to be considered for the source incorporated in the LC WELD welding equipment is that established in the UNE-EN 60825-1 standard for a point source with laser emission in continuous mode and in the infrared band (1050 - 1400 nm). EMP eye = 50 W/m<sup>2</sup> for the eyes and EMP skin = 10 kW/m<sup>2</sup> for the skin.

The following table presents a comparison of the accessible emission of the laser source at a distance of 450 mm from the exit of the welding torch with the EMP values (eye and skin). It is worth mentioning the following comparison of the accessible emission with the EMP values:

Parameter and symbol	Laser under analysis
<b>Average power P<sub>0</sub></b>	2 000 W
<b>Wavelength λ</b>	1060 - 1070 nm
<b>Accessible emission @ 450 mm, E</b>	9.71 MW/ m <sup>2</sup>
<b>EMP for the eyes, EMP<sub>ocular</sub></b>	50 W/ m <sup>2</sup>
<b>Excessive EMP for the eyes</b>	194 200
<b>EMP for skin, EMP<sub>skin</sub></b>	10 kW/ m <sup>2</sup>
<b>Excessive EMP for the skin</b>	971

### 2.6.2 NOMINAL EYE RISK DISTANCE (DNRO)

The parameter that best illustrates the risk of exposure to laser radiation is the nominal eye risk distance (DNRO).

The three types of laser radiation exposures that can be anticipated or given are direct exposure or indirect exposures to diffuse reflection or specular reflection.

The values of the DNROs are 281, 63 and 3.5 m for direct exposure, specular reflection and diffuse reflection, respectively. These distances indicate the danger zones for eye damage in case of exposure to the laser incorporated in the LC WELD machine, hence the need to implement adequate (collective and individual) protection systems. The results of the DNROs analysis applied to the LC WELD laser welding machine are summarised in the table below:

Parameter and symbol	Value
<b>Average power, P<sub>0</sub></b>	2 000 W
<b>EMP ocular</b>	50 W/ m <sup>2</sup>
<b>Lens focal length, f</b>	150 mm



<b>Beam diameter over lens, d63</b>	3.8 mm
<b>Direct exposure, DNROdir</b>	281 m
<b>Specular exposure, DNROesp</b>	63 m
<b>Diffuse exposure, DNROdif</b>	3,5 m

These values were analysed with a 2kW laser source and the reference point is the focal point, i.e. the tip of the welding torch.



From this analysis, we conclude that the use of appropriate PPE (explained in point 4.7) is essential for the safety of the user as well as the working environment, since in case of direct exposure to the laser without appropriate PPE, serious damage can occur.

### 2.6.3 REFLECTED BEAM HAZARD






- **Take care to avoid/minimise specular reflections. The primary laser of this product emits invisible laser radiation, corresponding to laser class 4, at or around a wavelength of 1060-1070 nm (infrared).**
- In addition, the laser guide (red pointer) of this product emits visible laser radiation, corresponding to laser class 3R.

As explained in section 2.2.1, multiple laser beams at different angles can be produced when working with laser equipment. These are specular reflections.

Laser welding systems can create specular reflections due to the interaction of the laser beam and the parts being processed. Although these secondary beams may be less powerful than the total power emitted by the laser, the intensity can be great enough to cause damage to the eyes and skin, as well as to the materials surrounding the laser.

The angle of the welding gun must be taken into account to avoid dangerous reflections.



**DANGER**

Laser beams can reflect off multiple surfaces. Be aware of the possibility of multiple reflections during welding. **The gun must always be in the correct position to avoid dangerous reflections.**

#### 2.6.4 LIGHT RADIATION AND RADIATION PROTECTION

The performance requirement of a laser radiation protection system, according to UNE-EN 60825-4, is to ensure that in case of exposure of its front surface in accordance with the predictable exposure limit (PEL), the laser radiation accessible on its rear side does not exceed the Class 1 accessible emission limit at any time during the maintenance control interval.

The LEP value must be assessed by considering the worst-case or reasonably foreseeable combination of all parameters of incidence of the laser beam on the protection. This is normally given by a direct incidence of the laser beam on the protection.

The control or maintenance inspection intervals specified according to UNE-EN 60825-4 are the durations mentioned above, which must be adapted to the use of each laser processing system or machine. For example, for a laser system under continuous observation, a laser radiation protection system endurance duration of 10 s is required.

In the case of the LC WELD hand-held laser welding machine, a direct impact on a safety shield is impossible during its intended operation. Such a situation can only occur in the case of gross negligence, where the operator voluntarily directs the torch towards the shielding. However, the materials chosen as the basis for possible protective screens were irradiated in this configuration.

In a collaboration between LC and PROCARELIGHT SL (an expert company in laser safety), several materials were validated according to the UNE-EN 60825-4 standard for use in the manufacture of covers or screens for protection against laser radiation, i.e. the risk analyses and tests required by this harmonised standard on protection systems were carried out.

As the welding process with the LC WELD machine is only carried out under continuous observation, all materials that exceed a direct laser exposure duration of 10s are valid as protective systems. All samples were irradiated until perforation. The materials tested and the duration withstood by each of them are:

- A 2 mm thick aluminium sheet showed a direct exposure duration of more than 2 min.
- A 1.5 mm thick aluminium sheet withstood direct laser exposure for 50 seconds.
- A steel plate (2 mm thick) withstood direct exposure to laser radiation for more than 10 s, but less than 20 s.



- The same behaviour as the steel sample was observed with a 2 mm thick iron plate.

#### 2.6.4.1 RISK ASSESSMENT FOR LASER PRODUCTS CLASS 4

Class 4 laser products must not be used without first carrying out a risk assessment to identify hazardous situations and assess the foreseeable level of exposure to the laser, as referred to in paragraph 4 of *Directive 2006/25/EC on the minimum health and safety requirements regarding the exposure of workers to risks arising from physical agents (artificial optical radiation)*. It shall also serve as a basis for determining the control and protective measures necessary to ensure safe operation.

The following factors will be taken into account in this assessment:

- Characteristics of the area(s) intended for laser welding.
- Process control.
- Manual operations.
- Clamping and positioning of parts.
- Beam output considerations: structural integrity of components, means of maintaining the condition of optical components, means of maintaining beam alignment, etc.
- Location and position of workers during laser welding.
- Environmental factors.
- Geometry, composition and surface finish of the part or parts to be worked on.



**As explained above, when working with highly reflective materials, the bounce light can conserve quite a lot of energy in the first part of the bounce, it is recommended to take extreme precautions with the hands to avoid skin burns.**

#### 2.6.5 ULTRAVIOLET LIGHT

As this is welding work, there are some risks similar to traditional welding to be aware of. Although much less than with traditional welding systems, during laser welding, intense visible radiation or ultraviolet (UV) light can be produced. Ultraviolet (UV) light, which is invisible, can damage the skin and eyes. For this reason, appropriate face protection (welding mask, specified in the section on PPE) must be worn.



## 2.7 ANALYSIS OF RISKS AND RISK FACTORS

### 2.7.5 EYE HAZARD

NEVER look directly into a laser opening (such as the output fibre, or the welding head) while the unit is on. The operator must turn the unit off and disconnect power to perform any maintenance action involving the fibre cable or fibre output head.

It is mandatory to always wear laser safety goggles specific to the laser equipment used.

Ensure that all personal protective equipment (PPE) is suitable for the output power and wavelength range listed on the laser safety labels affixed to the product.



**-NEVER look directly into the output port when supplying power to the laser.**

**-Avoid placing the laser and all optical components at eye level.**

**-Avoid using the laser in a dark environment.**

**-Use closed enclosures for the laser beam.**

**-Always turn the key to the "OFF" position when working with the output (e.g. when mounting the laser head on a device, etc.).**

**As an additional precaution, disconnect the power supply to the equipment.**



**Highly reflective metals, such as aluminium, may cause some of the beam energy to be reflected at the welding site and require additional precautions.**

- **Specular reflections can also pose a hazard to the operator** if any part of the beam is reflected from several surfaces.
- **Take precautions to understand the expected specular reflection cone** for each processed part and do not attempt to view the part or place any part of the body within the expected specular reflection cone.

Operators and observers must also be aware of reflections at all times. Further reflections are likely to occur if the laser parameters are not adjusted correctly to achieve fusion of the target part.



## 2.7.6 SKIN HAZARD



### Welding and cleaning process - UV radiation

Skin damage due to exposure to UV radiation produced during the welding (or cleaning) process.

#### Cautions:



- It is compulsory to wear the appropriate PPE while using the equipment.
- The required PPE includes: (1) welding helmet over specified laser safety goggles, (2) flame, heat and arc resistant gloves, (3) sturdy clothing suitable for welding.



### **DANGER**



### Welding process - High temperature

Severe skin burn from contact with a hot surface or from exposure to thermal radiation or hot particles.

#### Cautions:



- Appropriate PPE must be worn during welding operations.
- The required PPE includes: (1) welding helmet over specified laser safety goggles, (2) flame, heat and arc resistant gloves, (3) sturdy clothing suitable for welding.
- Avoid touching the welded part or the nozzle tip of the welding head or the tube with unprotected skin immediately and shortly after laser emission.

Exposure to ultraviolet light can cause skin burns (similar to sunburn) and this can increase the user's risk of skin cancer and accelerate skin ageing.

Depending on the intensity of the infrared light, skin lesions may include thermal burns or excessive skin dryness.



Sparks generated during the welding process can also cause burns.

The laser welding process itself transfers a significant amount of energy and heat onto a material. The parts worked on with the laser equipment may be at high temperature even after the work is completed. Likewise, the nozzle, tube and other parts of the laser gun may be hot during use. Be sure to use the appropriate PPE to protect yourself from burns, such as gloves and appropriate clothing.

It is essential to take precautions to avoid skin damage by wearing clothing suitable for work with laser welding equipment, resistant to fire, heat and electric arc. Clothing must be sufficiently resistant to UV radiation.

### 2.7.8 IN-PROCESS HAZARDS

During the laser welding process, various hazards can occur when working with materials of different characteristics. The laser reacts with the material and can generate vapours, fumes, sparks and various particles. These fumes and particles can be a hazard.



#### **DANGER**

#### **Welding process - Fumes and Particulates**

**Damage to body tissues or organs from exposure to fumes and other by-products generated by the welding process.**

#### **Cautions:**

- The user must take measurements according to the material of the workpiece to be welded.
- During welding, keep your head away from the fumes.
- Always keep in an area with adequate ventilation.
- Hazardous and toxic fumes, vapours and particles must be captured and expelled from the work area by means of an extraction system.
- Ensure that the work surface is well ventilated. The opening of the collection unit should be located as close as possible to the process area.
- PPE (respiratory protection) must be worn if the released hazardous substances cannot be extracted close to the process.



**It is advisable to use a fume and vapour extraction system, suitably located close to the welding area, and should exhaust fumes and vapours out of the work area, ensuring a renewal of clean air.**

If the material to be welded generates a lot of fumes due to its composition (galvanised, aluminised or other treatments), it will be compulsory to incorporate a fume and vapour extraction



---

system or, failing that, respiratory protection equipment with air supply.

---

Fumes generated by the welding process may contain components that are harmful to health. It can adversely affect the lungs, heart and central nervous system.

When the laser interacts with target materials such as plastics, metals or composites, the target material may start to vapourise. Often the fumes and mists are not visible, but they are highly toxic and pose a serious health hazard.

UV emissions during the welding process can react with oxygen and nitrogen in the air to form ozone and nitrogen oxides which, in high concentrations, can be lethal.

---

**DANGER****Risk of asphyxiation in poorly ventilated confined spaces**

**Gases used in the welding process itself, such as argon or nitrogen, can accumulate in the environment.**

**Dangerous concentrations of toxic fumes and gases can build up very quickly and cause unconsciousness and death by asphyxiation.**

**Cautions:**

- Carry out routine air monitoring to determine the levels of hazardous fumes in the area where the laser equipment is operated.
  - In confined spaces and other circumstances, the use of a respirator may also be necessary.
- 

It is recommended that a risk assessment for welding dust, particles and fumes be carried out to ensure the proper disposal of the residues caused by the welding process itself.

The owner of the laser, before starting to work with the laser, must:

- Be familiar with the material to be worked on and its possible reactions with the laser beam.
- Read and follow the safety data and warning labels on all materials and accessories used in the work.
- Employ appropriate measures to prevent and control the risk; such measures will normally require the removal of fumes from the process area to the outside and appropriate purification before exhaust gases are released back into the atmosphere away from personnel;
- Inform, instruct and train operators on the risks and precautions to be taken;
- Where necessary, control the exposure of operators and carry out an appropriate form of health surveillance in compliance with local regulations.

During the welding process itself, projections of micro-particles can occur which can cause burns.



It is recommended to use cotton safety clothing that completely covers the operator's arms and torso to adequately protect the skin. The welder must wear protective goggles and face shields. As well as special welding gloves (TIG type gloves are recommended), which in addition to protecting against radiation, also protect against micro-projections from the welding process.

### 2.7.8.1 FIRE HAZARD

There are two types of fire extinguishers that must be available near the laser area.

1. The ABC dry chemical extinguisher is a good general purpose extinguisher that should be readily available. This type of extinguisher is suitable for:

- Fires of solid materials, generally of an organic nature - the combustion of which results in the formation of embers - such as wood, paper and textiles.

- Fires due to flammable liquids.

- Electrical fires.

2. A Class D dry powder extinguisher shall also be provided. This type of extinguisher is suitable for combustible metal fires.

Consult national legislation and legal obligations at work for specific characteristics of fire extinguishers.



#### **DANGER**

**The laser can ignite solvents, gases and combustible materials.**

**Laser light can ignite volatile substances such as alcohol, gasoline, ether and other flammable solvents and gases (e.g. MAPP gas), causing a fire or explosion.**

Precautions:

**Exposure to solvents and other flammable materials and gases must be avoided and taken into account when installing and using this device.**

- **Do not weld combustible and flammable materials (e.g. magnesium).**
- Whenever possible, combustible and flammable materials should be completely removed from the laser area.

**DANGER**

**Welding and laser cleaning can cause a fire or explosion!**

**The heat and sparks produced during operation of the system can cause the system to cause a fire or explosion.**

**Precautions:**

- Laser welding should only be carried out if the area is free of combustible materials.
- Never weld on containers containing flammable or combustible material.
- If you do not know the contents of a container, you should assume that it is flammable or combustible.
- Fire extinguishers should be close by and accessible to personnel, who should be trained in their use.

---

### 2.7.9 SAFETY OF GAS CYLINDERS

The LC-WELD laser welding equipment requires gas for a good weld finish, as in other fusion metal joining techniques and methods.

The placement and arrangement of gas cylinders must be taken into account.

Cylinders can explode or be damaged if placed incorrectly or close to the welding area, which can cause accidents and material damage. Falling or overturning of the cylinder can also cause damage and accidents.

**Precautions:**

- Cylinders must be positioned so that they are protected and placed in such a way that they cannot be knocked over.
- Cylinders must be kept away from sparks, heat sources or possible flames, as well as from the deflection of the laser beam.
- The cylinder must be stored in an upright position and secured to a fixed support.

It is necessary to have operational regulators in good condition that are suitable for the gas and pressure required. All hoses and couplings must also be suitable for the application and maintained in good working order.

---

### 2.7.10 RISK ANALYSIS OF LC-WELD EQUIPMENT

On the following pages, the risk assessment relating to the machine is attached, taking into account the UNE-EN ISO 11553-1 standard. The legend used in the risk assessment



in the different phases of the life cycle and the different states of the machine is as follows:

LIFE CYCLE PHASES OF THE MACHINE	
A	Transport
B	Assembly and installation
C	Commissioning
D	Regulating, Learning / Programming and/or Process Change
E	Operation
F	Cleaning, Maintenance
G	Troubleshooting / Troubleshooting
H	Dismantling / Decommissioning
MACHINE STATES	
Machine error condition	
a)	The variation of a characteristic or a dimension of the processed material or workpiece
b)	The failure of one (or more) of its components or of its functions
c)	External disturbances (e.g. electromagnetic interference, shocks, vibrations)
d)	A design error or deficiency (e.g. programme errors)
e)	Disruption of its power supply
f)	Surrounding conditions (e.g. damaged ground surface)
Human error condition	
a)	Loss of control of the machine by the operator (mainly for portable machines or mobile machines).
b)	Reflex behaviour of a person in case of malfunction, incident or failure during the use of the machine
c)	Behaviour that results from a lack of concentration or attention
d)	Behaviour resulting from the application of the "law of least effort" when performing a task.



e)	Behaviour resulting from pressures to keep the machine running under all circumstances.
f)	Behaviour of some people (e.g. children, people with disabilities, people with disabilities)

Evaluación de Riesgos		Estados posibles ISO12100																Realizado por Tipo de aparato	Procarelight Soldadura	Sistema	Maquina LC-WELD: Soldadura láser manual		Normas y directivas a aplicar	Indicaciones / Criterios para la PEM e inspección			
		Condición Error Máquina								Condición Humana Errónea																	
Nº	Ciclos de vida de la máquina	A	B	C	D	E	F	G	H	a	b	c	d	e	f	a	b	c	d	e	f	Descripción breve	Objetivo de la protección	Solución/Medidas a tomar			
		1	B= Montaje e instalación C= Puesta en servicio D= Reglaje, Aprendizaje, Programación E= Funcionamiento F= Limpieza, Mantenimiento G= Búsqueda/detección averías								X	X									X						X
2	B= Montaje e instalación C= Puesta en servicio D= Reglaje, Aprendizaje, Programación E= Funcionamiento F= Limpieza, Mantenimiento G= Búsqueda/detección averías								X	X									X	X	X	X	Peligros producidos por las radiaciones: exposición al haz Láser directo que pasa por el interior del cabezal o a reflexiones especulares producidas por herramientas o partes de la máquina cuando se retiran las protecciones	Evitar lesiones en la vista o en la piel a las personas que trabajen cerca de la máquina	1- Advertir mediante etiquetas de advertencia (visibles al retirar las protecciones) de la presencia del haz invisible. 2- Sólo debe intervenir personal cualificado con la formación adecuada. 3- Deberán utilizar los EPis adecuados y en buen estado (gafas certificadas según EN 207 y ropa adecuada)	Directiva 2006/25/EC UNE-EN ISO 11553-1 EN-IEC 60825-1 TR/IEC 60825-14 EN 207	1- Verificar el correcto estado de las gafas de protección 2- Verificar que los índices de protección IR de las gafas son los correctos 3- Verificar que el personal de mantenimiento tenga la formación adecuada
3	B= Montaje e instalación C= Puesta en servicio D= Reglaje, Aprendizaje, Programación E= Funcionamiento F= Limpieza, Mantenimiento G= Búsqueda/detección averías								X	X									X	X	X	X	Peligros producidos por las radiaciones: - ignición - explosión - emisión de contaminantes de mantenimiento e interpuertos en el camino del haz Láser	Evitar riesgos colaterales a las personas que trabajen sobre la máquina y a la propia máquina	1- No interponer materiales de ningún tipo en el camino del haz Láser (invisible) 2- Formación del personal que vaya a intervenir en estas operaciones 3- Adherencia de las instrucciones de mantenimiento	Directiva 2006/25/EC TR/IEC 60825-14	1- Verificar las instrucciones de mantenimiento 2- Verificar que el personal de mantenimiento tenga la formación adecuada
4	B= Montaje e instalación C= Puesta en servicio D= Reglaje, Aprendizaje, Programación E= Funcionamiento F= Limpieza, Mantenimiento G= Búsqueda/detección averías								X	X									X	X	X	X	Peligros eléctricos	Evitar riesgos de descargas eléctricas durante operaciones sobre la Máquina	1- Sólo debe intervenir personal cualificado con la formación adecuada 2- Deberán utilizar los EPis y herramientas adecuadas y en buen estado	UNE-EN ISO 11553-1	1- Verificar el correcto estado de los aislamientos eléctricos 2- Verificar que el personal de mantenimiento tiene la formación adecuada
5	E= Funcionamiento																						Peligros que resultan de la interacción del haz con el material: - Generación de materiales tóxicos, alérgicos, carcinógenos, metales pesados, etc. En el procesado de materiales	Evitar inhalación o el contacto con la piel de partículas que puedan causar daños	1- Sólo debe intervenir personal cualificado con la formación adecuada 2- Instalación de un sistema de aspiración adecuado 3- Deberán utilizar los EPis adecuados y en buen estado	UNE-EN ISO 11553-1	1- Necesario que el personal tenga la formación adecuada 2- Verificar el correcto funcionamiento del sistema de aspiración 3- Verificar el correcto estado de los EPis
6	E= Funcionamiento																						Peligros que resultan de la interacción del haz Láser con el material: - Emisiones de humos y vapores	Evitar la inhalación de humos y vapores	1- Sólo debe intervenir personal cualificado con la formación adecuada 2- Instalación de un sistema de aspiración adecuado 3- Deberán utilizar los EPis adecuados y en buen estado	UNE-EN ISO 11553-1	1- Necesario que el personal tenga la formación adecuada 2- Verificar el correcto funcionamiento del sistema de aspiración 3- Verificar el correcto estado de los EPis
7	B= Montaje e instalación C= Puesta en servicio D= Reglaje, Aprendizaje, Programación E= Funcionamiento F= Limpieza, Mantenimiento G= Búsqueda/detección averías								X	X			X						X	X	X	X	Peligros que resultan de la interacción del haz Láser con el material: - Ignición. En el procesado de plásticos, maderas o materiales combustibles	Evitar que se produzca llama	1- Sólo debe intervenir personal cualificado con la formación adecuada 2- Disponer de un sistema de extinción automático 3- En ausencia de un sistema de extinción automático, no dejar la máquina desatendida en ningún momento y tener un extintor al lado	UNE-EN ISO 11553-1	1- Necesario que el personal tenga la formación adecuada 2- Verificar el correcto funcionamiento del sistema de extinción
8	B= Montaje e instalación C= Puesta en servicio D= Reglaje, Aprendizaje, Programación E= Funcionamiento F= Limpieza, Mantenimiento G= Búsqueda/detección averías																						Peligros generados por descuidar los principios ergonómicos en el diseño del puesto de trabajo	Evitar la fatiga o lesiones debidas a una postura o movimientos inadecuados	1- Adecuar el espacio de trabajo y los elementos ergonómicos necesarios	UNE-EN ISO 11553-1	1- Verificar el espacio de trabajo y los elementos ergonómicos



### **ELECTRICAL RISK**

Caused by tampering with the power supply circuit, which should only be accessed by authorised maintenance personnel using the specific safety measures related to the electrical risk and/or by deficiencies in the insulation of the flexible cables or mains connections of the machine.

To reduce the electrical risk, do not open the door used to store the electrical circuit, as there are no parts inside for the user to handle. In the event of a fault, switch off the machine and notify a responsible or authorised person so that they can contact the specialised technical service.

To avoid indirect contact, make sure that there is a proper ground connection and that the housing is in perfect condition. Make sure that the chassis of the LCWELD laser welding device is connected to the ground.

Do not use gas, flammable liquid or electrical conduits for grounding.

Direct electrical contact can occur in the supply circuit due to insufficient insulation of flexible cables or connections to the mains or to the machine.

Indirect electrical contact can occur with the machine casing due to a voltage or grounding fault.

### **PROJECTIONS AND BURNS**

Eye projections and burns can be caused by micro projections of particles due to the welding itself and the parts being welded. Take the necessary measures to protect eyesight and skin.

Risk of burns or skin lesions. To minimise the risk, the use of protective gloves and close-fitting clothing of a suitable length for the activity being carried out is recommended, being cotton safety clothing that completely covers the arms and torso of the operator.

### **EXPLOSION AND FIRE**

It can be caused by working in flammable environments or inside containers that have contained flammable liquids or by welding containers that have contained flammable products. To avoid or minimise the risk, the material must be checked before starting work with the laser equipment.

### **INHALATION OF POLLUTANTS**

Risk of inhalation of contaminants produced by metal welding. To minimise or avoid the risk, optimal ventilation of the room is recommended together with localised extraction or, failing that, confinement of the process. If the first method is not sufficient and isolation of the process is not possible, individual protection of the worker's respiratory tract must be used in addition.



### **KNOCKS OR FALLS**

Risk of knocks/cuts against moving and immobile objects of the equipment, such as the casing or other parts of the machine.

Risk of falling objects during handling, good use of the hose and gun during use is recommended.

Risk of falling to the same level, it is recommended to maintain order and cleanliness in the work area to avoid falls caused by moving parts of the equipment such as the hose.

### **WELDING WIRE ENTRAPMENT**



It is compulsory to keep the feeder door closed at all times, except when operating the welding wire, in which case it must always be done with the equipment stopped and not in operation.

## **2.8 SAFETY MARKINGS ON LASER EQUIPMENT AND LABELLING**

The safety label placard, which is placed on the device, provides information about the risks of laser radiation that are present in your particular device.

This product has the required safety labels located on the outside of the device case in several places. These include warning labels indicating removable or displaceable protective housings, openings through which laser radiation is emitted, and certification and identification labels.

The following is the meaning of the labels on the product and their location on the equipment.

The UNE-EN 60825-1 standard requires that all laser products must carry labels to warn about the class, the beam emission aperture, the characteristics and the dangers of exposure to laser radiation generated by the specific product.

In addition to the laser identification and sorting labels on the LC WELD machine, there are the following labels:



A label indicating the output of the laser beam, i.e. on the welding torch with an arrow pointing towards the tip.



A label indicating the characteristics of the laser emission (wavelength and maximum power), the hazard from exposure to visible and invisible Class 4 radiation.



Laser radiation hazard label. Can be found alone or combined with other symbols.



#### SAFETY GOGGLES.

Compulsory eye protection.

Pictogram according to EN 61310 Indication, marking and operation.

Part 1: Specifications for visual, audible and tactile signals, Paragraph 7.



#### GLOVES.

Mandatory hand protection against burns.

Pictogram according to EN 61310 Indication, marking and operation.

Part 1: Specifications for visual, audible and tactile signals, Paragraph 7.



#### FACE SHIELDS.

Mandatory face protection.

Pictogram according to EN 61310 Indication, marking and operation.

Part 1: Specifications for visual, audible and tactile signals, Paragraph 7.



#### PROTECTIVE CLOTHING

Mandatory protective clothing in the work area.

Pictogram according to EN ISO7010.



#### WARNING! RISK OF ELECTRICAL CONTACT.

Work on the electrical installation must only be carried out by qualified personnel authorised by the company and in compliance with safety regulations.

Pictogram according to EN 61310 Indication, marking and operation.

Part 1: Specifications for visual, audible and tactile signals, Paragraph 7.

**WARNING! RISK OF LASER RADIATION**

Work on the laser machine may only be carried out by qualified personnel authorised by the company and in compliance with safety regulations.

*Pictogram according to the specific laser radiation standard EN 60825-1.*

**WARNING! GENERAL DANGER.**

General indication of caution due to a hazard which shall be defined in the area where the sign is placed.

*Pictogram according to EN 61310 Indication, marking and operation.*

*Part 1: Specifications for visual, audible and tactile signals, Paragraph 7.*

**HANDLING WITH GLOVES IS PROHIBITED**

Indicates the prohibition of handling certain items with gloves. In the case of LC WELD PRO, this refers to a task with the feeder.

Pictogram according to **UNE 81-501/81 on safety signs at workplaces.**



Risk of entrapment.

Indicates the risk of entrapment of certain components.

Pictogram according to EN-ISO 7010 Standard

**DANGER****Risk of injury due to illegible or missing labels!**

Over time, labels can become damaged, soiled and become difficult to identify or unreadable. If the labels cannot be read clearly, hazards or necessary operating information cannot be recognised. This can lead to accidents and/or serious injury to the user of the equipment.

**Cautions:**

- Always keep labels in good condition so that they remain legible.
- Never remove a label affixed to the equipment.



- If any label is damaged, illegible or missing, please contact the service department of your dealer.

Location and meaning of safety labels on LC-WELD PRO equipment:



On the inside of the yarn winder we find the following information stickers:





## 2.8.1 REGULATORY COMPLIANCE

Standard	Title / Description
<b>Directives:</b>	
<b>2014/35/EU</b>	The Low Voltage Directive covers all electrical equipment and components designed for use with a voltage rating between 50 and 1000 V for alternating current (AC) and between 75 and 1500 V for direct current (DC). It provides the essential (safety) requirements to be met by the electrical equipment and components covered by it, and describes the conformity assessment procedure to be applied by the manufacturer to ensure compliance with the essential requirements.
<b>2014/30/EU</b>	The EMC Directive aims to ensure that all electrical and electronic equipment minimises the emission of electromagnetic interference that may influence other equipment. The directive also requires equipment to be able to withstand disturbances from other equipment.
<b>2006/42/EC</b>	The Machinery Directive is an EU directive on machinery and certain parts of machinery. Mandatory health and safety specifications are combined with voluntary harmonised standards. Its main objective is to guarantee a common safety level for machinery placed on the market or put into service in all member states and to ensure its free movement within the EU.
<b>Laser safety</b>	
<b>IEC 60825-1 (EU)</b>	Safety of laser products. Part 1: Equipment classification and requirements
<b>CDRH 21 CFR 1040.10 (United States)</b>	Code of Federal Regulations (CFR). Title 21. Food and Drugs - Chapter I. Food and Drug Administration - Department of Health and Human Services - Subchapter J. Radiological Health - Part 1040. Standards for Performance for light emitting products - Section 1040.10. Laser products
<b>ISO 11553-2</b>	Safety of machinery. Laser processing machines - Safety - Part 2: Safety requirements for hand-held laser processing devices Part 2: Safety requirements for hand-held laser processing devices.
<b>EN 207</b>	Personal eye protection equipment. Filters and eye protectors against laser radiation (laser safety goggles).



## 2.9 WORKPLACE

The LC-WELD device is a CLASS 4 laser device and it is therefore mandatory to work with the device in a safe workplace. The risk assessment is to be carried out by personnel trained and specialised by LC in the assessment of laser workplaces. Safe working areas must be marked out.

### 2.9.1 SECURITY OF THE ENVIRONMENT

The LC-WELD PRO is prepared to work and be operated in:

- Interior space
- I work without rain or water.
- Ambient air temperature 5 to 35 °C.
- Relative humidity between 10 and 90 %.
- Overvoltage category II.
- See product specifications for additional information.

This equipment is not suitable for use where unprotected persons or children may be present. Keep away from sources of shock or vibration.

- Ensure that all personal protective equipment (PPE) is suitable for the output power and wavelength range listed on the laser safety labels attached to it.
- Inattentive or careless actions and operation may cause injury to the operator due to reflected or scattered laser radiation.
- Do not expose the device to a high humidity environment (>90 % humidity).
- The laser device is water-cooled. Operation at higher temperatures will accelerate ageing and may decrease performance. If the device overheats, do not use it and call for technical support.

#### 2.9.1.1 NOISE LEVEL AND DECLARATION

Declaration of noise emission levels	
<b>Machine: LC-WELD laser welding</b>	Operating conditions Emission sound power measurements of the equipment without welding. Welding pressure measurements of a metal part



	for 30 seconds at 1 metre from the welding point.
<b>Equivalent continuous A-weighted sound pressure level at the workstation in dB(A).</b>	84
<b>Maximum instantaneous C-weighted sound pressure level at the workstation in dB(C).</b>	97
<b>Sound power level emitted by the machine, A-weighted, in dB(A).</b>	67
<b>Reporting constants, background noise (K1A) and local environment correction for power (K2A) and sound pressure (K3A) in dB.</b>	$K_{1A} = 1.7$ $K_{2A} = 0.8$ $K_{3A} = 0,3$
<b>Values determined according to the basic acoustic standards UNE-EN ISO 11202:2010 and UNE-EN ISO 3746:2010.</b>	

The values quoted are noise emission levels and are not necessarily safe sound levels for work. Although there is a correlation between emission levels and exposure, this cannot be used reliably to determine whether additional precautions are necessary.

Factors influencing the actual exposure levels for personnel include the characteristics of the workspace, noise from other sources, etc. i.e. the number of machines and other adjacent processes.

Also, the permissible exposure levels may vary from country to country. This information, in any case, allows the user of the machine to make a better assessment of the hazard and risk.

### 2.9.2 ESTABLISHMENT OF A CONTROLLED LASER AREA

In many jurisdictions, laser safety regulations require the appointment of a Laser Safety Officer (LSO) in each company or institution where laser equipment is used.

The employer is primarily responsible for compliance and adherence to laser safety standards, but may delegate responsibilities or tasks. The key points in establishing the controlled laser area are the determination of the maximum foreseeable irradiance to which personnel may be exposed and then the design of the PPE and shielding of the laser area.

Suitable enclosures must be used to ensure a safe working area for the laser. This includes, among other things, laser safety signs, interlocks, adequate warning devices and training/safety procedures. Do not operate with the welding head at eye level.



- The primary laser of this product is class 4. Therefore, it is mandatory to appoint a site RSL:

In Germany: According to the OStrV, the designation of an RSL at the workplace is mandatory when workers use or are exposed to laser products of class 3R, 3B and 4.

In the United States: According to ANSI Z136.1, the designation of an RSL in the workplace is mandatory when workers use or are exposed to Class 3B and Class 4 laser products.

Although not mandatory in our jurisdiction, it is advisable to assign a laser safety officer.

- The laser safety officer, together with the distributor of the equipment can work to establish the laser controlled area, to protect all persons who may be in the vicinity of the operating laser equipment.
- Use the laser only in a controlled laser area with controlled access.
- A recommended option is to carry out administrative controls, i.e. to keep a record of all persons entering and leaving the controlled laser area, as well as all persons who have been trained to work with lasers.
- It must be ensured that the laser is in a controlled area where the beam cannot escape either explicitly or accidentally. Any barrier used in the LLZ must be made of a laser-resistant material that can withstand both direct and diffuse beams.

In the EU: see EN 60825-4.

- Outside the controlled laser area, there must be appropriate signs indicating when laser work is in progress. In addition, there must be appropriate warning and hazard signs, informing of potential hazards.

In the EU, the marking of the laser zone is mandatory according to EN 60825-1.

- Restrict access to the CFZ to only those persons who are trained in laser safety while operating the hand-held laser device.

Post a sign with the names of all persons authorised to work within the laser working area.

---

### 2.9.3 SAFE WORKING SPACE: CONTROLLED LASER AREA

This room may consist of a room or an area enclosed by fixed or movable partitions (cabin, protective enclosure, etc.). It is considered to be an area with access reserved for personnel authorised by the person in charge of the unit.



- A movable wall or partition is an integral part of the means of prevention and should only be moved for planned operations with compensatory measures if necessary.
- A laser device can be installed in an enclosure acting as collective protective equipment.

Safe working spaces must be identified. Depending on the risk assessment carried out, one or a combination of the following options shall be chosen:

1. Install welding equipment inside a controlled area, i.e. an enclosure with fixed walls and ceiling and access door with safety switches to prevent access by third parties or unauthorised persons. Access shall be restricted to authorised personnel. In addition, a light signal external to the area may be used to indicate when laser work is in progress.
2. Use screens separating workstations to protect other workers from direct and indirect laser light radiation. The material of these screens must comply with the following characteristics:
  - These partitions must be at least 2 metres high.
  - This area must be enclosed in such a way that no laser or light emission to the outside can occur.
  - It should be a well-ventilated area with a fume extraction system if necessary.
  - One of these partitions will act as a door, so it must be movable, without losing the watertightness of the whole.
  - It is not necessary to close the ceiling, as long as we do not have other people working in an area or on a higher level with direct contact to the laser welding equipment.
  - The material of such partitions can be made of:
    - 2 mm aluminium (preferably)
    - 1.5 mm aluminium.
    - 2 mm carbon steel.
    - Aluminium and rock wool sandwich panel.
  - It is advisable to paint these screens black to avoid reflection of the material itself.
  - It is recommended that the minimum working space be 3 x 3 metres.
  - On the outside it shall be indicated that laser work is carried out indoors, with appropriate safety signs.
  - Access by unauthorised persons shall be prohibited. It is recommended to have a control of the persons who have access to the controlled laser area.



The characteristics of this demarcated area are indispensable for a safe working space once the hazards and risks outlined above are known.

**DANGER**

**Under no circumstances may anyone enter the work area without the appropriate safety PPE.**

**Irrespective of the solution adopted, the use of approved laser safety goggles by the operator of laser welding equipment is mandatory.**

Other recommended security measures:


- System using light signals on the outside of the enclosure, to know whether the laser is emitting or not.
- Power cut-off system in case of accidental opening of the door, with consequent interruption of the laser emission.
- Acoustic warning to know when a person wants to enter the enclosure and to be able to control the laser emission from the inside.

It is mandatory to work in a controlled area in order to work safely. Under no circumstances shall there be any unauthorised persons inside the welding area.

Regarding the configuration of the welding space:

- In a space without walls, with an enclosure of 4 partitions in the shape of a square or rectangle.
- In a space with a wall, with an enclosure of 3 U-shaped partitions, taking advantage of the wall.
- In a space with two walls, with an enclosure of 2 L-shaped partitions, taking advantage of the two walls.
- In an existing box with three walls, enclosure with 1 partition and door.

Examples of enclosures for a laser safety zone with LC-CABIN:





Example of LC-CABIN enclosure with traffic lights outside:

**DANGER**

**The configuration of the controlled area and the position of the movable partitions shall be determined by the results of the risk assessment carried out before the equipment is put into operation.**

When working with gas, it is strictly forbidden to approach with a flame, produce sparks or smoke in the vicinity of a workplace where gas may normally or accidentally be present in the atmosphere. It is forbidden to search for gas leaks with a flame; soapy water or other suitable detector must be used for this operation.

Good lighting is recommended for welding work. In general, a minimum illumination of 100-200 lux should be provided for operations without high visual requirements and from 300-500 lux if there are medium visual requirements such as precision or adjustment work, plus lux if high visual requirements are needed.

The slope of the ground must be a maximum of 7% to guarantee the stability of the equipment. In any case, it is recommended to work on a completely flat ground, without irregularities or slope.

Under no circumstances may the equipment be placed on top of other objects, such as pallets, tables, lifts, etc.

### 2.9.3 LASER SAFETY OFFICER (LSO)

In some jurisdictions it is mandatory to establish a laser safety officer, although not mandatory in some countries, it is always recommended. The workplace Laser Safety Officer (LSO) will need to identify the maximum permissible exposure and hazard



distances to determine what PPE, guards and other safety procedures are necessary to safely operate the product within the laser controlled area (LCA). The manager may also establish administrative controls and access restrictions to the area where the laser equipment is operated.

## 2.10 ELECTRICAL SAFETY



**DANGER**

**Electrical voltage! Danger to life through direct or indirect contact with live (live) parts.**

**Cautions:**

- **Only trained and authorised personnel may have access to the inside of the equipment for repairs.**
- **To avoid electric shock, do not remove the covers.**
- Any tampering with the product will void the warranty.



**DANGER**

**The input voltage to the laser welding unit is potentially lethal!**

**Cautions:**

- **All electrical cables and connections should be treated as if they were at a harmful voltage level.**
- All parts of the power cable, connector or housing of the device must be considered hazardous.



### **IMPORTANT**

**All electrical and welding gas connections must be connected before applying power to the unit.**

- In addition, and where applicable, all connections must be secured with screws to ensure proper operation.



**Inadequate grounding and AC voltage To ensure electrical safety:**

**Cautions:**

The device must be properly grounded through the protective earth conductor of the AC power cable. Any type of interruption of the protective earth conductor from the protective earth terminal can lead to personal injury.

Before powering the device, make sure that the voltage of the AC power supply is appropriate. Failure to use the correct voltage may result in damage to the device. Refer to your specific model markings for proper power connection.

## 2.11 PREVENTION AND SAFETY SYSTEMS

There are different prevention and safety systems that will make the handling and operation of the LC-WELD laser welding machine much safer and will minimise the risks during use. The LC-WELD machine is equipped with the technical safety elements required by the UNE-EN 60825-1 standard.

### 2.11.1 POWER SUPPLY CIRCUIT

Power supply cables must be of adequate cross-section to prevent overheating. Their insulation must be sufficient for a rated voltage > 1000 V. The connection terminals of the LC-WELD laser welding device and the plug pins must be adequately insulated.

### 2.11.2 "GROUND" CLAMP AND CONTROLS

The LC-WELD PRO laser welding device is equipped with a clamp that is very similar to what is known as a "ground". However, this clamp does not constitute a "ground" as such: it is simply a safety system that prevents the LC-WELD PRO laser welding device from operating if the gun or torch is not in contact with the work table or the workpiece, in order to avoid injuries and physical burns due to direct contact with the laser beam emitted by the gun.


The mass is important and of mandatory use. In addition, the output of the laser beam is only possible when a button on the top of the welding torch handle is pressed.



### 2.11.3 LASER EMISSION WARNINGS

There are laser emission warnings, located at different points on the laser welding equipment.

On the laser welding screen, when working, (within the WORK and WELDING SCREEN function), there is an alarm. When it is red, it indicates laser emission, e.g.:



The same warnings can be reproduced at the access points to the working areas with the equipment, for example, by installing traffic-light type warning lights. These warnings can be placed both outside the controlled laser area and inside, to indicate the laser emission. In the same way, they can be complemented with door sensor systems, so that when the door is opened unexpectedly, the laser automatically stops emitting.

### 2.11.3 GROUNDING

The installation of the grounding sockets must be carried out according to the manufacturer's instructions. It must be ensured that the chassis of the LC-WELD laser welding equipment is connected to the grounding system.

Do not use gas, flammable liquid or electrical conduits for grounding.



#### 2.11.4 ELECTRICAL PROTECTION MAGNETOTHERMICS

The equipment has two protections against overcurrents (magnetothermal) F1 and F2 located in the main electrical panel.



The protection system will be activated in the case of a general overcurrent or in the control circuit.

## 2.12 TRAINING

Article 6 of *Directive 2006/25/EC on the minimum health and safety requirements regarding the exposure of workers to risks arising from physical agents (artificial optical radiation)* requires that workers exposed to risks from artificial optical radiation receive information and training, especially workers using class 3B and class 4 laser products. The training shall include:

- The measures taken.
- General explanation of exposure limit values and associated potential risks.
- The results of assessments, measurements and/or calculations of the levels of exposure to artificial optical radiation carried out, as well as explanations of their significance and potential risks.
- How to detect adverse health effects due to exposure and how to report them.
- The circumstances in which workers are entitled to health surveillance.
- Safe working practices to minimise risks from exposure.
- The correct use of appropriate personal protective equipment.

If there is and/or is compulsory the figure of a laser safety officer who knows all the PPE and safety rules of the machine.



### 2.13 GENERAL SAFETY INSTRUCTIONS

The above provisions are subject to the obligations laid down in Directive 2006/42/EC of the European Parliament and of the Council of 17 May 2006 on machinery and amending Directive 95/16/EC and Directive 2006/25/EC on the minimum health and safety requirements regarding the exposure of workers to risks arising from physical agents (artificial optical radiation).

In addition to the European standards UNE EN 60825-1 and UNE EN 60825-4 regarding safety and classification of laser types, UNE-EN 208 of 2010 and UNE-EN 207 of 2018 regarding eye protection essential for the use of the equipment.



If this laser welding equipment is used in a manner not specified herein, the protection provided by the device may be impaired and the warranty will be void.



**Do not use nozzles, spare parts and consumables from other suppliers. The fibre cable of the LC WELD device connected to the gun using spare parts from other suppliers may cause the safety functions of the device to malfunction. This may also damage the equipment and increase the risk of injury due to laser irradiation.**

**Precautions:**

- Connect the fibre only to an approved welding head supplied by LC or an official distributor.
- Do not connect other devices to the laser welder head connections on the rear panel other than the supplied cable and head.
- Do not use nozzles, spare parts or similar from other suppliers, it may cause the equipment to malfunction.

### 2.14 PROHIBITIONS



Welding work with the LC-WELD PRO laser welding device must not be carried out in the vicinity of degreasing operations, as this may result in the production of fumes hazardous to health.



Welding shall also not be permitted inside containers, tanks or casks until they have been thoroughly cleaned and degassed with steam.



It is forbidden to carry out any kind of welding without the necessary protective equipment.



Never use the LC-WELD laser welding equipment outside the materials to be welded.



It is prohibited to store or operate near corrosive or flammable materials.



It is forbidden to use the gun with the dough in the gun itself.



It is forbidden to use the equipment without specific training.



## CHAPTER 3 - LASER WELDING

### 3.1 DESCRIPTION

LC Lasers manual laser welding is a revolutionary and innovative system in the world of metal welding.

The LC-WELD PRO belongs to the latest range of laser welding equipment, a complete and easy to use device, which allows very fine welds to be made without excessive heat input or deformation of the materials. We can ensure complete penetration in the materials and thicknesses indicated.

The operability of the LC-WELD PRO laser welding machine does not require a high level of technical expertise on the part of the operator. It allows us to weld a wide variety of materials using the same technique, simply by configuring the machine's parameters.

The power and precision offered by LC Lasers' manual laser welding system allows welding at high speeds, depending on the power of the equipment and the thickness of the material to be welded.

This technology also gives the option of welding with or without material input, depending on the weld preparation and the desired finish.

### 3.2 DIFFERENCES, ADVANTAGES AND DISADVANTAGES COMPARED TO OTHER WELDING TYPES

LC Lasers differ significantly from conventional welding for several reasons. Firstly, it does not use an electric arc like conventional welding, such as ELECTRODE, MIG-MAG (continuous wire) or TIG, but a very powerful and focused light (laser beam). This allows it to affect the material to be welded in a different way: it only heats the material where the light hits, unlike the electric arc.

This produces very thin welds with excellent depth and penetration and virtually no spatter without excessive filler, which reduces polishing time considerably and allows deep, strong welds to be made without overheating the material, resulting in a significant reduction in deformation, especially of thin materials.

Unlike other methods and technologies, LC laser welding allows the equipment to be configured to always achieve the same result: the welding is controlled by the machine, not the operator. The welding speed can therefore be selected with the welding wire feeder once the parameters have been set.



Although the gun and torch are designed to be as ergonomic as possible, the flexibility of the hose and the robustness of the gun require proper preparation for welding, including tooling, positioners or tackers, among others.

### 3.3 LASER WELDING APPLICATIONS

LC Lasers handheld laser welding is suitable for a wide range of applications offering innovative results and finishes in the metal industry:

- The LC-WELD PRO manual laser welding machine is specially designed for linear welding, with or without input, of sheet thicknesses between 0.5mm and 5mm, and of materials such as carbon steel, stainless steel, aluminium, titanium, among others.
- Laser welding revolutionises welding thanks to its speed, ease of use and other advantages. It is a device that aims for maximum efficiency and allows you to optimise your production system.

### 3.4 INTENDED USE OF THE LASER WELDING MACHINE

Following the steps and instructions in the above points concerning the operation of the laser machine is the only intended use of the laser welding machine. It is only intended to be used for its primary function: metal welding work using a laser beam.



**Under no circumstances may the laser welding machine be used for any purpose other than welding the materials specified and suitable for laser welding. See in this manual which materials can be welded with the laser welding machine.**

As indicated in the previous points, the type of welding to be carried out can be selected and the nozzles of the laser welding gun can be interchanged for this purpose, but not for any other purpose. The user of the laser welding machine is obliged to use the specified PPE for the intended use of the machine.



**Under no circumstances work or be near the laser machine without the appropriate laser safety goggles.**



Under no circumstances may the laser welding machine be used to work on objects that could injure people or animals or damage buildings, valuables or similar objects.

Under no circumstances should the laser gun be pointed at living beings, delicate materials, structures, constructions, electrical equipment, electrical appliances, electrical installations, vehicles, automobiles or other objects that are far away from the welding work itself, as these actions can result in serious accidents to people, animals and valuable installations. LC is exempt from any legal, penal or administrative liability and repercussions resulting from the misuse of the laser welding machine not foreseen in this manual.

Under no circumstances should the filler wire be used for any purpose other than to feed material during welding. It is important not to touch this wire under any circumstances once the machine is running.

---

#### 3.4.1 MATERIALS SUITABLE FOR LASER WELDING

The materials suitable for welding by the LC-WELD PRO hand-held laser welding machine are as follows:

- Stainless steel
- Aluminium
- Titanium
- Galvanised steel
- Carbon steel




**To work other materials or special alloys not specified in the above list, please consult LC technical service for your safety.**

---




# CHAPTER 4 - LASER WELDING EQUIPMENT


## 4.1 EQUIPMENT COMPONENTS



Comentado [ML1]: Pendent traducció a anglès



4.1.1 OVERVIEW OF THE REAR OF THE EQUIPMENT





#### 4.1.2 LASER RESONATOR

The laser resonator produces the laser beam, which is directed to the gun by means of a flex with a fibre optic cable.



The fibre laser generator data sheet is included in ANNEX 1, together with the optical specifications of the fibre output.

#### 4.1.3 CHILLER OR COOLER

The chiller is used to cool the laser resonator and the gun or torch, to maintain a stable temperature in both, as the energy produced gives off considerable amounts of heat. **The cooler should always contain distilled water**, and the level should NEVER drop below the sight glass. The water level should be checked periodically and the water should be changed every 10 months of continuous use.

#### 4.1.4 FEEDER OR YARN FEEDER

The feeder accessory is a removable device that is supplied with LC-WELD PRO. The feeder is attached to the gun by means of a fitting that connects the wire rope to a metal tube and to the gun. It can be regulated from the same screen, activating and deactivating the feeder and controlling the parameters.



It is compulsory to keep the feeder door closed at all times, except when operating the welding wire, in which case it must always be done with the equipment stopped and not in operation.



When the laser welding equipment is working with the feeder, the side door of the feeder, where the rollers and the filler wire are located, shall remain locked, if available. It is strictly forbidden to open and access the inside of the feeder while the equipment is working.



#### 4.1.5 DISPLAY

The LC-WELD laser welding machine's display allows easy and practical operation of the machine's parameters, simplifying its options as much as possible without reducing its capabilities. It is organised in a menu of functions explained in the SOFTWARE chapter.



#### 4.1.6 GUN


The gun or torch incorporated in the LC-WELD laser welding equipment is of high quality.

In this drawing, the optical path of the laser beam inside the gun and to the focal point is simplified.

The laser beam passes through the collimating lens to STABILISE its diameter before the Steering Mirror (SM). After the mirror, the beam is directed towards the focusing lens which focuses the beam at the tip of the gun, GETTING THE FOCAL POINT. After the



focal lens, the gun has two lens protectors that protect the lens from dust or external substances.



Steering mirrors in laser welding are used to direct and focus the laser beam to the precise welding location. This method offers the possibility of high precision and detailed control over the welding process. Steering mirrors allow precise manipulation of the laser beam, which is crucial for achieving high quality weld joints. They can direct the laser to specific areas and make fine adjustments to ensure correct penetration and weld formation.

They also allow rapid changes in beam direction, which increases the speed of the welding process and improves productivity.



**During the intended operation of the LC WELD device, the only possible opening of the laser beam is at the tip of the welding gun.**



#### 4.1.7. CONNECTION POINTS

The connection points at the back of the machine are described below.



Connection point	Function
GAS	Gas inlet connection for gun operation.
CABIN	Connection to the welding cabin security system.
CLAMP	Ground clamp cable connection.
FEEDER	Wire feeder connection
USB	Exporting machine statistics Export/Import of machine work configurations
ETHERNET	Conexión a internet de la máquina para acceder a la plataforma de "cloud" de cliente para ver online los datos de los equipos en funcionamiento. Conexión online para asistencias técnicas.

## 4.2 TECHNICAL DATA

### 4.2.1 DATA LASER WELDING EQUIPMENT

Model	LC-WELD PRO
Product reference	LC-SL1500W-PRO
Laser power	1500w
Electricity consumption	<5500W
Voltage	220-240VAC
Wavelength	1070nm ±10
Frequency range	<50 kHz
Power stability (2 hours)	<1,5%



Power stability (24 Hours)	<2.5%
Laser Efficiency	42%
Laser Class	4 (IEC 60825-1)
Weight	<150kg
Hose length	8m Approx
Measurements Approx.	420x720x1100 mm

#### 4.2.2 DATA WIRE FEEDER

Model	LC-FEED PRO
Product reference	LC-FEED-PRO-V1.07
Consumption	<120W
Tension	24Vdc
Measures	240x420x520mm
Weight	<12kg
Engine type	DC PWM
Other engine	Includes Encoder
Control system	CANBUS

#### 4.2.3 LASER DATA


Model	L1500W-V5.1
Product reference	L1500W-V5.1-50µm
Laser Power	≤1500W
Laser Type	CW HPP
Consumption	<3800W
Voltage	220-240VAC   50 Hz
Maximum energy consumption	20 A
Wavelength	1070nm ±10
Power instability	<2,5%
Power range	1-100%
Frequency range	<50 kHz
Laser Efficiency	42%
Start time	10 µs
Type of connection	QBH
Fibre length	10m
Output fibre diameter	50 µm



Weight	20kg
Dimensions	435x339x100mm
Ambient temperature	5~40°C
Ambient humidity	10-90%
Need for refrigeration	2,2kW Q
Cooling method	Water cooling
QBH cooling water temperature	Ambient temperature (non-condensing)
Cooling water temperature	24-26°C
Cooling water flow	30 L/min
Storage temperature	-10-50°C
Laser Class	4 (IEC 60825-1)
Pointer power	1mW
Pointer class	2M (IEC 60825-1)

#### 4.2.4 DATA GUN

Model	LC-WELD GUN SM
Material	Aluminium/Stainless Steel
Product reference	LCWELD GUN SM V 4.2
Weight	670g
Measures	230x210x30mm
Focal lens type	F150 $\lambda=1060-1080\text{nm}$
Lens protector type	99.999% T $\lambda=1060-1080$
Type of collimating lens	F=50C $\lambda=1060-1080\text{nm}$
Connection	QBH
System	Steering mirror (S.M.)
No. of lenses	1
No. of lens protectors	2
No. of collimating lens	1
Compatible equipment	LC WELD PRO & LC WELD SMART
Driver	LC_FMR-20_DRIVER_Rev2
Maximum power equipment	<2000W
Feeding	24V
Communication	CANBUS






# CHAPTER 5 - PACKING AND DELIVERY

In this section, we inform you about the packaging and delivery process of the LC WELD PRO manual laser welding equipment. Knowing this information will help to avoid any kind of inconvenience with the delivery of the package.






## 5.1 CONTENTS OF THE SHIPMENT OF THE LC-WELD PRO EQUIPMENT

LC REFERENCE	DESCRIPTION	IMAGE
LC-WELD PRO	LC-WELD PRO EQUIPMENT	
LC-FEEDER	WIRE FEEDER	
10402-00018	POWER SUPPLY CABLE	
10301-00014	GAS TUBE	
10103-00033	QUICK CONNECTOR GAS	
11501-00017	REFRIGERATOR DRAIN ASSEMBLY	














10701-00014	THREAD FEED WIRE (0.8-1.6mm)	
10401-00029	SAFETY CABLE	
10401-00026	FEEDER CONNECTION CABLE	
10901-00063	Gun support	
10701-00022	ALUMINIUM ROLLER KIT 0,8-1,0	
10701-00023	ALUMINIUM ROLLER KIT 1,2-1,6	
10701-00052	KIT ROLLERS GENERAL Ferritics 0,8- 1,0	



10701-00053	KIT ROLLERS GENERAL Ferritic 1,2- 1,6	
11101-00015	USB driver	
22001-00014, 22001-00035, 22001-00056, 22001-00077, 22001-00098	LC-WELD PRO PRINT MANUAL (depending on language)	
22001-00009, 22001-00117, 22001-00030, 22001-00051, 22001-00072, 22001-00093	WE CARE ABOUT YOU (depending on language)	
22001-00115, 22001-00042, 22001-00021, 22001-00063, 22001-00084, 22001-00105	PRINTED SAFETY BROCHURE (depending on language)	
55001-00001	PROTECTIVE GOGGLES	
11001-00003	LENS SHROUDS D18X3mm (x10)	
10103-00030	GROUND WITH CABLE AND CONNECTOR	



## ACCESSORY BOX:

10901-00168	WELDING PIPE	
11201-00089	M5X16 DIN912 x2	
11201-00167	M3X6 DIN912 x2	
10901-00071	Brass tube	
10901-00086	Sirga Ring	
10901-00041	Rope support	
10203-00010	Straight female straight metal cable fitting	
10901-00100	Lower towline support	
10901-00092	Welding pipe fixing thread	
10901-00169	Tool for lens boxes and protectors	
10901-00110	FE Nozzle Closed 0,8" nozzle	



10901-00111	Nozzle FE Closed 1,0" input	
10901-00112	Nozzle FE Closed 1.2" (1.2")	
10901-00113	Nozzle FE Closed 1,6" nozzle	
10901-00114	Nozzle AL Open 0,8" input	
10901-00115	Nozzle AL Open 1.0" input	
10901-00116	Nozzle AL Open 1,2" input	
10901-00117	Nozzle AL Open 1,6" input	
10901-00118	Short inner SA nozzle	



10901-00119	Long outer SA nozzle	
10901-00024	BRASS NOZZLE 0,8	
10901-00021	BRASS NOZZLE 1,0	
10901-00022	BRASS NOZZLE 1,2	
10901-00023	BRASS NOZZLE 1,6	
11001-00002	LENS F150 0,4mm LO: 1060-1080nm	
Keys of the equipment		

**IMPORTANT**

**In the event of an incident, you must inform the carrier immediately, providing a list of all incidents encountered.**

We recommend that you send photographs of the condition of the package to your LC Lasers technical and/or sales contact in order to resolve the issue and find a solution.

## 5.2 DELIVERY

All LC-WELD laser welding equipment is rigorously manufactured, checked, tested and approved by our technical and engineering staff prior to delivery: our strict quality control enables us to ship 100% operational and ready-to-work equipment. Ensuring that only qualified and fit-for-purpose laser equipment can be delivered.

On the other hand, it is always recommended to unpack the package very carefully, in order to reduce the possibility of any damage to the equipment. In section 5.4 a series of instructions for a correct unpacking of the package is provided.



**Check the box for any damage due to careless handling or blows during transport.**

### 5.3 INSPECTION ON DELIVERY

The package to be delivered is labelled with safety information for both the carrier and the recipient, but this does not necessarily guarantee correct handling. Check the outside of the box for obvious damage during transport.



IMPORTANT

**Precautions:**

- **It is of utmost importance that, as soon as we receive the package, we check whether the box or the laser equipment is damaged.**
- If you discover damage to the case or the laser machine during inspection, take photographs of the damaged parts.

### 5.4 UNPACKING THE PACKAGE

The use of a pallet truck is recommended for moving the machine to the place where it is to be unpacked. Always place the machine on a flat and stable surface.



IMPORTANT

When unpacking the package, our technical team always recommends using the right tools and personal protective equipment (PPE). In this way, we can guarantee a correct unpacking of the laser machine.



**Overweight Injury Warnings**

In order to avoid physical injury, never attempt to transport the package individually. The laser machine must be carried by at least two people.



Manual transport of the machine should be limited to a minimum time and distance. If long distance transport is required, material handling equipment should be used.

---

1. A list of product components is given in section 5.1. Check that all items are inside the box.
- 



**IMPORTANT**

If any component or material from the list provided is missing, please contact LC Lasers. Under no circumstances should you attempt to operate the equipment if you notice any damage or malfunction or if any item is missing.

---

2. It is recommended to keep all packaging for any future storage or transport needs.



## CHAPTER 6 - INSTALLATION

---

The laser welding machine is likely to be used most often by the welder, who has to perform welding as a large part of his job. It is also possible that a distributor or dealer will use the machine to demonstrate its operation to a third party.

Whatever the case may be, the operating steps described in this manual must be followed. This chapter details the first steps to be taken when you receive your new LC-WELD laser welding equipment. Please follow these instructions carefully when starting up the device for the first time and keep this manual handy for future reference regarding maintenance and operation of the device.

### 6.1 PRECAUTIONS

---



IMPORTANT

**Damage to the welding system - incorrect voltage!**

**Before connecting the power supply, make sure that the voltage and wiring are correct!**

**Precautions:**

- **Please refer to the specifications for the appropriate power supply requirements and/or consult LC technical service or an official distributor.**
  - Make sure that the input voltage is equal to the level indicated in the specification (see section 6.1).
- 



IMPORTANT

Use only in an environment with sufficient airflow to allow for the specified heat load produced during the intended operation of the equipment.

---

### 6.2 PREPARATION OF EQUIPMENT

When the equipment is received, it is important not to carry out any action without having read this manual carefully. In case of initial doubts, contact your technical service.

The following sections specify the different preparations necessary for the correct functioning and operation of the equipment.



IMPORTANT

**The refrigerator is delivered without water** to avoid damage to the equipment in the event of possible water loss during transportation. To ensure correct start-up of the refrigerator, please see section 6.2.5.

---

### 6.2.1 ENVIRONMENTAL CONDITIONS

The equipment must be in an environment with a **reasonable temperature**. The suitable temperature range is **between 10°C and 33°C**.

---

### 6.2.2 ELECTRICAL CONNECTION

To make the connection to the electrical power supply, a 32 A single-phase electrical panel connector is supplied with the equipment. This connector must be connected as follows:

L1=Line voltage > L2/N=Neutral connection > PE=Grounding

Connect the equipment to the power supply with the cable provided with the equipment. Make sure that all connections are securely fastened, and that no connectors are loose.

Finally, operate the rear disconnecter and switch on the machine normally.



IMPORTANT

**Damage to the welding system - incorrect voltage!**

**Before connecting the power supply, make sure that the voltage and wiring are correct!**

**Precautions:**

- **Please refer to the specifications for the appropriate power supply requirements and/or consult LC technical service or an official distributor.**
- **Make sure that the input voltage is equal to the level indicated in the specification (see section 6.1).**

---

### 6.2.3 GAS CONNECTION

The LC-WELD PRO laser welding machine requires gas for a good weld finish, as in other fusion metal joining techniques and methods.



The gas also protects some of the optical elements of the gun, so an internal sensor system **will not allow work to be carried out** if the equipment is not connected to a **pressurised gas system**.

The gases admitted for welding shall be high purity inert gases such as:

- Technical Argon.
- Nitrogen or Technical scourge.

The gas inlet is located at the rear of the unit, and the connection is made by means of a quick connector connected at the other end to the gas bottle with regulator or to the gas supply system if one is available.

The FLOW rate of gas supplied in welding is usually between **18L/min and 22 L/min**, the flow rate being variable to adapt it to the different types of work carried out.

**IMPORTANT**

It is important to **ALWAYS** open the shielding gas supply before starting to work with the LC-WELD PRO laser welding device. Otherwise the control software itself will not allow work, as it will not detect any pressure in the system.

**DANGER****Positioning and fixing gas cylinders**

Gas cylinders can explode if damaged or placed near the welding area, causing injury and property damage. Injury and damage may also occur if the cylinder tips over.

**Precautions:**

- Gas cylinders must be protected and located in areas where they cannot be knocked or damaged.
- Place them away from sources of heat, sparks or flames, as well as from the reflection of the laser beam.
- The cylinder must be stored in an upright position and secured on a fixed support.

#### 6.2.4 SAFETY, CAB AND SEMAPHORE

There are different safety systems on the LC-WELD PRO laser welding machine, such as the ground clamp and the LC-CABIN safety cabin system.

- The ground clamp must ALWAYS be connected to the work table or, failing that, to the workpiece if it is too large to be placed on the table or if it has non-conductive parts. Details of its operation will be given later in this manual.

**Connect the ground clamp to the welding table or to the workpiece to be worked on.**

- For safety and regulatory reasons, the LC-WELD PRO device must be associated with a security locking system, to which the device must be connected.

This system should incorporate, at a minimum:

- Cabin made of suitable material.
- A system of sensors on the door(s), intended to interrupt the operation of the equipment if one or more doors are opened during the use of the equipment.
- An external traffic light, intended to indicate the status of the equipment inside the cab.
- In some territories, it is necessary to use door locking systems.


For the connection of the security system, cabin and traffic light, the connector located in the rear part will be used and the cable provided with the cabin will be connected to it. This cable is responsible for communicating the equipment with the control board of the car, and controls everything related to safety, both the door closing sensors and the traffic light.

**NOTE:** *The equipment will not allow work if the safety system is not connected to an LC-CABIN cabin. In case of non-installation of a safety system with LC-CABIN cabin, consult your dealer.*

#### 6.2.4.1 LC WELD PRO CONNECTION TO THE LC SAFETY PROPRIETARY SYSTEM


The LC SAFETY system is LC Lasers' own system for connecting the LC WELD PRO to an LC CABIN. LC SAFETY provides a safe and simple connection between the laser welding unit, the external traffic light and the cabin door sensor to prevent unexpected openings when the laser is active. The LC CABIN offers to form a laser safety zone to work safely with the equipment.

The following diagram summarises the connection between the LC WELD PRO and the LC CABIN via the LC SAFETY system:



#### 6.2.4.2 LC WELD PRO CONNECTION TO AN EXTERNAL SYSTEM

To connect to a system other than LC SAFETY itself, the following pin diagram must be followed:



PIN	LABEL NAME	COLOUR	SIGNAL
1	+24V	Web	24V SUPPLY
2	GND	Black	GND
3	+ITLK	Grey	ITLK +
4	RESET	White	RESET
5	L_RD	Green	LIGHT RED 24V
6	L_GN	Pink	LIGHT GREEN 24V



7	L_OG	Orange	LIGHT ORANGE 24V
8	AUX	Blue	RESERVE

- Pin 3 and 2 are for the door sensor.
- Pins 2, 5, 6, 7 are for the traffic light.
- Pin 4 is RESET FUNCTION.

### 6.2.5 COOLING AND COOLING WATER

The LC-WELD PRO hand-held laser welding unit is water-cooled. The water used for cooling the unit is **deionised distilled water**.

LC-WELD laser welding units are delivered, unless otherwise specified by the customer, with **the chiller empty of water**.

Before starting the equipment, you must fill the tank with distilled deionized water through the access on the back of the housing, as shown in the following images:



Access to the tank (unclip the cap)



Filling with water

**Check that the water level is adequate:** it should not be below 90% of the indicator bubble located on the back of the equipment.

Once the tank is filled, when you turn on the equipment, the rest of the circuit will automatically prime. The automatic priming process may take up to 4 minutes.

The control system will not allow operation at temperatures higher or lower than the established ranges (see section 6.3).

The cooling system does not consume water, so the level should not decrease. If a drop in water level occurs, turn off the equipment immediately and check for leaks.



If you find any water leak, discontinue use and contact the technical assistance service of your official distributor.

If the device overheats, discontinue use and contact the Technical Assistance Service of your official distributor.

---

#### 6.2.6 AIR OUTLET

At the front and rear are the cooling outlets of the equipment; it is recommended that the equipment is not too close to a wall or a surface that impedes good ventilation.

It is recommended that the equipment be at least **1m away from the wall**.



IMPORTANT

**Once the equipment is ready for welding and/or transport is not required, it is essential and mandatory to brake the wheels by using the brakes on the wheels.**

---



## CHAPTER 7 - USE OF THE EQUIPMENT

---

Any user of the LC-WELD PRO equipment must follow the operating and safety steps described in this manual. The operating instructions are essential for the proper use and maintenance of the equipment.

Before using the equipment, as mentioned in the previous chapter, it is necessary to carry out all the necessary checks, summarised below:


- When the equipment is received, it is important not to carry out any action without having read this manual carefully. In case of initial doubts, contact the technical service.
- The equipment should be in an environment with a **reasonable temperature**, suitable temperatures would be **between 10°C and 33°C**.
- Properly connect the equipment to **the mains power supply** with the specified parameters.
- Properly connect the equipment to **a gas bottle or gas supply system** at the indicated flow rate (18-22 L/min).
- Properly connect **the ground clamp to the** work table or the workpiece to be worked on.
- Properly connect the equipment to the **LC-CABIN security system**.
- Check the cooling **water level**.
- At the rear is the cooling outlet of the equipment, it is recommended that the equipment is **not in contact with a wall or a surface** that impedes good ventilation. It is recommended that the equipment is **at least 1m away from the wall**.
- Once the equipment is ready for welding or is not required to be transported, **the wheels** should be **locked** by using the brakes on the wheels.

**This chapter details the different components of the equipment, as well as their function and use.**



## 7.1 GUN: PARTS, COMPONENTS AND OPERATION

Comentado [ML2]: Traducció a l'anglès



To remove the lens protectors, lens and collimator lens, the gun incorporates a tool. This supplied tool located on the back of the laser gun is equipped with a threaded section and another allen type. One m2.5 threaded end to remove the optical drawers, and two others with a 1.5mm and 2mm Allen type tip to release the retaining ring from the protectors or the lens.



In case this part is lost or missing, the following tools can be used:

- Screw with M2.5 thread
- Allen of M1.5 and M2

## 7.1.1 "GROUND" CLAMP

The LC-WELD PRO laser welding unit incorporates a direct contact safety system, similar to the ground clamp used in electric arc welding systems.



However, this clamp is not a mass as such: it does not cause an electric arc, as the LC-WELD PRO laser welding system melts the material by light incision, not by electric arc.



This clamp provides one of the main safety systems incorporated in the LC-WELD laser welding equipment, as the control system does NOT allow the equipment to operate if the welding gun or the welding wire is not in contact with the material to be welded.

The ground clamp must ALWAYS be connected to the workbench or, failing that, to the workpiece if it is too large to be placed on the workbench or has non-conductive parts.

For this purpose, it must be ensured that the welding table to be used or the surface on which the clamp is placed is metallic and conductive, in order to facilitate the correct connection between the clamp and the gun.

The "ground" clamp is connected to the equipment by means of a suitably labelled connector on the rear.

Reference Code No. ( 10103-00030 )

---

#### 7.1.2 QBH

The QBH is the system used to connect the fibre optic head coming out of the laser resonator to the gun. It is a special connector, and must always be properly connected, otherwise the control software will trigger an alarm and will not allow the LC-WELD laser welding equipment to operate.

To connect it correctly, a specific sequence of movements must be carried out (see chapter 11 of MAINTENANCE).

---

#### 7.1.3 STEERING MIRROR SYSTEM

The new technology developed by LC Lasers, the Steering Mirror (SM), consists of a mirror that oscillates between the various axes by means of magnets to guide the laser beam outwards and perform laser welding.




**INFORMATIVE NOTE:** Access to the SM system **is subject to the guarantee of the gun**, and it is therefore **forbidden to** manipulate this access without the authorisation of LC Lasers technical service.



#### 7.1.4 FOCAL LENS

Located before the lens protector, its function is to concentrate the light beam coming from the collimator in an "hourglass" shape.



The focal point is the place where the power of the laser beam is most concentrated, and therefore the optimum point for welding. Therefore: always make sure that the point of incision of the laser in the material coincides with the focal point, for maximum effectiveness of the laser beam.

To find the focal length see POINT 7.5 .

The lens is housed inside a drawer on the top of the gun, marked with a letter L.



Use the tool supplied with the gun to loosen the drawer. If this part is lost or missing, the following tools can be used:

- Screw with M2.5 thread
- Allen of M1.5 and M2



The drawer that houses the lens is secured with a stud bolt inside, which holds the protector in place, and features a hole that makes it easy to engage and disengage the drawer. To remove the drawers, use the threaded part of the tool to pull them out. Carefully remove the drawer from the hole and, using the tool provided, unscrew the stud bolt. This will release the lens from the drawer, allowing you to change the lens. To change the lens, the metal ring above the lens must also be removed.

Once you have placed the new guard on the drawer, replace the ring and fix it again with the stud bolt. Place the drawer back into its corresponding hole and fit it into the gun. The drawers have a magnet part which makes them easier to fix.

LC reference code: 11001-00002

#### 7.1.5 SIRGA


The line, coming from the feeder, consists of a rubber sheath and a \*graphite\* line inside.

At the end, the rope should protrude about 20cm more than the rubber sheath.

For wire-feed welding, the wire rope must be attached to the wire-feed fitting supplied by LC in the enclosed accessory box.

#### 7.1.6 LENS PROTECTORS

Lens protectors are one of the consumable parts of the LC-WELD laser welding equipment. There are two lens protectors housed in two drawers on the top of the gun.



Comentado [ML3]: Traducció a l'anglès



The protectors are housed in the two drawers marked with the letter P.

This shield, as its name suggests, is specially designed to allow the laser beam to pass outwards and not inwards, when it comes from bounce or refraction.

This protects the lens from possible pitting and damage caused by rebound or refraction and also from possible micro projections that could settle on the lens itself.

The lens protector should always be kept as clean as possible, checked periodically and replaced if necessary.

The lens protectors for this gun are located in two removable drawers on the top of the gun.

Reference Code No. 11001-00003.



The lens protector can be accessed with the special tool supplied.

For more information on handling the lens protector and replacing it, see section 12.3.1 of this manual.

Use the tool supplied with the gun to loosen the drawer. If this part is lost or not available, the following tools can be used:

- Screw with M2.5 thread
- Allen M1.5 and M2

The drawer that houses the protectors is secured with a stud screw inside, which holds the protector in place, and has a hole that makes it easy to attach and detach the drawer. To remove the drawers, use the threaded part of the tool to remove them. Carefully



remove the drawer from the hole and, using the tool provided, unscrew the stud screw. This will release the lens protector from the drawer, allowing you to make the change. To change the protector, you must also remove the metal ring placed on top of the protector.

Once you have placed the new protector in the drawer, replace the ring and secure it again with the stud screw. Place the drawer back into its corresponding hole and attach it to the gun. The drawers have a magnet part that makes them easy to fix.

---

#### 7.1.7 GAS IN THE GUN


The gas enters at the rear of the gun where the driver is located and through a fitting it reaches the tip of the gun to supply gas for welding.

---

#### 7.1.8 WELDING PIPE

This is the metal tube marked with millimetres. This tube allows the laser beam and shielding gas to exit and also houses the nozzle at the outermost end of the tube.

The tube is equipped with a threaded fastening for easy removal and fixing.




The millimetre markings on the tube will help to find the focal length of our laser welding equipment (SEE ITEM 7.5).

---

#### 7.1.9 COLLIMATOR LENS

In the pistol grip there is a drawer with the collimator lens. This lens concentrates the laser beam coming from the source to the focal lens of the gun.



The collimator lens is fitted inside the next drawer with the letter C that is fixed with a screw:



This lens is surrounded by a metal ring as the lens protector and the lens.

#### 7.1.10 NOZZLES

The nozzles are the element that will provide direct contact with the welding material or filler wire.

They are considered as positioners, as they provide comfort and the correct positioning of the gun in different types of welding, with or without material contribution (welding wire).

The material of these nozzles is copper with a nickel plating to ensure maximum strength and durability.


There are different shapes, which are divided into nozzles for work **WITH** material **supply** and nozzles for work **WITHOUT** material **supply**:



### 7.1.10.1 GROOVED NOZZLES FOR WELDING WITH MATERIAL SUPPLY

There are 4 sizes for the 4 welding wire diameters compatible with the LC-WELD laser welding equipment: 0.8mm, 1mm, 1.2mm and 1.6mm. See point 9.2 for 'Choice of welding nozzles'.

LC reference codes:

10901-00110	Nozzle FE Closed 0,8" nozzle	
10901-00111	Nozzle FE Closed 1,0" input	
10901-00112	Nozzle FE Closed 1,2" (1.2")	
10901-00113	Nozzle FE Closed 1,6" nozzle	
10901-00114	Nozzle AL Open 0,8" input	
10901-00115	Nozzle AL Open 1.0" input	
10901-00116	Nozzle AL Open 1,2" input	



10901-00117

Nozzle AL Open 1.6"  
input

These nozzles have a machined channel through which the wire will be guided in the direction of the laser beam, thus favouring the rigidity and centring of the wire. Each size has a channel of a different width for the different wire diameters allowed.

#### 7.1.10.2 NOZZLES FOR WORK WITHOUT MATERIAL INPUT:

- **Short fork for flat welds and inside corners without material input.**

Its design facilitates the work on butt welds. The space in the middle facilitates the passage of any welding points made for the first clamping of the workpiece in its optimum position.

It usually requires a guide to make welds as straight as possible.

- **Long fork for welding outside corners without material input.**

Its design makes it easy to work on outside corner welds.

The larger space between the two tips allows the corner to pass optimally inside the nozzle, making it easier to position in this type of welding.

10901-00118

Short inner SA nozzle



10901-00119

Long outer SA nozzle





### 7.1.9.3 NOZZLES FOR WASHING

With the same welding equipment, laser cleaning work can be carried out.

To carry out laser cleaning work, we must use the part of the software prepared to configure the cleaning parameters (see point 8.4.1.1.1 CLEANING AND DOTTING).

The nozzles to be used for laser cleaning work are the SHORT INSIDE SA NOZZLE (10901-00118).

## 7.2 ROLLERS

The welding wire feeder has different types of rollers:

**For aluminium :**


NAME	LC REFERENCE	REPRESENTATIVE IMAGE
Aluminium kit 0.8/1.0	10701-00022	
Aluminium kit 1.2/1.6	10701-00023	

**For ferritics:**

NAME	LC REFERENCE	REPRESENTATIVE IMAGE
------	--------------	----------------------



0.8 and 1.0" smooth ribbed bottom rollers	10701-00052	
1.2 and 1.6" smooth ribbed bottom rollers	10701-00053	

NAME	LC REFERENCE	REPRESENTATIVE IMAGE
Non-ribbed top rollers without teeth (all diameters)	10701-00033	

### 7.3 SWITCHING THE EQUIPMENT ON AND OFF

In order to switch on the LC-WELD PRO laser welding device correctly, the following steps must be followed:

1. Make sure that all connections have been made for proper installation (see Chapter 6):
  - a) Electrical connection
  - b) Connection to gas supply
  - c) Connection of the ground clamp
  - d) Connection of the safety system LC-CABIN
2. Make sure that the doors of the LC-CABIN are properly closed and secured.
3. Make sure that the red emergency switch is not tripped. If it is tripped, turn it clockwise to release it.
4. Activate the disconnecter located at the rear of the equipment by turning it clockwise.
5. Turn the key switch on the front of the unit clockwise to the ON position.
6. The display will become active. Wait for the CPU of the system controller to become fully active (approximately 50 seconds).
7. Enter your username and password to access the equipment control system.
8. Once in the options menu, select 'START'. Activate the chiller and the laser resonator.
9. As soon as the green "system ready" indicator appears, the device is ready for use.



IMPORTANT

Before switching on the equipment, make sure that the emergency switch (mushroom) is released, otherwise the equipment will not switch on.



IMPORTANT

Before operating the LC-WELD laser welding equipment, we must wait for the control software to indicate that the system is ready by means of the "system ready" indicator.

**DANGER**

All electrical connections must be connected before applying power to the unit.

**DANGER**

Ensure that all persons around operating laser equipment wear personal protective equipment (PPE) while in use. This includes specified laser safety glasses, mask, gloves, welding clothing.

- Ensure that all power is removed from the laser when handling the fibre cable. The minimum bend radius allowed is 150mm.


To switch off the LC-WELD PRO laser welding device, simply follow the above steps in reverse order:

1. Turn the key anticlockwise.
2. Deactivate the disconnecter at the rear of the unit by turning it anticlockwise.
3. Shut off the gas system to avoid possible leaks.

#### 7.4 SWITCHING THE GUN ON AND OFF

The laser gun is activated with the button on the top of the gun handle (trigger). When the trigger is pulled, if everything is in proper working order and the tip of the gun is in contact with the workpiece or welding material, the laser beam will be emitted to work.

It is intended to be activated with the gun held firmly in the preferred hand and by pressing with the index finger. Ignition will not occur if the gun is not in contact with the material.

**DANGER**

It is forbidden to operate the gun without being in contact with the material or the welding table.

It is **TOTALLY FORBIDDEN** to use the mass directly in the welding gun.

In welding mode, without making contact with the ground, if the trigger is pressed, the welding wire will come out at the programmed welding speed.

**Precautions:**

- Correct use of the dough is mandatory.
- The gun must never be operated if it is not in contact with the material.

**DANGER**

It is mandatory to aim the gun correctly in the direction of the material to be processed.


Never point the gun in the direction of people, objects and/or animals.

**7.5 FOCAL LENGTH**




As previously mentioned, the laser beam emerges from the collimator as a uniform, parallel beam. The main function of the lens is to concentrate this beam into a tiny spot, similar to the shape of an hourglass.

The central point of this 'hourglass' pattern is where the beam energy is maximally concentrated. Adjusting the laser and gas output tube is essential to ensure that this point coincides with the welding point, thus guaranteeing optimum energy input for the welding process.



The focal length, which determines this welding point, is usually located at approximately at 150 mm from the lens, although this measurement may vary.



Each of our devices comes with a quality control certificate detailing the factory focal length obtained during the quality control.



This focal length shall be adjusted only by using the measuring scale engraved on the threaded tube of the gun tip.



The different nozzles have been designed to maintain the correct distance and adjust to the set focal length. Once the focal length has been defined, the nozzles can be interchanged according to the type of work to be carried out, without the need to make additional adjustments in relation to the focal length.



**IMPORTANT**

**It is important to note that the focal length may change over time due to various factors. If a change in focal length is detected or difficulties in finding the focal length are encountered, it is essential to contact the Technical Support Service of the official distributor.**

#### 7.5.1 CALCULATION OF THE FOCAL LENGTH

Since the focal length can vary, it is essential to have an easy and objective method to find it. To do so, follow the steps described below and use the tools designed for this purpose:

- Focal length functionality of our equipment.
- Sample test tube where it can be checked the power of the laser beam.

**Step 1:** Access the specific functionality for the calculation of the focal length. It is located in the WORK menu.



AVANZADO



BÁSICO



CALIBRACIÓN



DISTANCIA FOCAL

**Step 2:** Prepare the test pieces intended for calculating the focal length or, failing that, a 1.5mm thick aluminum plate on which the laser can be shot. In this way, the correct laser beam power at the appropriate focal length can be checked and found. On this plate the different points will be made at different length settings (-12mm to +12mm) and then the power of the laser will be checked.

**DISTANCE FOCAL**

-12 mm	_____
-10 mm	_____
-8 mm	_____
-6 mm	_____
-4 mm	_____
-2 mm	_____
0 mm	_____
2 mm	_____
4 mm	_____
6 mm	_____
8 mm	_____
10 mm	_____
12 mm	_____




**IMPORTANT**

It is essential to use an ALUMINIUM sample for the calculation of the focal length, as this material provides more reliable results due to its properties.

**Step 3:** Once you are ready to weld, start the procedure through the program by pressing the START button on the screen.




The procedure shall consist of a series of **predefined shots at different focal positions**. The equipment will indicate on the square of the screen the position of the threaded tube (-12mm, -10mm, -8mm, etc.) which the user must adjust before each shot.



When all is ready, fire in the appropriate box of the flask being used.

Once the procedure is completed, a shot scale will be obtained which will facilitate the deduction of the focal length. This will be achieved by observing and analysing the results obtained as can be seen in the example below:



**Step 4:** Once the optimal focal length has been determined through the procedure described above, it is crucial to assemble and adjust all components of the welding equipment according to these results.




Once the optimal focal length has been determined through the procedure described above, it is crucial to assemble and adjust all the components of the welding equipment according to the results obtained.

This step will ensure that the welding is done accurately and effectively, making the most of the focal length settings for optimal results.

With this focal length system, the focal length will not vary when changing nozzles since the shape of the nozzles has been adapted to do so. The configuration allows the nozzles to be replaced depending on the type of welding to be carried out without changing the position of the laser output tube because the dimensions of the nozzles automatically compensate for this variation, allowing you to always work with the correct focal length.

## 7.6 POSITIONING

In order to weld correctly with the LC-WELD laser welding equipment, we must maintain a specific position in relation to the area to be welded.



For flat welds, the gun handle must be kept parallel to the weld bead to prevent the laser beam from bouncing back into the laser and gas outlet tube, which could damage the lens protector and the different optical elements of the gun.



For welding inside corners, the gun must be kept parallel to the weld bead, but the position must also be maintained at 45° to the horizontal axis.

For welds in external corners, the principle is the same: and also, always seek to impact half of the angle described by the two parts.



IMPORTANT

**It is recommended to keep the handle flat and parallel to the material for proper welding.**



IMPORTANT

**It is VERY IMPORTANT to maintain the position throughout the welding process, taking care NOT to VARY the angle or direction of the gun, so as not to adversely affect the result.**

## 7.7 WELDING

The LC-WELD PRO laser welding unit can weld with or without material input. When welding WITH welding material, the welding is carried out with standard welding wire of the desired material (see section 3.4.1).

In the case of NO filler welds, the surfaces to be welded are melted so that they are joined together without the addition of extra material.

### 7.7.1 WELDING WITH MATERIAL CONTRIBUTION

In CON welding, the surfaces to be welded are melted together and material is added to fill small gaps or spaces.

There are only two types of nozzles available for the welding with filler wire, for welding in all positions and for welding in the outside corner. There are 4 different sizes of nozzles to choose from, one for each wire diameter, 0.8, 1, 1.2, 1.6. The nozzles are grooved nozzles, and the groove is used to guide the wire towards the centre of the laser beam.

The final quality of the laser weld depends significantly on an adequate wire thrust. The particularity of this method is that the gun directs and defines the welding speed, generating regular and precise beads.



Problems with wire feed can result in no wire feed or irregular movements, causing defective and unaesthetic welds.

These problems often occur with specific materials such as aluminium and 1.6 mm ferritic materials over long distances or in awkward positions.

---

#### 7.7.1.1 THREAD SETTINGS

In order to operate the LC-WELD PRO laser welding machine with material feed, a welding nozzle must first be installed, choosing a size that is compatible with the diameter of the welding wire to be used.

The nozzle must be positioned with the channel at the bottom, where the welding wire will exit, in order to guide it correctly.

---

#### 7.7.1.2 INSTALLATION AND CONNECTION OF THE WIRE FEEDER

To use the wire feeder supplied with the LC-WELD laser welding equipment, the wire rope must first be installed.

The wire rope has a standard MIG-MAG type wire feeder connector at one end. This connector must be inserted in the correct position (front of the wire feeder) and screwed in completely.

To connect the feeder to the equipment, simply connect the cable provided from the back of the feeder to the back of the equipment.

To finish, place the spool of welding wire on the feeder shaft, tighten the spool clamp, take the tip of the wire and feed it through the wire guide into the rollers. Make sure that the wire passes through all tubes and holes. When the end of the thread is already inside the towline, lower and lock the pressers, adjusting the pressure if necessary (recommended pressure = 2).

Make sure that the feeder switch is in the ON position (I), and the equipment is switched on and with an active user.

By pressing the button "▲" continuously, the wire will advance rapidly. Keep it pressed until the welding wire comes out of the tip of the wire rope.

Once the thread comes out of the end of the hose, insert it into the pipe of the fitting until the hose is fixed with the quick release coupling.



#### IMPORTANT

**If you place the wire rope in the hose before the wire is completely passed through, the wire may get caught in the metal tip, in which case the welding wire may wrinkle at the feeder outlet.**



IMPORTANT

**It is compulsory to change the thread spool and/or the rollers with the machine OFF.**

#### 7.7.1.3 CONNECTING THE FEEDER TO THE GUN

In order to connect the wire feeder to the gun, the line supplied with the equipment must be connected to the power supply by means of a quick-connect fitting.

Once the welding wire has been inserted, a metal tip compatible with the wire diameter chosen must be selected and screwed onto the tip of the feed pipe.



The welding fixture is attached to the gun by fitting it to the outside of the laser and gas outlet tube by means of a snap ring and tightening it with a hexagonal screw.

#### 7.7.1.4 STEP-BY-STEP THREAD ADJUSTMENTS

The thread pusher system basically consists of 4 parts which we will describe below:

- **Coil**
- **Motor:** consists of 4 drive rollers for aluminium and 2 for other materials, with an encoder that adjusts the power to maintain the set speed.
- **Sleeve:** allows the thread to be guided to the gun.
- **Gun application:** This system allows the wire to be guided and acts as a junction between the sheath and the welding nozzle channel.

The method for adjusting and/or verifying step-by-step all components of the thread-pusher system is as follows:


- 1- **Motor:** the correct roller pressure is 2, and this should be sufficient for any material and with a maximum length of 4 metres.

It is not possible to have any thread rubbing problems before this element.

**IMPORTANT**

**It is essential to assemble the aluminium kit with the 4 traction rollers to guarantee a good push of the aluminium wire.**

- 2- **Sleeve:** Visual check of the yarn sleeve, which should be visible from the inside of the winder and should be as close as possible to the rollers (without rubbing against them).

**IMPORTANT**

**In case of any problems with the thread's contribution, this is a key inspection point that will allow us to easily rule out problems.**



It is not recommended in any case to exceed a distance of 4 metres (and it is recommended to reduce this distance if using wires with a diameter of 1 mm or less).

The inside of the sheath may not have any problems with the wire, although the wire may rub more or less on the inside of the sheath depending on its diameter, the length of the wire and the welding positions.

- 3- **Spray gun application:** this is the part where there are usually the most problems with rubbing and which requires the most precision in the adjustment.



The appliqué must be correctly adjusted to allow the thread to pass through the channel without excessive rubbing. As a check, the thread should be parallel to the channel, otherwise the thread will rub excessively against the inlet or outlet edges of the channel and this may cause thrust problems.


To adjust this fixture, loosen the large screw on the side of the fixture, put the gun in a comfortable position that allows you to see the position of the thread at the same time, adjust/move the fixture and tighten the screw.

This is usually done with the gun face up on a table, and if there is no table at the welding site between the legs face up.



Once we have correctly positioned the applique and the thread is correctly centred in the channel, we can proceed to tighten the screw again and make a final check to make sure that the thread is correctly adjusted.

The thread should be easy to move with the fingers and if not, it should be re-tightened.



IMPORTANT

**Performing this check regularly is key to ensuring good wire pull. Remember that wire rubbing may depend on the welding position, and the wire may be hot during welding!**

In conclusion, these are the important points of this process:

- **Recommended roller pressure: 2**
- In case of aluminium, use U-grooved rollers and connection kit with upper drive rollers.
- **Visual inspection of the sheath:** the yarn sheath should be visible coming out of the rope inside the winder: this will allow us in case of problems to make a quick visual inspection and rule out some problems.
- **Precise adjustment of the thread passage through the feed nozzle channel and subsequent verification after adjustment**

#### 7.7.1.5 OPERATION

To operate the LC-WELD laser welding equipment with wire feed, you must centre the wire and nozzle, and ensure that the wire is seated in the existing channel in the nozzle.

The thread must be cut so that the tip coincides with the red pointer and, if this does not coincide exactly with the thread, move the pointer with the target located on the

parameterization screen by pressing the icon  and moving the pointer sideways to make them coincide.

**DANGER****Never fire WITHOUT THE PRESENCE OF THE RED DOT.**

Once these steps are completed, the gun is ready for operation.

When welding with filler, we must ensure that the tip of the welding wire makes contact with the welding shaft, but not the nozzle or the welding wire outlet tube.

The ideal positioning of the gun must be observed (section 7.6).

Once correctly positioned, press the gun power button (trigger).

When the equipment starts welding, you will notice that the wire, as it exits the wire feeder and feed tube, **pushes** the gun backwards. It is **VERY IMPORTANT** to follow this push while pressing lightly in the direction of the welding axis to ensure a uniform result.

**IMPORTANT**

**Unlike other conventional types of welding, with LC-WELD PRO manual laser welding, it is the machine that controls the welding, not the operator: with the same set-up, if the position and thrust tracking requirements are met, anyone can weld the same weld bead, regardless of the welder's technique or experience.**

#### 7.7.1.6 FEEDER CONFIGURATION TIPS AND PARAMETERS

Manual laser welding WITH wire feed is very easy to operate, just follow some of the tips below:

- To end a welding seam, a specific gesture must be made, raising or lowering the gun, depending on the type of work carried out, a few thousandths of a second after releasing the gun activation button (trigger), to prevent the wire from sticking to the gun.
- If the welding wire sticks to the welding bead, simply focus the red pointer on the tip of the welding wire and fire a short shot while pulling the gun.
- Apply light pressure in the direction of the welding shaft to guide the wire into position and force it to push the weld.
- It is recommended to make use of the 'Burn Out' parameter.

#### 7.7.1.7 TROUBLESHOOTING THREAD THRUST PROBLEMS

**Rope exit cover:**



The occurrence of this problem probably indicates significant fretting somewhere in the system that has not been resolved. In attempting to remedy this, the increased pressure on the pusher rollers may have caused other problems. In addition, it is possible that it is the result of an incorrect fit in the part that holds the thread sheath to the towline.

**Presence of aluminium dust as the wire advances:**

This phenomenon indicates excessive friction between the yarn and the nozzle, usually caused by an incorrect angle of the yarn to the nozzle channel.


**Thread feed problems:**

If the thread does not advance correctly, there are a number of steps to follow to identify the source of the problem:

- verify that the pusher rollers do not slip and are able to push the yarn properly
- Check that there is no excessive friction in the passage of the wire through the welding nozzle channel.
- Make sure that the thread sheath has not come out of the line.
- If all these factors are correct, check the welding positions to avoid excessive wire friction on the sheath.

**Thread jammed when tightening the appliqué:**

If the wire sticks when tightening the clamp screw, it is likely that by over-tightening, the wire is crushed excessively against the welding nozzle channel. To remedy this, either loosen the wire slightly by hand or readjust the clamp by loosening and retightening the screw with the appropriate tool.

**IMPORTANT**

**The position of the appliqué must be firm so as not to impair the completion of the weld when attempting to exit the weld.**



IMPORTANT

**If a good thrust is not achieved, and always as a last resort, nozzles with a larger diameter than the thread used can be used.**



IMPORTANT

**Working with 0.8 mm aluminium wire can be problematic: it is advisable to shorten the length of the line as much as possible and to adapt a sheath for a better experience.**

### 7.7.2 WELDING WITHOUT MATERIAL SUPPLY

In fillerless welding, the surfaces to be welded are melted so that they are joined together without adding any extra material. For this type of welding, the parts must be very well positioned: they must touch each other perfectly and not leave any empty space.

#### 7.7.2.1 NOZZLES AND THEIR APPLICATION

The LC-WELD laser welding unit has several nozzles as described above:

- Short fork for flat welds without material input.

Its design makes it easy to work on butt welds. The space in the middle facilitates the passage of any welding points made for the first clamping of the workpiece in its optimum position.

It usually requires a guide to make welds as straight as possible.



- Long fork for welding outside corners without material input. Its design makes it easy to work on outside corner welds.



The larger space between the two tips allows the corner to pass optimally through the inside of the nozzle, making it easier to position in this type of welding.



---

#### 7.7.2.2 ADJUSTMENT

For non-contributory welding, the equipment must be properly prepared:

- Remove the appliqué for the yarn supply.
- Change the nozzle to a nozzle for non-additive welding, depending on the work to be carried out.
- Adjust the focal length if necessary, threading the tube in or out as appropriate (see section 7.5).
- Position the nozzle and then lock the rotation of the tube with the locknut on the laser and gas outlet tube itself.

---

#### 7.7.2.3 OPERATION

To operate the LC-WELD laser welding equipment for welding without material input, simply ensure that the nozzle is in contact with the material or parts to be welded, and press the activation button. Remember the positioning of the gun: always maintain an inclination of +/- 60°, to avoid direct bouncing of the laser beam into the laser and gas outlet tube, which could quickly damage the lens protector.

---

#### 7.7.2.4 TIPS AND PARAMETERS

The LC-WELD laser welding machine requires a constant welding speed:

We advise you to first choose a speed at which you are comfortable to move steadily, and then set the parameters for power, frequency and so on to suit the chosen speed.

You can also modulate the thickness of the weld seam, if you wish, via the parameterisation screen, using the "gauge width" tab.

By maintaining a stable position and speed, a high uniformity of results can be ensured.



## CHAPTER 8 - SOFTWARE

---

The LC WELD PRO software is specifically designed by LC for manual laser welding.


The software of the LC-WELD PRO laser welding unit allows, among other functions:

- Parameterise the equipment in different ways.
- Create different levels of users and permissions.
- Create welding profiles.
- Create and execute jobs (tasks).
- Assign jobs to user groups.
- Control all elements of the equipment from a single screen.
- Control the equipment remotely.
- Create highly detailed cost statistics.

The following is a detailed explanation of how the software works, its different functionalities and programming.

### 8.1 STARTING THE SOFTWARE

Once the equipment has been switched on correctly (see section 7.3), a green screen with two tabs will appear on the display:



- The user can be selected via the top tab using the right or left arrows.
- By clicking on the lower tab, a keyboard will appear, which can be used to enter the password of the selected user.

The software starts by default with the user **ADMIN**, whose default password is **1**.

If desired, once logged in, new users can be created from an administrator account (see section 8.3 USERS).

Through the USERS section, access can be given to different users with different permissions.

---

#### 8.1.1 GENERAL SOFTWARE BUTTONS

- Menu button.



On different screens the menu icon appears, a button that allows us to return to the previous menu of the screen where we are.

- Flecha hacia atrás.



The 'back arrow' button appears in the software and is used to return to the previous screen where we are.

- Calibration button.





It is used to center the red pointer on the inner diameter of the gun tube, as well as center it with the welding wire.

- Selection of options in tables.

Information appears in table format on different screens of the software. To select the desired option from the table, you must click on the left side of the desired line of the tables, right where the arrow indicates and then the GO button

	GROUP	OPER 1	OPER 2	OPER 3	OPER 4	OPER 5	OPER 6

### 8.1.2 MAIN MENU

Once you have selected the user and entered your password, you will have access to the main menu screen.

The main screen of the software is a general menu of functionalities.

It should be noted that, depending on the user's permissions, he/she will have access to some functionalities or others.


The description of each functionality shall detail which type of users will have access to it.

The total functionalities available in the main menu of the "ADMIN" and "MANAGER" users are as follows:

- HOME
- WORK
- JOBS
- CONFIGURATION (CONFIG)
- HELP
- USERS
- ALARMS




- STATISTICS



The total functionalities available in the main menu for "OPERATOR" users are as follows:

- START
- WORK
- HELP
- ALARMS
- LANGUAGE



## 8.2 START




The first menu item is START.


This option is accessible to all users.

This screen is the only way to activate the laser resonator and the cooler. It is necessary to activate both options to start operating the equipment.

To activate the cooler and the laser resonator, the two buttons on the left side of the screen must be selected.



As soon as both the cooler and the laser resonator are activated, the current temperature of the cooling system will be displayed on the right-hand side of the screen.



To start using the equipment, the water temperature must be between 24°C minimum and 29°C maximum.



### SYSTEM READY



The "SYSTEM READY" indicator indicates when the system is **ready** to start working. When **everything is correct** (resonator and cooler are on and at the correct temperature, gas is open and the safety system is correctly activated), the "SYSTEM READY" indicator will turn **green**.

The "System Ready" indicator is present on various screens of the software.



### IMPORTANT

**If the water is outside the set temperature ranges, the system does not detect the presence of pressurised gas, or the LC-CABIN safety system (optional) is not properly closed and activated, the "SYSTEM READY" indicator will not turn green, so the system would not be ready for operation.**

## 8.3 USERS




The USERS menu allows the ADMIN and MANAGER level profiles to manage the users registered in the system.

Click on the USERS icon to access a menu with three options:

#### USERS

- Management (Administrator access only)
- Session
- History





### 8.3.1 MANAGEMENT



Pressing "MANAGEMENT" opens a screen with the list of existing users in the system.

This same screen can be used to create or delete users.

#### MANAGEMENT

- To create a new user, simply enter a name and password on the right-hand side of the screen, select the level you wish to assign, and then click "NEW". New users can be of "OPERATOR" or "MANAGER" level. OPERATOR users have limited functions available, while the MANAGER user has almost all functions available, except user management.
- To delete a user, select the user and click on delete.

\*It should be noted that a user cannot be deleted if he/she is included in a group; the user must first be deleted from the group(s) to which he/she is assigned.

\*The equipment is delivered with a single ADMIN level user. The **default password is 1**.

NAME	PASSW	DATE	LEVEL

NAME:

PASSWORD:

LEVEL:

DELETE

NEW

### 8.3.2 SESSIONS




#### SESSIONS

By going to the "SESSIONS" section, you can access a list of details about the sessions started in the equipment.

This list details information such as:







#### 8.4.1 SYNERGIC



The "SYNERGIC" option allows you to work synergistically with previously configured parameters.

Once in "SYNERGIC" mode, a menu will appear with several options:

- THICKNESS
- MATERIAL
- POSITION
- CONTRIBUTION
- THREAD (SUBJECT TO "CONTROL")





Through the different options, you must choose the characteristics of the welding you are going to perform. With this information, the system automatically configures the necessary parameters.

**Parameters to select and their meaning:**

<b>THICKNESS</b>	<p>This is the thickness of the sheet metal to be welded. The options allow you to select different millimeters depending on the thickness to be worked.</p> <p><b>AVAILABLE OPTIONS: 0.8 - 1 - 1.2 - 1.5 - 2 - 3 and 4.</b></p> <p>All expressed in millimeters (mm).</p>
<b>MATERIAL</b>	<p>Material of the sheet metal to be worked.</p> <p><b>AVAILABLE OPTIONS: Carbon steel, stainless steel, titanium, galvanized and aluminum.</b></p>
<b>POSITION</b>	<p>Position in which the weld will be performed.</p> <p>A distinction is made between "FLAT" welds and other positions (OTHER).</p> <p>"FLAT" welds will be considered with full penetration.</p>
<b>CONTRIBUTION</b>	<p>It is possible to select whether the welding will be carried out WITH or WITHOUT wire feed.</p> <p><b>OPTIONS AVAILABLE: YES, NO</b></p> <p>Select YES to work with input, select NO to work without input.</p>
<b>THREAD</b>	<p>This option will only be available if the previous option is affirmative, i.e. if the welding option WITH wire feed has been selected.</p> <p>In this option the diameter of the wire to be used is determined.</p> <p>The options are subject to the thickness of the sheet metal: the use of a wire with a diameter greater than the thickness of the selected sheet metal will never be permitted.</p> <p><b>AVAILABLE OPTIONS: 0.8/1/1.2/1.6 mm.</b></p>




Once all the options are configured, simply click on the "START" icon to access the welding screen (see section 8.4.3).

In this same "SYNERGIC" menu, on the right side, you can find two options: EDIT and COMMONS.





On the COMMON screen you can view the following welding parameters grouped into: GENERAL, FEEDER and CLEANING.

Below are the settings included in each function in the left menu:



The "GAS" option is a manual activation of the electromagnetic valve, designed to perform a purge of the gas system.






The "PREVIEW" option allows you to preview the weld painting (LINE), designed to check its width.


**See section 8.4.2.3 for a detailed explanation of CLEANING parameters.**

Using the EDIT option, the following predefined settings can be viewed and configured when selecting the SYNERGIC options:



- LASER: power, frequency, duty cycle, start/end ramp time
- SCAN: shape, frequency, width and PREVIEW
- FEEDER: forward speed, delay.
- POINT

Below are the settings included in each function in the left menu:





The "PREVIEW" option allows you to preview the weld painting (LINE), designed to check its width.






Refer to section 8.4.2.3 for a detailed explanation of TACK parameters.

These options are the same as those in the existing screen in the "MANUAL" work menu (see section 8.4.2).


On the same edit page, you can change the desired settings. Once you have adjusted the settings to your preference, press "SAVE".



In this case, these settings will be saved corresponding to the combination of options chosen on the first screen of SYNERGIC mode.

The next time this same combination of options is chosen, the previously saved modified settings will be configured using the EDIT menu.

Within the EDIT screen, the option to revert to factory settings is offered by pressing this icon:




This way the settings are restored to default.




As in the rest of the screens, using the START option you will access the welding screen to start working.

In the SYNERGIC-EDIT screen, settings can be saved to create profiles for advanced mode:



On this screen you can insert a work profile name to save the selected settings.




#### 8.4.2 MANUAL MODE



Using this working mode, the user has complete freedom of settings. This option allows creating new WORK PROFILES, editing existing ones, working with the desired WORK PROFILE, or working with complete freedom of settings.

MANUELLE




Navigating between WORK PROFILES, by changing profiles, will change the settings displayed on the screen.

Access to the welding screen to work.

Settings for cleaning and spot welding.

Once in "MANUAL" mode, a menu with several welding operation setting options will appear on the left side of the screen. These are grouped into LASER, SCAN, FEEDER and GAS.

Below is an explanation of the parameters that can be found:



**LASER**

<p><b>LASER POWER</b></p>	<p>Laser power delivered to the weld. Expressed as a percentage (%). Power is one of the most determining parameters for energy efficiency.</p>
<p><b>LASER FREQUENCY</b></p>	<p>Laser emission frequency. Expressed in Hertz (Hz) The frequency is determined by the material we are welding:</p> <ul style="list-style-type: none"> <li>• <b>Ferrous materials: 20,000Hz</b></li> <li>• <b>Aluminum: 50 Hz</b></li> </ul>
<p><b>LASER WORKING CYCLE</b></p>	<p>Time during which the resonator emits laser radiation within one Hertz of laser emission. Expressed as a percentage (%) The duty cycle is determined by the material to be welded:</p> <ul style="list-style-type: none"> <li>• <b>Ferrous materials: 80%.</b></li> <li>• <b>Aluminum: 100%.</b></li> </ul>
<p><b>BURN OUT</b></p>	<p>This parameter allows to program the wire feed stop separately from the laser stop, i.e. the wire feed ends first, then the laser beam turns off. It allows you to configure the duration for which the laser beam remains on after the wire feed has stopped. It is expressed in milliseconds (ms). This parameter is used to obtain a better weld finish. The recommended programming time is approximately 500 ms. THIS PARAMETER IS COMPARABLE TO WHAT IS KNOWN AS "BURNBACK".</p>

Tabla con formato

Con formato: Izquierda

Con formato: Párrafo de lista, Izquierda, Con viñetas + Nivel: 1 + Alineación: 0,63 cm + Sangría: 1,27 cm

Con formato: Párrafo de lista, Izquierda, Con viñetas + Nivel: 1 + Alineación: 0,63 cm + Sangría: 1,27 cm

Con formato: Izquierda




**RAMP START TIME**

These two parameters indicate the time for progressive increase (START) or reduction (END) of the laser power.

**RAMP END TIME**

**IMPORTANT: If you are working with wire feed, only the start ramp is operational, not the end ramp.**



**SCANNING**

<b>SCANNING</b>	<p><b>Shape</b> which will draw the galvanometric mirror system of the gun during welding.</p> <p>This parameter could be compared to the combing of welds carried out in conventional welding.</p>
<b>FREQUENCY OF FORM</b>	<p><b>Frequency of hair styling.</b> It is expressed in Hertz (Hz). To put it simply, this is the speed at which the weld combing should be done.</p>
<b>LINE WIDTH</b>	<p><b>Size or width</b> that the shape of the LINE will have. It is expressed in millimeters (mm).</p>


Tabla con formato

Con formato: Normal, Sin viñetas ni numeración

Con formato: Normal, Sin viñetas ni numeración

Con formato: Francés (Francia)

The "PREVIEW" option allows you to preview the weld painting (LINE), designed to check its width.



**FEEDER**


<p><b>FEEDER ADVANCE SPEED</b></p>	<p>Speed at which the welding wire will advance during welding. It is expressed in millimeters per minute (mm/min).</p> <div style="border: 1px solid black; padding: 5px; text-align: center;">   <b>IMPORTANT</b> </div> <p><b>It should be remembered that the wire feed speed (FEEDER ADVANCE) will be the weld feed speed, as explained in section "7.6.1.5 Operation" of this manual.</b></p>
<p><b>REAR FEEDER SPEED</b></p>	<p>Speed at which the welding wire will recoil once the weld is complete. It is expressed in millimeters per minute (mm/min).</p>
<p><b>DELAY</b></p>	<p>Time required for the power wire to come out after the laser is activated.</p>
<p><b>DISTANCE SETBACK</b></p>	<p>The distance the wire will retract after welding is complete. It is expressed in millimeters (mm).</p>
<p><b>COMPENSATION</b></p>	<p>Length of feed wire returned at the end of the welding job.</p>
<p><b>RETURN SPEED</b></p>	<p>Speed at which the wire feed returns at the end of the welding job.</p>
<p><b>RETURN TIME</b></p>	<p>Waiting time before the wire returns at the end of the welding job.</p>
<p><b>SELECTOR "START ON"</b></p>	<p>Enable or disable wire feed within the welding profile.</p> <ul style="list-style-type: none"> <li>If the box is NOT checked (☐), the reel motor will not be activated at any time during work.</li> </ul>

Tabla con formato

Con formato: Izquierda

Con formato: Izquierda, Espacio Antes: 5 pts

Con formato: Fuente: Sin Negrita, Francés (Francia)

Con formato: Fuente: Sin Negrita

Con formato: Izquierda

Con formato: Izquierda

Con formato: Izquierda



**“ADVANCE”  
SELECTOR AND “ACTIVATE  
RETURN”**


- If the YES box contains a check mark (✓), YES the wire feed motor will be activated while working.

This parameter can be divided into two functions:

- If the “ADVANCE” selector is NOT checked (✓): During the programmed time, the laser beam will be emitted but the feed motor will not be activated. This function is intended to preheat certain materials before starting the welding bead.
- If the “ADVANCE” selector YES is checked (✓): During the programmed time, the charger motor will be activated but no laser beam will be emitted.
- If the “ENABLE RETURN” selector is NOT checked (✓): the wire will not return once the laser activation is complete.
- If the “ACTIVATE RETURN” selector YES is checked (✓): the wire will return when the laser activation is completed according to the set values.

**Con formato:** Párrafo de lista, Izquierda, Con viñetas + Nivel: 1 + Alineación: 0,63 cm + Sangría: 1,27 cm

**Con formato:** Fuente: Negrita, Francés (Francia)



**GAS**

<b>PRE-GAS</b>	<b>Gas blowing</b> protection before welding, intended to eliminate the air surrounding the welding axis. It is expressed in milliseconds (ms).
<b>POST-GAS</b>	<b>Gas blowing</b> protection after welding, intended to eliminate the air surrounding the welding axis. It is expressed in milliseconds (ms).




The "GAS" option allows manual activation of the solenoid valve, intended to purge the gas system.

Once the desired parameters have been selected, using the START button we can access the welding screen to start working.

#### 8.4.2.1 SELECTION OF THE WELDING PROFILE

In the "PROFILE" option you can select working profiles (groups of saved parameters) and edit them if necessary, or work directly with the PROFILES already created. Automatically, the equipment is delivered from the factory with a "default" PROFILE with generic parameters.




To view existing PROFILES, you can navigate using the arrows at the top of the screen. By changing PROFILE, the settings associated with each profile will load automatically.

If you want to view the list of all saved PROFILES, you can navigate using the arrows, or select the three lines, which give access to the menu on the left side of the screen, then select the "search" option.


#### 8.4.2.2 SEARCHING, CREATING, SAVING AND EDITING PROFILES

In this case, a list will appear on the right side of the screen, allowing us to select the WELDING PROFILE we want.

From the ADVANCED WORK option you can search, create, save, edit and delete WELDING PROFILES. To perform any action related to WELDING PROFILES you must access through the following submenu option. A column will open on the left side of the screen.




The magnifying glass allows you to search through the PROFILES saved in a list. The list will appear on the right side of the screen.



To select a PROFILE, simply tap the left side of the PROFILE line you want to choose, then select LOAD.



The + symbol allows you to create a new WELDING PROFILE by editing all the parameters again and giving it a new name.



Once the desired settings have been selected, it is necessary to click on the save icon. Otherwise, if you change profiles or exit the menu without saving the changes, they will not be saved in the profile concerned.



This option allows the user to revert to the last saved settings.




By pressing this icon, the WELDING PROFILE will be deleted.

#### 8.4.2.3 CLEANING AND POINTING (MANUAL MODE)


From MANUAL WORK, spot welds and cleaning welds can be performed using the CLEANING "NET" and POINT options.

Selecting these options in the "LC WELD MODE" welding screen changes the displayed equipment parameters to suit cleaning and spotting tasks.

From the MANUAL screen and selecting CLEANING "NET" or POINT, some basic settings appear and can be changed to work. The MANUAL option allows you to edit and save the POINT and CLEANING settings.



For the POINT function, parameters related to LASER, SCAN, FEEDER and GAS can be selected.




For the CLEANING function, parameters related to LASER, SHAPE and GAS can be selected.

Depending on the parameters entered in this screen, if the POINT parameters are edited and saved, they will be directly linked to the combination of options entered in this first SINERGIC work screen.

In the case of CLEANING, the saved parameters are general for all combinations. It is not possible, in SINERGIC mode, to save a modification of the CLEANING parameters.

By using the 'RESET' option you can recover the factory settings.



#### 8.4.3 WELDING SCREEN

To work, you must access the welding screen using the "START" icon that appears in the different working modes (BASIC, ADVANCED or JOBS).

To access this screen, it is essential that the "SYSTEM READY" indicator is green, otherwise the program will not allow access to the welding screen.

This screen is different from others because it is black in color.

If the ground connection is correct and there are no system alarms (cooling to the correct temperature, no laser incidents), the equipment will allow the user to perform welds.



IMPORTANT

**It should be noted that if the equipment has an anomaly or an active alarm (see section 8.9 - ALARMS) or if the system is not ready (SYSTEM READY), the program will not allow access to the welding screen to work.**

#### In the welding screen:


- The "CONNECTION" indicator shows whether the necessary contact of the gun with the table and the EARTH is made correctly.
- The 'WELDING' indicator in the central part of the screen indicates when the laser is emitting.



If it is GREEN, the laser is emitting and poses a risk to unprotected persons.

As mentioned in other sections, this signal can be reproduced outside the cabin, for example at traffic lights.

- The 'STOP' button allows you to exit welding mode and return to the previous screen.
- Using the 'FEEDER' button, the feeder is activated or deactivated. When activated, new controls will appear on the screen to control the feeder parameters. With the 'FEEDER FORWARD' and 'DISTANCE REVERSE' options, you can fine-tune the feeder regulation to work in the desired way.
- With the arrows on the right side "MANUAL" you can manually advance or rewind the wire.
- In the central part of the welding screen there is a section reminding the necessary PPE and the obligation to use it by the worker.



IMPORTANT

**If there is no ground, when you press the button on the welding gun and the wire feeder is active, the wire will automatically come out by itself.**


At the top you can see some welding related parameters:




- LASER POWER
- LASER FREQUENCY
- LASER WORKING CYCLE
- FORM FREQUENCY
- SHAPE WIDTH

#### 8.4.4 SCREEN FOCAL LENGTH

In the "JOBS" menu you will find the "FOCAL LENGTH" option.






Using the START button we can start pulling every XX mm to find the welding distances DS1 and DS2.

The 'POSITION' square indicates the position of the threaded tube (-10mm, -8mm, -6mm, etc.) that the user must adjust before each shot.


**See POINT 7.5 for a detailed explanation of how to set the focal length.**

#### 8.4.5 CALIBRATION SCREEN

Through the CALIBRATION screen, you can center the red pointer on the inside diameter of the gun tube, as well as align it with the filler wire.

By pressing the icon , the next window will open, allowing the user to move the red pointer from left to right to center it correctly:

Red Pointer Centering Screen:

**IMPORTANT**

The red pointer must always be centered on the gun outlet tube, regardless of its position on the screen. To calibrate the center of the tube with the center of the screen, please contact the technical support of your official distributor

If you are unable to center the red dot using the calibration screen, please contact your technical support for assistance.

**8.5 TASKS****TÀCHES**

The LC-WELD PRO team allows you to create and manage tasks in detail and assign them to different users.

This allows you to control costs, obtain statistics on each job in different areas, have a record of the work carried out by each of the users, know which jobs are completed, among other options.

This feature is located in the "TASKS" section. This menu is only accessible for ADMINISTRATOR or MANAGER level users. In the "TASKS" menu, you will find the following options:

- NEW TASK
- CURRENT TASKS
- VALIDATED TASKS
- GROUPS



The following points detail how to create new tasks and assign them to users. The summarized sequence for creating a new job would be as follows:

1. Create a new user group via the GROUPS menu.
2. Go to the new NEW JOB to create a new one and assign it to a group.
3. To start a created and assigned task, go to CURRENT JOBS and select the desired task.
4. To continue a job started, it will also be accessible via CURRENT JOBS.
5. To view work already completed, go to VALIDATED WORK.

#### 8.5.1- NEW TASK



NOUVELLE TÂCHE

Through the "NEW TASK" menu, you can create new jobs by entering different variables:

- Task Name
- Number of rooms
- Observations
- Assigned Operator Group
- Name of the part
- Part number
- Material
- Gas



Here is the list of information to enter when creating a new TASK, as well as their explanation:

<b>NAME</b>	This field is intended to enter the name of the task
<b>NUMBER OF PIECES</b>	By pressing the box, a numeric keypad appears to enter the number of pieces contained in the task.
<b>BAND</b>	By clicking on the "GROUP" box, a window opens with the previously created groups containing the users registered in the equipment.
<b>OBSERVATIONS</b>	This space is provided to enter a brief explanation or observations regarding the task to be performed. (OPTIONAL)
<b>PIECE</b>	This space is designed to contain the name of the part to be completed in this task.
<b>PART REF.</b>	Space provided to enter the part reference number.
<b>MATERIAL</b>	By selecting this option, a list of materials appears. You must choose the material of the part to be welded from the list of materials suitable for laser welding: <ul style="list-style-type: none"> <li>• Stainless steel (INOX)</li> <li>• Carbon steel (IRON)</li> <li>• Titanium</li> <li>• Galvanized</li> <li>• Aluminum</li> </ul> To select the desired option, simply touch it and press the "Accept" button.
<b>GAS</b>	You must also select the shielding gas to use. It should be noted that argon will be used for ALL materials





Then tap DETAILS.

### 8.5.2.1. TASK DETAILS

If you select a TASK and press the "DETAILS" button, a screen will display all the information available on the selected TASK:

- TASK information
- TASK time statistics
- details per user of work done so far, including:
  1. the username,
  2. the finished parts,
  3. the total time in the TASK,
  4. total time in working mode,
  5. total time out of work mode
  6. the total welding time.

TÂCHE	UTILISATEUR	COMPLETE	TOTALX min	TRAVAIL min	PAUSE min	SOUDURE min

TEMPS TOTAL	-999999999 min	MÉTRES DE FIL	-999999999.99 m
TEMPS TRAVAIL	-999999999 min	SOUDURE	-999999999 min
TEMPS DE PAUSE	-999999999 min	PIÈCES TERMINÉ	-999999999

#### TO COMPLETE A TASK:

If you want to complete a task, you must go to the "DETAILS" screen and select "VALIDATE".

This way, the TASKS will go from "in progress" to "validated".

### 8.5.3 TASKS PERFORMED





#### 8.5.4 GROUPS



GROUPES


In this section the creation and/or deletion of user groups is managed.

The creation of GROUPS is necessary for the subsequent creation of JOBS, since these must be assigned to a user group (whether at OPERATOR or MANAGER level).

The ADMIN user cannot be included in a group.

Groups can have a maximum of 6 users.


By pressing the GROUPS icon in the JOBS menu, a screen will open containing the list of ALL created groups with the details of all users assigned to each group:




The ADMIN user cannot be included in a group.



Groups can have a maximum of 6 users.

By pressing the GROUPS icon in the TASKS menu, a window opens containing the list of ALL created groups with the details of all users assigned to each group:



To create new groups, click on "NEW". Then another screen will open, with two lists:



- In the "NAME" box, you must enter the name assigned to the group being created.
- The LEFT list is the list of ALL USERS created in the system.
- The list on the RIGHT is the list of users introduced into the new group.
- To select system users and assign them to a group, they must be selected from the "USER" list and entered into the "OPERATOR" list using the .
- To remove a user from the group being created, simply select them and press the cross .

CONDITIONS for creating groups:

- It is mandatory to give a name to the group, at least one character.
- At least one user must be added to the group.
- A maximum of 20 groups can be created.
- You cannot delete a group if it has active or pending TASKS.

## 8.6 CONFIGURATION



CONFIG

In the 'CONFIG' option you can access the configuration submenu, to edit the general configuration of the equipment and to access various information about the equipment.


The options available in the "CONFIGURATION" menu are as follows:

- LANGUAGE
- ETHERNET

## ORIGINAL USER'S MANUAL



- UPDATE
- FACTORY RESETS
- DATE & TIME
- ADMIN
- SYSTEM INFO
- EXPORT
- BACKUP



**NOTE** Depending on the USER level, more or fewer options will appear on this screen.

### 8.6.1- LANGUAGE



LANGUAGE

Click on the "LANGUAGE" icon to access the different languages available.

- o Languages available: English, French, Italian, Portuguese, Spanish, French, Italian, Portuguese, English

Simply click on the icon of the desired language and then press the "back" button



. The system will have changed the language in all fields.



A

## 8.6.2 ETHERNET




Press the "ETHERNET" icon to access the configuration of the Ethernet network connection of the equipment.

To configure the internet connection, if you do NOT want to configure the network settings manually, you can select the DHCP option that appears on the screen.

The network where the device is connected is assigned an IP address automatically:

1. Connect to the Ethernet port with the local network.
2. Change the network configuration, we can do it in two ways:
  - Manually: Changing the fixed IP and the Gateway IP.
  - Automatically: Selecting the DHCP option.



The Ethernet port is located on the back of the equipment.



- If the **IP configuration** is correct and the Ethernet cable has Internet service, the device will automatically **connect to the "cloud"**.
- You can access the **"cloud"** with your customer account and you will be able to see **the equipment data through the "dashboard"**.
- To access the **"cloud" service**, you must log in with your computer at: <https://unitronics.cloud/> and log in with your user account.



#### IMPORTANT

**Important, if automatic network configuration (DHCP) is used, the external OPC-UA communication protocol is disabled. If you do not use this protocol with an external network, you may ignore this message.**




### 8.6.3 FACTORY RESETS



In the 'FACTORY RESETS' option, the ADMIN and MANAGER users are given the option to reset the parameters of the equipment to the factory defaults in different fields:

#### FACTORY RESETS

- **TASKS, GROUPS AND USERS:** Allows you to delete all TASKS, GROUPS and USERS at once. All these categories are eliminated at once because they are all related to each other.
- **JOBS:** Allows you to delete all the created Jobs
- **SYNERGIC PARAMETERS:** Allows ALL parameters modified on any occasion to be returned to their factory settings (both the welding parameters and the POINT and CLEANING parameters).
- **STATISTICS:** Allows you to delete all statistics collected by the team's system and reset all values to 0.





## 8.6.4 ADMIN



ADMIN

This screen allows you to change the administrator user name and password.

Access is only possible from an ADMINISTRATOR level user.

2/09/2012  
EN 99:99

CONFIGURATION - ADMIN

CURRENT PASSWORD

NEW NAME

NEW PASSWORD

DEFAULT SETTINGS CHANGE SETTINGS

To update name and password of the ADMINISTRATOR profile:

10. Enter the current password.
11. Enter the desired new user name.
12. Enter the desired new password.
13. Press the 'CHANGE SETTINGS' button.

The "DEFAULT SETTINGS" button allows you to revert to the default user name and password.

- User: ADMIN
- Password: 1




### 8.6.5 SYSTEM INFO



The SYSTEM INFO section is only visible to the administrator user.

Under SYSTEM INFO various information about the internal control system of the equipment is displayed.

In the event of a breakdown or malfunction of the system, the Technical Assistance Service may require information from this section.



The UPDATE button on this screen reads the version of the system devices, as long as they are active. If any component of the equipment is changed, this information must be updated.

### 8.6.6 UPDATE



The UPDATE menu allows the user to choose between:

- ☒ - Update the equipment's software and firmware.
- ☒ - Update the equipment's multimedia help.

The updates will basically consist of 3 stages:

- USB preparation
- USB connection
- Automatic update process

**IMPORTANT**

**It is necessary to use the USB drive provided with the machine. The system requires a USB drive with the compatible format.**

**1- USB preparation**

The information necessary for the update will be sent via "WeTransfer" or another similar service. The file has to be located in the root of the USB provided by LC and cannot be in subfolders.

You will receive the information compressed in a file called "uni.zip", this file should not be unzipped:

Nombre	Fecha de modificación	Tipo	Tamaño
CE	07/11/2023 12:09	Carpeta de archivos	
GAR	07/11/2023 12:09	Carpeta de archivos	
MAN	07/11/2023 12:08	Carpeta de archivos	
VID	09/11/2023 11:39	Carpeta de archivos	
uni.zip	17/11/2023 10:00	Archivo WinRAR Z...	570.492 KB

**IMPORTANT**

**Do not modify, move or delete files in these folders, or change folder or file names to ensure a smooth update.**

**2- USB connection on the machine**


The update is performed by means of a file contained on a USB stick (pen drive), which must be inserted into the USB slot on the back of the computer.





### 3- Automatic update process

Select the "UPDATE" icon on the system or media and wait for the system to complete the whole process.



IMPORTANT

**It is crucial to wait for the machine to reboot itself after the update. Do not interrupt the process, remove the USB or turn off the power under any circumstances.**

UPDATE → Update firmware and software.

MULTIMEDIA → Updates all system media (documents, videos)




IMPORTANT

**If any part of the process is interrupted, please contact your nearest service centre.**



### 8.6.7 DATE & TIME

The 'DATE&TIME' option allows us to change the date and time of the device:




### 8.7 HELP



HELP

In the 'Help' menu you will find different options:

- Documentation
- Videos
- Technical Service
- FAQs






### 8.7.1- DOCUMENTATION



#### DOCUMENTATION

Click on the "DOCUMENTATION" icon to access a series of digital documents related to the LC-WELD PRO device:

- User manual
- EC Declaration of Conformity
- Warranty manual



### 8.7.2- VIDEOS




#### VIDEOS

In the "VIDEOS" section you will find a series of explanatory videos about the equipment and its operation.

There is a video on laser safety and a video on tips and tricks applied to laser welding.

With the next updates, the number of videos will be increased, as well as their subject matter.





### 8.7.3. TECHNICAL SERVICE



By clicking on the "TECHNICAL SERVICE" icon, you can access two lists of information:

- Official distributor
- LC Lasers

**TECHNICAL SERVICE** These listings contain contact information for both entities.

DISTRIBUTOR		MANUFACTURER	
COMPANY	<input type="text"/>	COMPANY	<input type="text"/>
COUNTRY	<input type="text"/>	COUNTRY	<input type="text"/>
CITY	<input type="text"/>	CITY	<input type="text"/>
ADDRESS	<input type="text"/>	ADDRESS	<input type="text"/>
PHONE	<input type="text"/>	WEBSITE	<input type="text"/>
E-MAIL	<input type="text"/>		

## 8.8 ALARMS




### ALARMS

The "ALARMS" section allows ALL users to view the overall status of the entire system, showing the active and inactive alarms of the system.

There are alarm indicators in different fields:

- Gun Control
- Chiller
- Feeder
- Laser
- Gas



- **GUN CONTROL:** This section shows the alarms related to the general electronic control board of the equipment.
- **CHILLER:** This section shows the status of the chiller control board.
- **FEEDER:** This section shows the status of the wire feeder control board.
- **LASER:** The LASER section displays various information on the status of the laser resonator.
- **GAS:** Finally, the GAS section shows information about the gas circuit.

**\*All the information on this screen may be required by the Technical Assistance service for remote diagnostics.**

In certain cases, the registered error code is also displayed.


As soon as certain errors appear, they can be quickly corrected and, in some cases, the system must be REARM.

In this case the REARM button appears. Simply press it to reset the system.

To see more information about the alarm type codes, press the “” button.

### 8.8.1 ALARMS HISTORY

In the 'HISTORY' option you can access the history of alarms that have appeared. The table indicates the error codes, the alarm time and the date.



If you want to clean the alarm history, we can select 'CLEAR ALL'.

### 8.8.2 ALARM EXPLANATION

On the alarm screen, if one is activated, an information panel will appear with details about the activated alarm. Below are the possible alarms:

<b>CHILLER FLOW 2</b>	<p><b>THE CHILLER WATER CIRCUIT IS NOT FLOWING CORRECTLY. The causes of this problem can be several: low water level, bad Pump operation, flow sensor failure or chiller do not receive power.</b></p> <p><b>Check the water level. If the alarm persists, contact technical support.</b></p>
<b>CONTROL_TEMP</b>	<p>OVERTEMPERATURE OF THE GUN. Temp control = gun overtemperature.</p> <p>This alarm warns that a very high temperature has been detected inside from the gun. This may indicate that the light beam has deviated from its normal path causing serious damage to the light distribution mechanism.</p> <p>Contact your service representative.</p>
<b>E00CO</b>	<p>Communication between the system and the gun control has failed</p> <p>This occurs when the system sends an order to the controller and does not receive a response indicating that the order has been executed. When this happens,</p> <p>The reset button will appear and the system will have to be rebooted.</p>



	If these alarms persist, contact technical support.
<b>E00XW00</b>	<p>The gun control watchdog is no longer received</p> <p>This occurs when communication between the gun and the machine has been interrupted. It may be caused by the hose being pulled or stepped on, electromagnetic interference or due to a malfunction of some internal device of the machine.</p> <p>Contact technical support.</p>
<b>E00XZ00</b>	<p>Communication between gun control and machine has not been initiated correctly</p> <p>This alarm occurs when, upon startup, communication with the gun control does not begin, normally caused by disconnection of the communication cables.</p> <p>Contact technical support.</p>
<b>E01CO</b>	<p>Communication with the laser has failed</p> <p>This occurs when the system sends a command to the laser and does not receive a response indicating that the command has been carried out. When this happens, the reset button will appear and the system will have to be restarted.</p> <p>If these alarms persist, contact technical support.</p>
<b>E01CR01</b>	<p>Communication with the laser has failed</p> <p>This alarm occurs when too many erroneous communication frames have been received when reading the laser status.</p> <p>Contact technical support.</p>
<b>E01CT00</b>	<p>RS232 communication module has failed</p> <p>This module is responsible for communication with the laser. Get in contact with technical service.</p>
<b>E01XA00</b>	<p>Communication with the laser has failed</p> <p>This alarm occurs when the laser status cannot be read. Turn off the machine and turn it on again, if the problem persists, contact the technician.</p>
<b>E01XB</b>	<p>An internal laser error has occurred</p> <p>The last two numbers of the error code indicate the type of error. Contact your service representative.</p>
<b>E01XL00</b>	<p>Laser license is blocked</p> <p>You need to contact technical service to unlock the laser.</p>
<b>E02CO</b>	<p>Communication with the feeder has failed</p> <p>This occurs when the system sends an order to the feeder and does not receive a response indicating that the order has been executed. When this happens the reset button will appear and the system will have to be restarted.</p>
<b>E02XW00</b>	The feeder watchdog is no longer received



	<p>This occurs when communication between the system and the feeder has been interrupted. It may be due to the poor condition of the communication cables with the power supply.</p>
<b>E04BN02</b>	<p>The system's internal battery has run out</p> <p>The system cannot function without it. Contact technical support to replace the battery.</p>
<b>GAS</b>	<p>Gas status.</p> <p>The system will not be ready until the gas pressure is correct, as shown by the active gauge.</p> <p>If, during start-up, the pressure level drops too low, the system will enter an error state. The reset button will appear and the system must be rebooted.</p> <p>If, when the gas cylinder flow rate varies, the system does not change from off-low-active or vice versa, this will indicate a malfunction of the internal pressure sensor. Contact technical support.</p>
<b>LASER_INTERLOCK</b>	<p>Laser lock signal has been activated</p> <p>The interlock is activated from the rear of the machine with the connection of the cabin or by the internal emergency self-activation indicated by the int alarm. Stop.</p> <p>Check cabin control status</p> <p>When the system is ready for welding or welding and this alarm is activated, the reset button will appear and the system will have to be restarted.</p>
<b>LASER_QBH</b>	<p>This alarm indicates that the laser output device (qbh) is failing</p> <p>Probably because; is not properly anchored to the gun, there has been a break in the optical fiber or the internal electrical circuit of the laser is damaged.</p> <p>If the fault persists when checking the qbh, contact Technical Service.</p> <p>When the system is ready for welding or welding and this alarm is activated, the reset button will appear and the system will have to be restarted.</p>
<b>LASER_TEMP</b>	<p>The working temperature has not been reached or has been exceeded</p> <p>Wait until the working temperature is correct</p> <p>If the chiller has been running for a long period of time and the alarm does not go away, it means that the chiller is not working properly, it is not capable of heating the laser sufficiently.</p> <p>On the other hand, this alarm will also appear when the chiller cannot cool the laser, caused by an overtemperature of the system.</p>



In these cases, contact technical support.

When the system is ready for welding or welding and this alarm is activated, the reset button will appear and the system will have to be restarted.

**W04BL01**

Internal system battery is low

The battery needs to be replaced soon, if the battery runs out the system will crash. Contact technical support.

**8.10 STATISTICS****STATISTICS**

One of the major technological advances of LC-WELD PRO is its excellent costing capabilities and the automatic creation of cost statistics.

This menu is closely related to the TASKS, since, thanks to the information gathered by the system through the TASKS, the programme is able to create detailed statistics on welding costs, being able to calculate them per operator, per task, per piece and per metre of welding, among others.

Two icons appear in the "STATISTICS" menu:

- Statistics
- Costs


**8.10.1 COSTS**

In the submenu option 'Costs' you can create cost profiles:

This is the data the team needs to calculate statistics in a detailed and realistic way, adapting the actual job prices to the costs shown for completed jobs.



By creating cost profiles, it will be possible to assign them to each TASK, so that actual costs can be calculated more specifically.



Cost profiles are groups of indicators to be able to calculate the actual price of a welding job (labour price, gas price, electricity price and input rates).

To create a **new cost profile**, select NEW.

A screen with different fillable boxes will open: both the name of the cost profile and the detailed prices must be entered:

- Gas prices
- Price of labour
- Electricity prices
- Price of input material
- Gas flow used in welding



Once you have entered all the values, and the name of the profile, just press "SAVE" and the cost profile will be created automatically.

Once cost profiles have been created, when viewing statistics we can select THROUGH which cost profile we want to view the statistics. As explained above, we can also classify the statistics according to user. By means of the options marked with the red box, the USERS or COST PROFILES options are edited.


### 8.10.2 STATISTICS



The internal "STATISTICS" section shows global data of the equipment in relation to consumption.

A distinction is made between three groups:


- **GLOBAL:** The total time the equipment has been on, and the percentage of this time in which the act of welding has been carried out, is shown.
- **FILLING:** The "FILLING" section shows the percentage of the total time in which welding has been carried out WITH material input, and the metres of input material consumed.
- **CONSUMPTION:** gas consumption in litres and electricity consumption in KW/h are shown.



At the bottom right of the screen there is a "WORKS" icon, next to a tab where you can select between current or validated tasks.



Select the type of task you want to consult and then click on WORKS to enter the list of tasks. Once in the WORK list, select the desired WORK and press "GO".





Within the selected WORK you will find a very detailed list of all costs related to this same WORK. It is divided into 5 groups:

- TIME
- CONTRIBUTION
- CONSUMPTION
- PARTS
- COSTS

STATISTICS - CURRENT WORKS - VALUES	
<b>TIME</b>	
TOTAL TIME	-999999999 min
WORK TIME	-999999999.9 %
PAUSE TIME	-999999999.9 %
WELD TIME	-999999999.9 %
<b>FILLING</b>	
WELD FILLING	-999999999.9 %
FILLING METERS	-999999999.9 m
<b>CONSUMPTION</b>	
GAS	-999999999.999 m <sup>3</sup>
ELECTRIC	-99999999.99999 KW
<b>COSTS</b>	
ELECTRIC	-999999999.9 €
FILLING	-999999999.9 €
LABOUR FORCE	-999999999.9 €
GAS	-999999999.9 €
TOTAL COST	-999999999.9 €
COST PR PIECE	-999999999.9 €
COST PR METER	-999999999.9 €
<b>PIECES</b>	
NUMBER OF PIECES	-999999999
AVERAGE TIME	-999999999 s

**TIME:** This section shows all the information related to the operating time of the equipment during the selected WORK:

- **TOTAL TIME (MIN):** This is the total time the system has been executing the TASK, regardless of the status of the job.
- **WORK (%):** Percentage of the total time spent INSIDE the LC-WELD MODE welding screen.
- **PAUSE (%):** Percentage of the total time spent OUT of the LC-WELD MODE welding screen.
- **WELDING (%):** Percentage of total time actively welding with the equipment.

**FILLING:** This section shows the information concerning the contribution material:

- **WELD. WITH WELDING (%):** Percentage of the total time welding with wire input.
- **METRES OF WELD (m):** Total metres of wire used by the equipment during welding.



**CONSUMPTION:** This section shows data on the consumption of the equipment:

- **GAS (L):** Gas consumption of the task is shown in litres.
- **ELECTRICAL (KW/h):** The electrical consumption during the task is displayed in KW/h.

**PIECES:** Information about the pieces made is displayed:

- **NUMBER OF PIECES:** Total number of total parts in the task
- **AVERAGE TIME:** average time per piece

**COSTS:** The designated cost ratio is shown for each of the parameters. The costs are separated into profiles. Different cost profiles can be applied to the same task by selecting them with the side arrows on the tab at the top of the COSTS.

In case you want to reset the GLOBAL statistics of the equipment, see the function of point 8.6.4 FACTORY RESETS.

In the section ACTUAL TASKS you can separate the costs per operator:

STATISTICS - CURRENT WORKS - VALUES		2/09/2012 EN 99 : 99	
TIME		<span style="border: 1px solid red; padding: 2px;">USERS</span>	
TOTAL TIME	-999999999 min	COSTS	
WORK TIME	-999999999.9 %	ELECTRIC	-999999999.9 €
PAUSE TIME	-999999999.9 %	FILLING	-999999999.9 €
WELD TIME	-999999999.9 %	LABOUR FORCE	-999999999.9 €
FILLING		GAS	-999999999.9 €
WELD FILLING	-999999999.9 %	TOTAL COST	-999999999.9 €
FILLING METERS	-999999999.9 m	COST PR PIECE	-999999999.9 €
CONSUMPTION		COST PR METER	-999999999.9 €
GAS	-999999999.999 m <sup>3</sup>	PIECES	
ELECTRIC	-999999999.9999 KW	NUMBER OF PIECES	-999999999
		AVERAGE TIME	-999999999 s

Through the arrows we can navigate through the statistics of each user.



2/09/2012  
EN 99 : 99

STATISTICS - CURRENT WORKS - VALUES - USERS

USER

TIME	
TOTAL TIME	-999999999 min
WORK TIME	-999999999.9 %
PAUSE TIME	-999999999.9 %
WELD TIME	-999999999.9 %

FILLING	
WELD FILLING	-999999999.9 %
FILLING METERS	-999999999.9 m

CONSUMPTION	
GAS	-999999999.9 m <sup>3</sup>
ELECTRIC	-99999999.99999 KW

COSTS	
ELECTRIC	-999999999.9 €
FILLING	-999999999.9 €
LABOUR FORCE	-999999999.9 €
GAS	-999999999.9 €
TOTAL COST	-999999999.9 €
COST PR PIECE	-999999999.9 €
COST PR METER	-999999999.9 €










PIECES	
NUMBER OF PIECES	-999999999
AVERAGE TIME	-999999999 s

### 8.11 EXPORT STATISTICS

Within the SETTINGS menu, there is the EXPORT option:

2/09/2012  
EN 99 : 99

CONFIGURATION

 LANGUAGE	 ETHERNET	 UPDATE	 FACTORY RESETS	 DATE & TIME
 ADMIN	 SYSTEM INFO	 EXPORT	 BACKUP	

**NOTE**

Depending on the USER level, more or fewer options will appear on this screen, depending on the permissions of each user level.



With the LC WELD PRO equipment it is possible to export machine statistics and data in .csv files.

To carry out the export, a USB must be connected to the back of the machine



IMPORTANT

**It is necessary to use the USB drive provided with the machine. The system requires a USB drive with the compatible format.**

The connected USB must have the folders created and ordered in a certain way. First of all, a folder with the name EXPORT must be present.

BACKUP	12/02/2024 10:30	Carpeta de archivos
CE	09/11/2023 13:28	Carpeta de archivos
<b>EXPORT</b>	12/02/2024 10:40	Carpeta de archivos
FAQ	30/11/2023 9:49	Carpeta de archivos
GAR	30/11/2023 9:42	Carpeta de archivos
MAN	30/11/2023 9:42	Carpeta de archivos
VID	30/11/2023 10:47	Carpeta de archivos

Inside 'EXPORT', the following subfolders must exist:

<b>ERRORS HISTORY</b>	12/02/2024 10:40	Carpeta de archivos
<b>MANUAL JOBS</b>	12/02/2024 10:40	Carpeta de archivos
<b>STATISTICS</b>	12/02/2024 10:40	Carpeta de archivos
<b>USERS HISTORY</b>	12/02/2024 10:40	Carpeta de archivos
<b>USERS SESSIONS</b>	12/02/2024 10:40	Carpeta de archivos
<b>WORK GROUPS</b>	12/02/2024 10:40	Carpeta de archivos
<b>WORKS HISTORY</b>	12/02/2024 10:40	Carpeta de archivos
<b>WORKS IN PROCESS</b>	12/02/2024 10:40	Carpeta de archivos

The files will be created directly in each folder, with names predetermined by the system. If files with the same name already exist in the folders, the files will be overwritten. Likewise, if the folders have another name, the export will not execute correctly.

nombre	fecha de modificacion	tipo	tamaño
WORKS_IN_PROCESS	04/01/2024 10:29	Archivo de valores sepa...	3 KB



To export data, once the USB is connected, you must access the 'SETTINGS' and 'EXPORT' option. ON this screen, we can select what data we want to export.



The USB should not be removed while the export is running.

## 8.12 BACKUP


In the CONFIGURATION menu, there is the BACKUP option. This option will only be visible from the ADMINISTRATOR user.






The purpose of BACKUP is to export copies of existing configurations so that they can be imported into other machines. For example, if there are multiple 'manual jobs', users, job groups and tasks in a system, and you do not want to create them again on another machine, BACKUP allows you to export this data to import it on another computer.

Within the BACKUP menu, we find these options:



### 8.12.1 BACKUP EXPORT

An identification code must be entered. The file created in the export will have this name. To avoid creating files where the identifier has invalid characters (since the system will not find them) it has been limited to only numeric characters. The identifier code must only have numeric characters.





The inserted USB must have a folder with the name 'BACKUP'.

BACKUP	12/02/2024 10:30	Carpeta de archivos
CE	09/11/2023 13:28	Carpeta de archivos
EXPORT	12/02/2024 10:40	Carpeta de archivos
FAQ	30/11/2023 9:49	Carpeta de archivos
GAR	30/11/2023 9:42	Carpeta de archivos
MAN	30/11/2023 9:42	Carpeta de archivos
VID	30/11/2023 10:47	Carpeta de archivos

To export data:

- a. Insert a USB with a folder named 'BACKUP'.
- b. Enter an identification code.
- c. Select export.



#### IMPORTANT

**It is necessary to use the USB drive provided with the machine. The system requires a USB drive with the compatible format.**

#### 8.12.2 IMPORT BACKUP

To import data from one machine to another, we must first have carried out the export as indicated in point 8.12.1.

On the USB connected to the machine there must be a folder with the name 'BACKUP' and inside the file exported from another machine.

123	31/01/2024 8:49	Archivo	257 KB
-----	-----------------	---------	--------

In the CONFIGURATION – BACKUP – IMPORT menu, we will access a screen that allows us to import the data.



2/09/2012  
EN 99 : 99

CONFIGURATION - BACKUP - IMPORT

IDENTIFIER CODE

IMPORT

STATUS

USERS, WORKS AND GROUPS  STATISTICS  
 MANUAL JOBS  COST PROFILES

You must enter the identification code corresponding to the file you want to import.

The boxes on the right side of the screen allow you to select what data you want to import. The data in the selected boxes will be modified during data import. Also, the synergistic parameters if they are not by default.

When importing the data with the chosen file, the calibration data, focal length, system information, administrator credentials, technical service data and error table will not be modified.

**IMPORTANT**

**It is necessary to use the USB drive provided with the machine. The system requires a USB drive with the compatible format.**



# CHAPTER 9 - WELDING PARAMETERS

LC-WELD PRO machines incorporate an advanced system for selecting the appropriate welding parameters for each material and thickness.

Even so, it is interesting and necessary to know how the different variables in the "Advanced" parameter table behave, as the operator must be able to modify the parameters proposed by the synergic system and adapt them to his needs in order to fine-tune the results as much as possible.

In that sense, this chapter will be divided into 3 parts:

- Use of the LC-WELD PRO synergy system.
- Explanation of the behaviour of the different existing parameters.
- Tables of indicative parameters separated by materials.

## 9.1 - LC-WELD PRO EQUIPMENT PARAMETERS

As mentioned above (Chapter 8 - Software), the LC-WELD PRO laser welding machines incorporate a parameter selection system, accessible from the two possible job types: "Synergic" and "Manual".

Once in the "SYNERGIC- EDIT" or "MANUAL" mode, a menu with various parameterisation options will appear:

PARAMETERS	Unit	Min - Max	EXPLANATION
LASER POWER	%	5-100	Laser power delivered to the weld. It is expressed as a <b>percentage (%)</b> . <b>Power</b> is one of the most important parameters determining weld penetration.
LASER FREQUENCY	Hz	10-50.000	Laser beam emission frequency. It is expressed in Hertz (Hz). The frequency is determined by the material to be welded: <ul style="list-style-type: none"> <li>• Ferritic materials: 20,000Hz</li> <li>• Aluminium: 50 Hz</li> </ul>
LASER DUTY CYCLE (LASER DUTY CYCLE)	%	15-99	<b>The amount of time</b> within one Hertz of laser emission in which the




			<p><b>resonator emits</b> laser radiation. It is expressed as a <b>percentage (%)</b>.</p> <p>The <b>duty cycle</b> is determined by the material to be welded:</p> <ul style="list-style-type: none"> <li>• <b>Ferritic materials:</b> 80%.</li> <li>• <b>Aluminium:</b> 100%.</li> </ul>
<b>S.M. SHAPE (SHAPE)</b>	-	Vertical - Horizontal	<p><b>Shape</b> to be drawn by the S.M. system of the gun during welding.</p> <p>This parameter could be equated to the <b>weld combing</b> performed in conventional welding.</p>
<b>S.M. FREQUENCY (S.M. FREQUENCY)</b>	Hz	1-100	<p><b>Frequency</b> at which the S.M. system will move. It is expressed in <b>Hertz (Hz)</b>.</p> <p>In simplified terms, this is the <b>speed</b> at which the weld is to be <b>combed</b>.</p>
<b>S.M. WIDTH</b>	ms	0,1-3,5 CLEAN: 0,1-5	<p><b>Size or width</b> that the <b>LINE</b> is going to have. It is expressed in <b>millimetres (mm)</b>.</p>
<b>FEEDER ADVANCE (FEEDER ADVANCE)</b>	mm/min	350-12500	<p><b>Speed</b> at which the welding <b>wire</b> will advance <b>during welding</b>. It is expressed in <b>millimetres per minute (mm/min)</b>.</p>
<b>FEEDER BACK (FEEDER BACK)</b>	mm/min	350-12500	<p><b>Speed</b> at which the welding <b>wire</b> will go <b>backwards</b> as soon as the welding is <b>completed</b>. It is expressed in <b>millimetres per minute (mm/min)</b>.</p> <p>This parameter is <b>closely linked</b> to the following parameter "<b>BACK DISTANCE</b>".</p>
<b>BACK DISTANCE</b>	mm	0-10mm (inc. 1mm)	<p><b>Distance</b> that the wire will <b>move back</b> as soon as the weld is <b>completed</b>. It is expressed in <b>millimetres (mm)</b>.</p> <p>This parameter, as explained above, is <b>closely linked</b> to the "<b>FEEDER BACK</b>" parameter.</p>
<b>BURN OUT (LASER OUTPUT)</b>	ms	0-2000	<p>This parameter allows us to parameterise separately the switching off of the feeder and the switching off of the laser, i.e. the wire feed is finished first and then the laser beam is switched off. It allows us to configure the programmed time it will take for the laser beam to switch off after the wire feed has been switched off.</p> <p>It is expressed in <b>milliseconds (ms)</b>.</p> <p>This parameter is used to achieve a better welding output. The <b>recommended</b> programming <b>time</b> is around <b>500 ms</b>.</p>



<b>GAS ADVANCE (GAS FEED)</b>	ms	5-300	<b>Pre-emission of pre-work</b> shielding gas, intended to <b>remove the air</b> surrounding the <b>welding shaft</b> . It is expressed in <b>milliseconds (ms)</b> .
<b>GAS RETARD (GAS OUTPUT)</b>	ms	5-300	<b>Post work gas emission</b> , intended to <b>protect the cooling of the weld</b> . It is expressed in <b>milliseconds (ms)</b> .
<b>DELAY AND SELECTOR ADVANCE</b>	ms	0-3000	<p>This parameter can be divided into two functions:</p> <ul style="list-style-type: none"> <li>• If the "<b>ADVANCE</b>" selector <b>does NOT have a "tick"</b>. (✓): During the <b>programmed time</b>, the <b>laser beam will be emitted</b> but the <b>feeder motor will not be activated</b>. This <b>function</b> is intended to <b>preheat</b> some materials before starting the <b>weld bead</b>.</li> <li>• If the "<b>ADVANCE</b>" selector <b>DOES have a "tick"</b>. (✓): During the programmed time, the Feeder motor will be activated but no Laser beam will be emitted.</li> </ul>
<b>FEEDER SELECTOR (WIRE FEEDER)</b>	NA	NA	<p>Activation or non-activation of the wire feed within the welding profile.</p> <ul style="list-style-type: none"> <li>• If the <b>box does NOT</b> have a <b>tick (✓)</b>, the <b>wire feed motor will NOT be activated</b> at any time <b>during the job</b>.</li> <li>• If the <b>YES box</b> contains a <b>tick (✓)</b>, <b>YES will activate</b> the <b>wire feed motor during the job</b>.</li> </ul>



9.2 CHOICE OF WELDING NOZZLES AND CLEANLINESS





# CHAPTER 10 - DASHBOARD AND REMOTE CONTROL

---

LC WELD PRO units have the option of accessing an online Dashboard to view technical and operating data of the unit. In order to start using the device's Dashboard, the user must contact [weldpro@lclasers.com](mailto:weldpro@lclasers.com) with the following information:

---

**Serial number of the welding equipment**

---

**Distribution company from which the equipment was purchased**

---

**Name of the company**

---

**Company address (where the machine is used)**

---

**Company website**

---

**Preferred language**

---

**Contact person:**

- Email (Used to manage in the cloud account)**
  - Name**
  - Surname**
  - Telephone**
- 

With this information, LC's technical team will create a company profile on the remote system and link it to your laser equipment so that the Dashboard can be accessed.




## 10.1 ETHERNET



RED

The "NETWORK" icon will allow us to access the configuration of the equipment's Ethernet network connection.



Before starting, it is important to have all the necessary elements ready to facilitate the process. These are some of them:

Network configuration:

- **Details** provided by the network administrator: IP address, subnet mask, default gateway and DNS servers.

Physical connection:

- **Internet connection available** in the company with an Ethernet **network cable** of sufficient length to connect the equipment to the network.
- If a Wi-Fi connection is desired, a Wi-Fi adapter will be required to connect to the machine's Ethernet port.

Verification of the connection:

- A **computer with internet access** to run a program and attempt to connect to the machine.



IMPORTANT

**This guide is intended for connecting our LC-WELD-PRO equipment via an Ethernet network on Windows operating systems.**




!	IMPORTANT	<p><b>It should be remembered that the steps should be done in this order: 1- Network configuration 2- Physical connection 3-Checking the connection</b></p>
!	IMPORTANT	<p><b>If automatic network configuration (DHCP) is used, the external OPC-UA communication protocol is disabled. If you do not use this protocol with an external network, you may ignore this message.</b></p>

## 10.2 ETHERNET: NETWORK CONFIGURATION

- a. Initial preparation
  - Turn on the equipment without connecting the Ethernet cable.
- b. Access the network configuration
  - Click on the CONFIG icon in the taskbar.
  - Select "NETWORK".
- c. To configure the internet connection, if you do NOT want to set the network configuration manually, you can select the DHCP option that appears on the screen.

The network where the device is connected is assigned an IP address automatically:

- d. Connect to the Ethernet port with the local network.
- e. Change the network configuration, we can do it in two ways:
  - Manually: Changing the fixed IP and the Gateway IP.
  - Automatically: Selecting the DHCP option.





### 10.3 ETHERNET : PHYSICAL CONNECTION

There are several ways to check the internet connection:

- Ping
- Web browser
- Connection to external services

Connecting to external services (which is the one we will use) requires using applications or services that require an Internet connection, such as email or cloud services. If these services can be accessed, the Internet connection is active.

After completing the steps described above for the network configuration, it is necessary to complete the following steps in order to connect your computer to the internet:

- **Physical connection:** turn off the machine, if it is still on, and connect an Ethernet cable with internet to the back of the machine, where you will find an Ethernet port (RJ45).




- **Turn on the power** and wait until the system is fully operational.

### 10.4 ETHERNET: CONNECTION VERIFICATION

If the IP settings are correct and the Ethernet cable has access to the Internet, the device will automatically connect to the cloud. You can access the cloud with your customer account and view the device data via the dashboard at the following link: <https://unitronics.cloud/> (log in with your user account).

After accepting all cookies on the login screen, you will need to log in:



## 10.5 ETHERNET: TROUBLESHOOTING

The problems we may encounter are basically 2:

- **Restricted access:**
  - If you encounter access restrictions, contact the company's IT department to obtain the necessary permissions.
- **Intermittent or slow connection:**
  - Reboot the corporate router or modem to resolve temporary problems.
  - Update the network drivers on the machine, if possible.




IMPORTANT

**Remember: In enterprise environments, follow the network policies set by the company and, in case of persistent problems, contact the company's IT technical support.**


## 10.6 CLOUD DASHBOARD CLIENT

Once the machine has been registered and connected to the internet. The user will be able to access the CLOUD, where from a computer he/she will be able to view different data of the machine.


At the top of the screen, you can choose the serial number to select the equipment for which you wish to obtain statistics.




In this list you can select the equipment:




The display shows the total number of hours the machine has been running, the total time the machine has been in operation and the KWh consumed.



In the following section you can see the laser temperature of the device:



The following section shows the statistics of daily running time and daily welding time:



The 'Machine status' section shows the alarms panel of the equipment, divided in the same way as they are on the machine itself:





## CHAPTER 11 - MAINTENANCE

The LC-WELD PRO laser welding equipment requires regular maintenance to ensure proper operation.

The different operations related to maintenance are detailed below:

- Transport and storage
- Cautions to be taken
- Periodicity of the different maintenance tasks

### 11.1 TRANSPORT AND STORAGE

The different components of the equipment must be stored and kept properly after use:

- **Hose:** It must be coiled in the existing side fittings on the equipment.
- **Gun: it** must be properly fitted into the holder specifically designated for it on the side of the equipment.
- **Feeder or wire feeder:** It must be stored on top of the equipment on the pivoting support specifically designated for it, with the towline attached to the hose or properly coiled, without disturbing the passage or potentially causing accidents. All doors and/or covers must be properly closed and secured.

To prevent it from tipping over during transport, it is recommended to move the LC-WELD PRO Laser welding unit carefully by pushing on the horizontal bar at the front of the unit.

The equipment must always be moved using the wheels.



**Under no circumstances should any attempt be made to lift the equipment manually: serious accidents and/or injuries may occur.**

If it is essential to lift the equipment, forklift trucks or similar must be used, with appropriate safety measures in place.

The person in charge of operating/driving the forklift must be in possession of a valid forklift licence.

- It is advisable to wear safety footwear and appropriate work clothing to protect users' feet and prevent accidents to the skin and the rest of the body.



- The body posture should be appropriate without putting too much strain on the back.  
In case of injury and/or discomfort to any part of the body, refrain from dragging and/or moving the equipment.  
The equipment must be stored in a cool and dry place, free from agents and objects that could damage the materials and/or components.



## IMPORTANT

**It is important to apply the brakes once the equipment has been transported and is in a safe place.**

**It is mandatory to activate the brakes during use of the equipment and in storage: otherwise serious accidents may occur.**

## 11.2 CAUTIONS

The following precautions can be taken into account in general for all LC WELD PRO models.



### General maintenance precautions

For maintenance, repair and inspection, it is essential to **switch off the equipment**, remove the key and press the **emergency stop** switch.



### Welding Gun Maintenance Precautions

Under **no circumstances should the gun** be serviced when the equipment is **switched on**, unless expressly instructed to do so by an authorised Service Centre.

The equipment **must be switched off**, to avoid possible damage or accidents.



### Precautions when handling fibre laser cable.

**Incorrect** handling of the laser fibre cable can damage it and cause **serious problems and** malfunctions in the operation of the equipment. Avoid bending, **dragging or placing excessive weight** on the fibre cable. Do not bend more than 150 mm in diameter.

**Precautions when handling the different optical elements**

Any **scratches or dirt** on any of the **optical elements of the gun** can **degrade** the laser welding process.

For this reason, appropriate measures must be taken to handle any of the optical elements correctly, such as working in a **dust-free environment** and **wearing nitrile gloves** so as not to leave any greasy residue on the optics.

**Precautions when returning to work after maintenance**

Once the maintenance work has been completed and **before using the equipment**, check that all **screws are tight**, all **connections are correct** and that the **safety systems are working properly**.

### 11.3 PERIODIC REVIEWS

To ensure the proper functioning of the LC-WELD PRO laser welding equipment, a number of periodic inspections must be carried out.

#### 11.3.1 DAILY REVIEWS

- **CLEANING THE GUN: Every day at the end of each shift**, the gun must be cleaned **with a cloth** (either cotton or microfibre) and a **NON-AGGRESSIVE** cleaning product (such as glass cleaner), to remove **the dust and surface dirt** accumulated on the gun. While cleaning, it is advisable to check that the gun does not leak water from any joint. Clean the welding tube, check the state of the nozzles and clean the front of the gun (estimated time 5 minutes).
- **CLEANING THE LASER AND GAS EXIT TUBE: Every day at the end of each shift**, the **laser and gas exit tube** of the gun must be cleaned to remove any micro projections that may have become embedded in the nozzle and/or the tube. This must be done with a **circular metal brush** with a diameter of Ø8mm. This operation must be carried out **by extracting the tube** from the gun, unscrewing it after unblocking the locking nut (estimated time 5 minutes).
- **CHECKING THE QBH:** While performing the daily cleaning of the gun, it is advisable to check the condition of the QBH, making sure that it is not loose or unscrewed. It must be firmly attached to the gun and its threaded part turned as far as possible to the right.



Reference photo:



### 11.3.2 WEEKLY REVIEWS

- **GENERAL CLEANING OF EQUIPMENT:** In addition to the daily checks, **every Friday at the end of the last shift** the equipment has to be cleaned in a general way:
  - Clean the side filters to remove accumulated dust.
  - Clean the top tray of the equipment to remove accumulated dust (clean with a cotton or microfibre cloth and a non-aggressive cleaning product such as glass cleaner if necessary).
  - Clean the equipment hose to remove accumulated dirt and dust.

(estimated time 15 minutes)



IMPORTANT

**Cleaning should always be carried out with the equipment switched off and the wheel brakes applied.**

- **WATER LEVEL CHECK:** In addition to the daily checks, **every Friday at the end of the last shift**, check the **level of the cooling water**, which **should not be below 90%** of the indicator bubble on the back of the unit (estimated time 1 minute).

The cooling system **does not consume water**, so if the **water level is found to be too low**, the **unit should be switched off immediately** and an **inspection of the possible leakage points** (cooler outlets and inlets, intermediate hose connectors) should be carried out to



look for possible leaks. If you find **any leaks, discontinue use** and contact your dealer's technical support service.

- **WIRING CHECK:** In addition to the daily checks, **every Friday at the end of the last shift**, all equipment wiring must be checked to ensure that it is in optimum condition and that there are no defects:
  - Power supply cable.
  - Ground cable and clamp.
  - Gas pipe.
  - Gun hose.

---

### 11.3.3 INSPECTIONS EVERY 10-12 MONTHS: REFRIGERATOR WATER AND REFRIGERATOR PUMP FILLING

- **REPLACEMENT OF THE COOLING WATER:** In addition to the monthly checks, the water in the cooler must be replaced **once a quarter**, due to the ionisation of the water as it passes through the interior of the laser.

This operation must be carried out by screwing the refrigerator drain fitting attached to a hose of the desired length, and emptying the tank by operating the stopcock on the drain cock.

Once the tank has been emptied, close the tap and fill the tank with approximately 25 liters of distilled deionized water.

Once the tank is filled, you just have to start the equipment and it will automatically carry out the circuit priming process. The automatic priming process can take up to 4 minutes.

NOTE: In case of failure of the automatic priming system, the circuit can be primed manually following the protocol described below:

---

#### PRIMING OF THE COOLANT PUMP

If you need to manually prime the coolant pump, follow the following steps (this will only be done as a last option, since the equipment already has a self-priming system). During the inspection and changing the water, it may happen that there is no water in the tube at the front of the refrigerator (located at the front of the machine), this will cause the refrigerator pump to not work properly, since the impeller will become damaged. It has emptied of water and therefore must be primed again.

## ORIGINAL USER'S MANUAL



Once the water has been changed, you must check if this transparent tube (easily accessible by removing the front cover of the machine) has water. If it does not contain water, it means that the refrigerator pump must be primed again. To solve it, if once the water in the refrigerator has been changed, this tube does not have water, introduce water through this transparent tube on the front. When the refrigerator pump works again, the equipment will operate normally. If you have doubts or do not solve the problem, contact your usual technical service..





# CHAPTER 12 - DIAGNOSIS AND TROUBLESHOOTING

---

The LC-WELD PRO laser welding machines work with highly advanced technologies.

However, like any industrial equipment, LC-WELD PRO laser welding machines are not exempt from **minor faults and problems** that need to be diagnosed and repaired.

This chapter provides details on how to diagnose these minor faults and/or problems and how to solve them.

## 12.1 DIAGNOSTIC PREMISES

The following are the main premises to be taken into account when diagnosing errors in our LC-WELD devices:

---

### 12.1.1 RULE FUNDAMENTAL

One of the **most important things to understand and keep in mind** is that the **red pointer** indicates the **path the laser beam will follow** when it is triggered.

If you do not see the red pointer on the gun output when switching on the equipment, the cooler and the laser, there are 2 options:

- The laser source is switched off or suffers from a problem and/or malfunction.
- The laser beam (red pointer) is deflected or interrupted, which means that there is an error or malfunction in the optical system, either at the level of dirt/pitting in one of the optical elements or at the level of the S.M. system (the beam is being abnormally directed).

If the laser is deflected or interrupted and the trigger of the welding gun is pulled, it is impossible to know where it will therefore be directed:



**WARNING:** Never fire unless you can see the red pointer on the pistol's trigger guard.

When the red pointer is not present at the tube outlet, it is **imperative to find the cause before attempting to weld.**



**ATTENTION:** Attempting to weld or fire the laser without the presence of the red dot will be considered negligent and the repair will be considered out of warranty.

#### 12.1.2 SEPARATION BETWEEN EQUIPMENT AND GUN

The first step that can be taken in diagnosing a fault is very easy:

We can be **100% sure** that the Laser resonators that equip our machines are specially programmed to **only allow a light beam to be fired** if the resonator is in **PERFECT INTERNAL CONDITION**, so we can draw the **following conclusion**:

**\*IF THE EQUIPMENT EMITS A LASER BEAM (AND AN ALARM IS NOT EMITTED FROM THE CONTROL PANEL IMMEDIATELY AFTERWARDS), ALTHOUGH PRACTICALLY ALL THE POWER IS LOST, WE ARE DEALING WITH AN OPTICAL TYPE ERROR).**

This means, in short, that the resonator can **only fire well**, so any **electrical and/or resonator errors will be automatically ruled out if a shot is fired at the right time**, and the **focus will be 100%** on the **optical system** of the equipment (gun and fibre head).

If, on the other hand, the equipment does **not behave normally** when attempting to weld (the resonator does not fire, the beam does not move normally, the wire does not come out, etc...) attention shall be drawn to the **electrical, electronic and control system of the equipment.**



### 12.1.3 DO NOT INSIST

As soon as an **error** appears **in the optics of the** LC-WELD PRO hand-held laser welding units, the most frequently observed **characteristic is the loss of power of the unit during operation.**

**The most common mistake** made by users of LC-WELD PRO equipment is to **insist on welding**, even going so far as to **increase the percentage of power in an** attempt to make the equipment weld better. This practice can only **further damage the** optics of the gun or the welding head, **making the repair more expensive.**

Therefore, **the most appropriate reaction** to an **eventual loss of power** will be to **check the optical elements one by one in the** order detailed later in this document.

### 12.1.4 STATE OF THE OPTICS

When an optical error is found, the optical system shall be checked.

This means checking the condition of each of the optical elements of the gun and/or the fibre head, and their condition must be **absolutely perfect.**

If we find any **smudges, shadows, or marks** on the surface of any of the **optical elements**, there is a very high percentage of probability that this element is **irreparably damaged.**

Attempts can be made to clean the surface of the optical elements with **microfibre cloths** or **special optical swabs** and **isopropyl alcohol**, but **there is no guarantee** that such cleaning will solve the problem since, as already mentioned, there is a very high probability of **irreparable damage.**

Optics can be checked in **two ways**:

- Counter reflex
- Against the light

Checking **against reflection** simply means looking for the reflection of any light (window, fluorescent, etc...) in the plane of the optical element and checking the perfect condition of the element.

The **backlight** check involves looking through the optical element against any light that is not excessively strong (preferably outdoor or ambient light) and checking that there is no damage to the element.



### 12.1.5 ORDER OF VERIFICATION

As soon as an **optical error** appears with an **apparent loss of power**, the optics of the gun should be **checked** based on the **probability of damage** to the individual elements of the gun and/or fibre head.

But first **of all**, it must be ensured that it is an optical problem, so the **check** will be carried out **strictly in the following order**:

1. Verification of the red pointer (sharp and centred).
2. Verification of focal length (Quality Control Certificate).
3. Checking the threaded pipe and nozzle (Cleaning).
4. Inspection of lens protector(s).
5. Lens inspection.
6. Inspection of the collimator lens

## 12.2 INSPECTIONS OF THE OPTICAL SYSTEM

### INSPECTION OF THE LENS PROTECTOR:

- Use the tool supplied with the gun to loosen the lens protector drawer.
- Carefully remove the drawer.
- Inspect the lens protector against backlight and glare.
- There are two lens protectors, check both carefully.

### LENS INSPECTION:

- Use the tool supplied with the gun to loosen the lens barrel.
- Release the shield block with an Allen key, and loosen the ground cable with an Allen key.
- Remove the protector block carefully to prevent the lens protector from falling off.
- Remove the thermal bridge with an Allen key.
- Once the thermal bridge has been removed, **visually check** the condition of the lens, focusing with a torch or light source if necessary, to look for any damage to the lens.



### IMPORTANT

**The rest of the optical elements of the system (steering mirror system, collimator and fibre head) are for the exclusive use of the Authorised Technical Assistance Service.**

**Any unauthorised tampering will automatically void the warranty on the gun and, if applicable, on the equipment.**



## 12.3 REPLACEMENTS IN THE OPTICAL SYSTEM



**IMPORTANT!!!**

**ATTENTION!!! Any operation related to the optics of the gun must be carried out in an environment FREE OF SUSPENSION DUST, to avoid possible contamination of the optical elements exposed during the operation.**

### 12.3.1 LENS PROTECTOR REPLACEMENT

To change the lens protector, the following steps must be followed:

- Loosen the lens protector housing from the threaded part using the tool provided with the gun. If this part is lost or missing, the following tools can be used:
  - o Screw with M2.5 thread
  - o Allen of M1.5
- Carefully remove the drawer of the lens protector.
- Loosen the stud bolt securing the guard to the drawer with the tool supplied with the gun.
- Remove the ring placed on top of the protector.
- Remove the damaged lens protector by dropping it on your hand and discard it.
- Replace the lens protector with a new one, always holding it by the edge to avoid soiling the lens surface.
- Replace the ring.
- Carry out the process in reverse, fixing the lens protector with the stud bolt, placing the drawer back into the hole.


### 12.3.2 LENS REPLACEMENT

To replace the focal lens, the following steps must be followed:

- Loosen the lens protector housing from the threaded part using the tool provided with the gun. If this part is lost or missing, the following tools can be used:
  - o Screw with M2.5 thread
  - o Allen of M1.5
- Carefully remove the lens drawer
- Loosen the stud bolt that secures the focal lens in the drawer with the tool provided with the gun.
- Remove the ring on top of the lens.
- Remove the damaged lens by dropping it on your hand and discard it.



- Replace the lens with a new one, always holding it by the edge to avoid soiling the lens surface.
- The new lens must **ALWAYS** be fitted **WITH THE CONVEXED PART INWARD OF THE GUN.**



- Carry out the process in reverse, placing the ring on top of the lens, fixing the lens with the stud bolt in the drawer, placing the drawer and fixing it on the gun.

---

### 12.3.3 NOZZLE REPLACEMENT

- Remove the nozzle from the laser and gas outlet tube by turning it counterclockwise.
- Tighten the new nozzle clockwise onto the laser and gas outlet tube.

## 12.4 ERRORS AND MALFUNCTIONS

In the following, different possible faults and malfunctions in the LC-WELD PRO laser welding equipment are detailed, which will be divided into two main sections:

- Errors and malfunctions in the equipment.
- Errors and anomalies in welding.



## 12.4.1 EQUIPMENT FAULTS AND MALFUNCTIONS


### 12.4.1.1 THE PISTOL DOES NOT FIRE

- Check if the red pointer is visible.
- Check that the laser source is switched on ("START" submenu).
- Screen in welding mode ("WORK" submenu, green "START" button, screen with black background).
- CONNECTION" indicator lit (green).
- WELDING" indicator lit (green).
- Check that no alarm signal is emitted ("ALARMS" submenu).
- Check the button on the gun:
  - o Check cable connections in the hose.

### 12.4.1.2 RED POINTER IS NOT VISIBLE

- Check that the laser source is switched on ("START" submenu).
- Check that no alarm signal is emitted ("ALARMS" submenu).
- Check if the lens protector is dirty.
- Check if the lens is dirty.
- Remove the laser head with the laser OFF.
  - o (Case 1) The red pointer is visible so the collimator may be dirty or damaged.
  - o (Case 2) The red pointer looks bad so the laser head may be damaged.
  - o (Case 3) The red pointer is visible. The collimator and head are in very good condition, it could be a problem in the STEERING MIRROR system (contact the service department).
  - o (Case 4) The red pointer is not visible - Contact the Service team.

### 12.4.1.3 THE RED POINTER IS VISIBLE, BUT I CAN'T CENTRE IT.

- Check the centring of the pointer using the "Work profile" screen. Pressing the  icon will open the centring screen.
- If it is not possible to centre the pointer correctly, please contact the Technical Service team.

### 12.4.1.4 ANY ALARM IS ACTIVATED

- Using the ALARMS submenu, detect which alarm it is.
- Please contact the Technical Service team.



#### 12.4.1.5 REFRIGERATOR RISES IN TEMPERATURE AND WILL NOT COOL

- Check that the air filter is not too dirty.
- Check the operation of the side fan.
- Check that the air outlet is not obstructed and has sufficient space to disperse the hot air.
- Possible fault in the cooler (pump, compressor...).
- Possible lack of refrigerant gas.
- Refrigerator replacement (contact the Service team).

#### 12.4.1.6 THE REFRIGERATOR DOES NOT SWITCH ON

- Check that no alarm signal is emitted ("ALARMS" submenu).
- Contact the Technical Service team

#### 12.4.1.7 THE LASER RESONATOR DOES NOT SWITCH ON

- Check that no alarm signal is emitted ("ALARMS" submenu).
- Please contact the Technical Service team.

#### 12.4.1.8 RED POINTER DOES NOT MOVE WHEN SOLDERING

- CONNECTION" indicator lit (green).
- WELDING" indicator lit (green).
- Check cable connections in the hose.
- Please contact the Technical Service team.

#### 12.4.1.9 THREAD DOES NOT DRAG WHEN FIRING

- Display in welding mode ("WORK" submenu, green "START" button, display with black background).
- Feeder mode activated on welding screen.
- Check the roller locking system on the feeder motor.
- Please contact the Technical Service team.

#### 12.4.1.10 SOLENOID VALVE DOES NOT ACTUATE WHEN TRIPPING

- Check that no alarm signal is emitted ("ALARMS" submenu).
- Press GAS on the parameterisation screen and check if E.V. is switched on.
  - o Ignition - Check the welding parameters and the condition of the gas cylinder as well as the flow rate of the regulator.
  - o No power on: check the power supply to the electrical panel.

## ORIGINAL USER'S MANUAL



- Please contact the Technical Service team.

### 12.4.1.11 VERY HOT OR BUBBLY LASER HOSE

- Broken laser fibre - Replace.
- Please contact the Technical Service team.


### 12.4.1.12 THE MACHINE DOES NOT TURN ON

Overvoltage. For these cases, the equipment has two magneto-thermal circuit breakers to protect both the internal electrical circuit and the user.

To reset the system, open the top cover by removing the 4 screws indicated in the image:



Once the cover is open, check that the F1 and F2 magneto-thermal switches have tripped and reset them.





## 12.4.2 WELDING ERRORS AND ANOMALIES

### 12.4.2.1 WHEN WELDING THE PIPE BURNS VERY MUCH

- The beam may be touching the tube: check the centring of the red pointer.
- Check the focal length. if it is not found, there is a problem with the optics (see chapter 12.2).

### 12.4.2.2.2 THE WELD IS NOT REGULAR

- Check the parameters on the work profile screen.
- Check the focal length.
- Check the centring of the red pointer.
- Check the welding position.
- Check that the welding wire comes out correctly and stably.
- Check that the feeder motor provides a constant wire feed.
- Possible presence of moisture in the welding wire.
- Check the optical system (see chapter 12.2).

### 12.4.2.3 THE WELDING LOSES POWER

- Optical problem, check optical section (see chapter 12.2).

### 12.4.2.4 LENS PROTECTORS BREAK TOO OFTEN

- Check that the nozzle and tube are not dirty.
- Check the humidity of the gas.
- Check that the gas pressure is adequate (18-22L/min).
- Check that the gas cylinder is not at the end of its capacity.
- Check that gas is flowing steadily out of the regulator.
- Check that the material to be welded is not very dirty. If it is dirty, it is recommended to clean it with acetone to remove greasy residues.
- The gas flow rate can be slightly increased (2-4L/min more).
- Check the welding position (+/- 55°).

### 12.4.2.5 WELDING ON ALUMINIUM: THE TUBE GETS VERY HOT

- This is normal due to the higher reflectivity of aluminium; keep an eye on the position.

### 12.4.2.6 NORMAL WELDING NOISE IS NOT HEARD DURING WELDING

- The problem could be the focal length, which can change over time.



- Check the optical section (see chapter 12.2).

#### 12.4.2.7 LENS OR LENS PROTECTOR FOGS UP

- Possible condensing environment (high humidity), however, check the optics in general (see chapter 12.2).

#### 12.4.2.8 PISTOL GRIP BECOMES HOT

- Check the output of the red pointer.
- Check the laser head.
- Check the collimator.
- Please contact the Technical Service team.

#### 12.4.2.9 MY EYES ITCH WHEN SOLDERING

- Use a welding fume extractor.
- Wear suitable, approved and well-maintained protective goggles and face shield.

### 12.5 SERVICE AND ASSISTANCE

As LC Lasers' hand-held laser welding technology is a highly innovative technology, it is not uncommon for questions to arise regarding safety, use of PPE, set-up, operation, installation and maintenance of the LC-WELD PRO equipment.

Most of them can be easily solved by reading this instruction and safety manual carefully.

If you have any questions or technical problems, please contact the Technical Assistance Service of your official distributor.

### 12.6 FAILURES

In the event of a malfunction of the LC-WELD PRO laser welding device, the user can only follow the instructions given in the previous points.

In the event of a fault outside the points indicated above, call directly to the Technical Assistance Service of your official distributor to solve the problem, without carrying out



any action other than those described above, leaving the equipment duly switched off, disconnected and stored to avoid damage to third parties.



IMPORTANT

**Under no circumstances open the side covers or carry out any operation on the rest of the equipment that has not been described in this manual. In case of doubt, contact the Technical Assistance Service of your official distributor.**

## 12.7 ACCIDENTS

In the event of an accident with the LC-WELD PRO Laser Welding Unit, a distinction must be made between:

- **Property damage** accidents.
- Accidents involving **personal injury**.
  - **Skin** damage.
  - **Eye** damage.

Call the emergency service and contact the relevant authorities in case of personal injury or physical damage.



# CHAPTER 13 - DISMANTLING THE WELDING DEVICE

## 13.1 LASER WELDING EQUIPMENT DISMANTLING PROCESS

For dismantling laser welding equipment, LC Lasers provides you with a number of tips and instructions to make the dismantling process quicker and easier.

1. Disconnect the gas supply to the laser welding machine.
2. Turn the switch to the OFF position and remove the key. Then put it in a plastic bag and attach it to the front of the device.
3. Disconnect all power cables from the laser welding equipment.
4. At the rear of the welding equipment, disconnect the flexible hose from the gas inlet connection. This is the gas line from the installation that enters the system.
5. Cover the welding head carefully with plastic and bubble wrap.
6. Carefully roll and wrap the hose and place it next to the welding head on top of the device.
7. This will complete the disassembly procedure.



### **WEEE Directive for environmentally safe disposal.**

**Improper disposal leads to pollution and contamination of the environment.**

#### **Precautions:**

- Electronic devices must be disposed of in accordance with regional directives on waste electrical and electronic equipment (WEEE), such as directive 2012/19/EU.
- Do not dispose of this product with unsorted municipal waste. At the end of its useful life, this product should be sent to separate collection facilities for recovery and recycling.
- **Please contact customer service for more information on the decommissioning of this product.**

By properly recycling electrical and electronic equipment, users can ensure **environmentally** sound treatment and disposal of waste to reduce potential environmental or health risks that may occur as a result of improper disposal.



# CHAPTER 14 – ANNEXES

## ANNEX 1 - LASER SOURCE CHARACTERISTICS

OPTICAL SPECIFICATION	<b>Output Power (W)</b>	≤1500
	<b>Operating Mode</b>	CW
	<b>Polarization</b>	Random
	<b>Power Range (%)</b>	1 - 100%
	<b>Central Wavelength (nm)</b>	1070 ±10
	<b>Power Instability (%)</b>	<2,5
	<b>Max. Modulation Frequency (kHz)</b>	50
	<b>Red point Laser power (mW)</b>	1
	<b>Beam Delivery Optics</b>	QBH
	<b>Output Fiber Diameter (µm)</b>	50
ELECTRIC SPECIFICATION	<b>Delivery Fiber Length (m)</b>	10-15.5
	<b>Operating Voltage (VAC)</b>	AC 220V 50/60Hz
	<b>Max Power Consumption (A)</b>	≤20
	<b>Dimensions W×H×D (mm)</b>	435X339X100
OTHER SPECIFICATION	<b>Weight (kg)</b>	20
	<b>Ambient Temperature (°C)</b>	5~40
	<b>Ambient Humidity (%)</b>	10-90
	<b>Cooling Method</b>	Water cooling
	<b>QBH Cooling Water Temperature (°C)</b>	Room temperature (No condensation)
	<b>Cooling Water Temperature (°C)</b>	24 - 26
	<b>Cooling Water Flow with load(L/min)</b>	30
<b>Storage temperature(°C)</b>	-10-50	



## ANNEX 2 - DIRECT, DIFFUSE AND/OR SPECULAR EXPOSURE

To carry out the laser radiation measurements and the assessment of the machine envelope, an instrument from the manufacturer OPHIR was used. The instrument consists of a power meter (or probe) and a reader (or display). As power meters, the thermal probe was used:

- model 3A, low power and high sensitivity,

The measuring probes are connected to the reader (of the Laser-Star model).

In laser welding, marking and/or cutting processes it can be assumed that most of the energy is absorbed by the material and the transmission is zero. However, there is always a part of the reflected energy to which a reflectance factor can be associated  $\rho$ . The part of the reflected energy can be of two types:

- Diffuse reflection, whereby the laser beam loses its directivity and its energy is transmitted in all directions in the space around the process zone. From a laser radiation exposure point of view, this is the shortest range. In the worst case, 100% of the incident energy can be considered to be reflected as scattered light, i.e. a reflectance equal to 1.
- Specular reflection, where a beam incident on a material is simply deflected in a direction opposite to the incidence at the same angle to the plane of the processed material and maintains its directivity. From the point of view of exposure to laser radiation, it is just as dangerous as direct exposure. The UNE-EN 60825-4 standard suggests that it should be assessed by testing.

The expressions used to quantify reflections may vary depending on the configuration of the laser system.